

Ye!!
inspire you always




Stellar | BTS301
Portable Bluetooth Speaker with Lighting
User Manual



Included In This Package

- Stellar
- Micro USB Cable
- 3.5mm AUX Cable
- Wrist Strap
- User Manual

Overview




LED Indicators

Indicator	Status
RED	Charging
GREEN	Fully Charged
BLUE	Paired
FLASHING BLUE	Pairing Mode


How to Charge Stellar

1. Plug the Stellar into your computer or USB compatible wall charger via the included Micro USB Cable.
2. When the Stellar is fully charged, disconnect the cable.

Note: Approximately 3 - 4 hours required for full charge. Battery will last up to 6 hours when connected wirelessly and up to 8 hours when connected through Line-in.




Using Stellar



1. Twist Stellar to the end of the right hand side and the lantern will turn on.
2. Twist Stellar back to the middle and it will turn off all the light.
3. Click on the flashlight button to turn on/off the flashlight
4. Long press the flashlight and mood light button to turn on/off the mood light.
5. While in mood light mode, click the flashlight and mood light button to hold/cancel your desired color.

Getting Connected





Bluetooth Pairing


1. Long press the power & pairing button.
2. The speaker is discoverable and ready for pairing.
3. The status indicator blinks blue.

4. On your Bluetooth music device, turn on Bluetooth and scan for devices in its Bluetooth menu.
5. When the "Ye!! - BTS301" appears on the device list of your device, select "Ye!! - BTS301". The status indicator turns solid blue after paired.

Example: iPad / iPhone / iPod Touch
Press Settings > General > Bluetooth > Bluetooth ON > Ye!! - BTS301 > Pair



Example: Android 4.3 Jelly Bean Smartphone
 Press Settings > Bluetooth ON > Scan > Ye!! – BTS301 > Settings >
 Check the Media audio box




Reconnecting Bluetooth Device

Keep in mind that the Bluetooth Speaker has a 10 meter range in open field. If you move out of range or turn off the Bluetooth feature on your Bluetooth device, the Bluetooth Speaker will disconnect from your device. To reconnect, simply follow the instruction in the "Getting Connected" section.

Changing Connected Bluetooth Device

1. Disable the Bluetooth function of your Bluetooth device.
2. The Bluetooth Speaker can now be connected to the different Bluetooth device.
3. Following the instructions in the "Getting Connected" section

Play Audio from Non-Bluetooth Device



1. Connect the Bluetooth Speaker and your non-Bluetooth audio device via the 3.5 mm cable. The speaker is ready to play music.

Specifications

Model No.	BTS301
Output Power	3W
Flashlight Distance	20 meters
Input Voltage	DC 5V / 1A
Input	Wireless Bluetooth & 3.5mm wired auxiliary
Playback Time	Up to 6 hours on Bluetooth
Bluetooth Version	Bluetooth 2.1 with EDR
Operating Distance	Up to 33 feet (10 metres)
Dimensions	180 x D72 mm
Weight	371 grams

Troubleshooting

No connection between Bluetooth Speaker and your Bluetooth device.

- Make sure the Bluetooth Speaker is fully charged
- Make sure the BT mode is switched on.
- Make sure your Bluetooth device is available and supports Bluetooth Advance Audio Distribution profile.
- Make sure the Bluetooth Speaker is within range of your Bluetooth device.

Audio is not coming out from the Bluetooth Speaker after Bluetooth device successfully paired.

- Make sure the Bluetooth device volume is set to a comfortable listening level.

Audio is not coming out from the Bluetooth Speaker after the non-Bluetooth device connected with the aux in cable.

- Make sure the 3.5 mm is correctly and firmly connected to the Bluetooth Speaker and non-Bluetooth device.
- Make sure the non-Bluetooth device is set to a comfortable listening level.

Safety Information

Read all information and warning before the use of this product. Improper use of this product may lead to product damage. You (the buyer) other than the dealer will be held liable for such as overheat, toxic fume, fire or explosion.

- Do not attempt to charge the speaker by using any other method other than USB Power Adapter or computer.
- To reduce the risk of fire or electric shock, do not expose the speaker to rain or moisture while charging.
- The speaker should not be exposed to dripping or splashing, and objects filled with liquids, such as vases, should not be placed on or near it while being charged or charging other devices. As with any electronic products, use care not to spill liquids into any part of the product. Liquids can cause a failure and/or a fire hazard.
- Do not place any flame sources, such as lighted candles, on or near the speaker.
- Do not expose the speaker to excessive heat, including direct sunlight or fire or the like.
- Make no modifications to the product or accessories.
- If the battery begins to leak, do not allow the liquid to come in contact with your skin or eyes. If contact has been made, wash the affected area with plenty of water and seek medical attention immediately.
- Do not step on, throw, or drop the speaker, or expose it to a strong shock.
- Do not attempt to service the speaker yourself. Opening or removing covers may expose you to dangerous voltages or other hazards and will void the manufacturer's warranty. To prevent risk of fire or electric shock, avoid overloading wall outlets, extension cords, or integral convenience receptacles.

Precautions

1. The radio waves emitted by the Bluetooth Speaker and Bluetooth device can affect operation of nearby electronics including medical devices.
2. Keep the unit in a cool, dry place.

For more information, please visit www.yelltowin.com

Designed by Ye!! in Hong Kong
 Made in China



FCC NOTE:

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS OR CHANGE TO THIS EQUIPMENT. SUCH MODIFICATIONS OR CHANGE COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This

equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF exposure guidelines, this equipment should be installed and operated with a minimum distance of 20cm between the radiator and your body.