


**Bluetooth Portable Speaker**

**Package Contents**

- BTS700 Portable Bluetooth Speaker
- Micro USB to USB and 3.5 mm splitter cable
- User Manual

**Overview**




**LED Indicators**

	Indicator	Status
⚡	RED	Charging
	GREEN	Fully Charged
AUX/ BT	Flashing BLUE	Pairing Mode
	Solid BLUE	Connected / AUX IN Mode

**How to Charge BTS700**

1. Plug micro USB Tip from the included cable to the micro USB slot from BTS700.
2. Plug USB Tip from the included cable to USB compatible wall charger with 0.5A current output (DC 5V, 500mA).
3. When the BTS700 is fully charged, disconnect the USB Cable.

Note: Approximately 1-2 hours required for full charge. Battery will last up to 6 hours when connected wirelessly and up to 10 hours when connected through Line-in.



**Play Audio from Bluetooth Device**

1. Switch the Bluetooth Speaker to the BT mode. The speaker is discoverable and ready for pairing. The status indicator blinks blue.



2. On your Bluetooth device, turn on Bluetooth and scan for devices in its Bluetooth menu.
3. When the "Ye!!-BTS" appears on the device list of your Bluetooth device, select "Ye!!-BTS". (If a pass code is requested, enter 1234.) The status indicator turns solid blue after pairing is established. The speaker is ready to play music.

Example: iPad / iPhone / iPod Touch  
Press Settings > General > Bluetooth > Bluetooth ON > Ye!!-BTS > Enter PIN: 1234 > Pair



Example: Android 4.03 Ice Cream Sandwich Smartphone  
Press Settings > Bluetooth ON > Scan > Ye!!-BTS > Enter PIN: 1234 > Settings > Check the Media audio box



**Reconnecting Bluetooth Device**


Keep in mind that the Bluetooth Speaker has a 33 feet range in open field. If you move out of range or turn off the Bluetooth feature on your Bluetooth device, the Bluetooth Speaker will disconnect from your device. To reconnect, simply follow the instruction in the "Play Audio from Bluetooth Device" section.

**Changing Connected Bluetooth Device**

1. Disable the Bluetooth function of your Bluetooth device.
2. The Bluetooth Speaker can now be connected to the different Bluetooth device.
3. Following the instructions in the "Play Audio from Bluetooth Device" section

**Play Audio from Non-Bluetooth Device**

1. Switch the Bluetooth Speaker to the AUX IN mode. The status indicator turns solid blue.
2. Connect the Bluetooth Speaker and your non-Bluetooth audio device with the included Micro USB to USB and 3.5 mm splitter cable. The speaker is ready to play music.



**Specifications**

Model No.	BTS700 Ye!!-BTS
Output Power	3W
Power Capacity	1,000 mAh
Input Voltage	DC 5V / 1A
Charge Time	1 - 2 hours
Playback Time	Up to 6 hours on Bluetooth
	Up to 10 hours on Line-in
Operating Distance	up to 33 feet (10 metres)
Bluetooth Version	Bluetooth 3.0 with EDR
Dimensions	61 x 61 x 54 mm
Net Weight	133 g

**Troubleshooting**

No connection between Bluetooth Speaker and your Bluetooth device.

- Make sure the Bluetooth Speaker is fully charged
- Make sure the BT mode is switched on.
- Make sure your Bluetooth device is

available and supports Bluetooth Advance Audio Distribution profile.

- Make sure the Bluetooth Speaker is within range of your Bluetooth device.

Audio is not coming out from the Bluetooth Speaker after Bluetooth device successfully paired.

- Make sure the Bluetooth device volume is set to a comfortable listening level.

Audio is not coming out from the Bluetooth Speaker after the non-Bluetooth device connected with the Micro USB to USB and 3.5 mm splitter cable.

- Make sure the Micro USB to USB and 3.5 mm is correctly and firmly connected to the Bluetooth Speaker and non-Bluetooth device.
- Make sure the non-Bluetooth device is set to a comfortable listening level.
- Audio is coming out with abnormal noise and sound quality. Try to change up the battery of Bluetooth speaker.

**Precautions**

1. The radio waves emitted by the Bluetooth Speaker and Bluetooth device can affect operation of nearby electronics including medical devices.
2. Keep the unit in a cool, dry place.

For more information, please visit [www.yelltown.com](http://www.yelltown.com)

Designed by Ye!! in Hong Kong  
Assembled in China

**FCC NOTE :**

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS OR CHANGE TO THIS EQUIPMENT. SUCH MODIFICATIONS OR CHANGE COULD VOID AND CHANGE ANNTENA WHICH THE MANUFACTURER PROVIDES. IT IS THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF exposure guidelines, this equipment should be installed and operated with a minimum distance of 20cm between the radiator and your body.