

changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.



250 Real Drive Licensed RC Car

User Manual

Suitable Type: LC2598660/80/90



Thank you for purchasing our product --258 Real Drive Licensed RC Car. Please read the user manual carefully before using the product, and retain the information for future reference.


CAUTION

- Non-rechargeable batteries are not to be recharged;
- Rechargeable batteries are to be removed from the toy before being charged;
- Rechargeable batteries are only to be charged under adult supervision;
- Different types of batteries or new and used batteries are not to be mixed;
- Only batteries of the same or equivalent type as recommended are to be used;
- Batteries are to be inserted with the correct polarity;
- Exhausted batteries are to be removed from the toy;
- The supply terminals are not to be short-circuited;
- Do not mix old and new batteries;
- Do not mix alkaline batteries, standard (carbon-zinc) or rechargeable(Nickel-cadmium) batteries.

Functions And Specification

1. Full Function: Forward, backward, turn left, turn right, stop;
2. Frequencies: 27MHz, 40MHz, 49MHz;
3. Batteries: 4 X 'AA' batteries for racer and 2 X 'AA' for transmitter; (Battery not included)
4. Speed: Low speed at 9Kmh, TURBO at 11Kmh;
5. Operating range: No less than 30m.

Components



Install And Remove Batteries

1. Install batteries to transmitter:
 - a) Use a cross-screwdriver to unscrew screws on transmitter, open battery compartment cover, and insert two 'AA' batteries.
 - b) Reinsert battery compartment and screw down.
2. Install batteries to racer:
 - a) Turn the battery door knob at 180° and open battery door;
 - b) Insert four 'AA' batteries at correct polarities, close battery door and turn door knob to lock back.

Methods To Operate

1. Switch power button to ON and place R/C Racer on the ground.
 2. Push Forward/Backward Controlling Pole to L1/L2 for running/accelerating forward with front lights and engine accelerating sound on; push backward for running backward with rear lights on. Move Left/Right Controlling Pole for turning left/right. When Controlling Pole resumes, car roars with Neutral sound.
 3. To adjust the alignment of the car, twist adjuster tip on car bottom ("R" for right, "L" for left).
 4. When finish playing, switch to "OFF" position.
 5. Remove batteries from racer and transmitter, store separately.
-

To Consumers

1. When playing the car indoor, avoid damaging furniture or glass surface
2. To avoid accidents happen, please do not run the car in public. Only use this product in safe outdoor environment.
3. When handling while running the car outdoor, please stop immediately.
4. Do not run the car on puddles or sand to avoid circuit failure.
5. Do not fold the antenna incorrectly. Broken antenna may have sharp edges and cause injury.
6. Do not pull the wires from the car unit. Broken wire may result function failure.
7. When the car is revolving, do not put your hand close to it, nor put it on the hair or clothing to avoid injury.
8. Do not run the car toward others.
9. Should not drop or bump the car.
10. Store the car in cool places and away from fire.
11. This product is composed of complicated electronic devices and original parts, please do not attempt to disassemble or alter this product.
12. When batteries are low in power, the car speed will slow down or out of control. Please change the batteries.
13. When the car is out of control, it may be due to battery compartment spring distortion. Adjust spring to proper position according to diagram.
14. If the car is under pressure for a long time, the rear twist board may be deformed. Hold the rear rotor and bend it to the opposite direction until the board is flat again.
15. Do not shake the box vigorously to avoid drop out of controller.
16. To enable longer life of the batteries, please follow below operations:
 - * Remove batteries when not in use.
 - * Do not mix old and new batteries; otherwise, the car runs slowly and battery life will die very soon.

Frequency And Environment

1. When there is another car of similar radio frequency operating nearby, the controller may not function.
2. When interfered by other radio-waves, the controller may not function. Try again at other location or time.
3. This product is designed to run on cement and sand polished surface. If run on wax polished surface, the car cannot move straightly due to poor contact between the tires and road surface, and may spin 180 degree or pivot.

! WARNING!

CHOKING HAZARD-Toy contains small parts. Not for children under 3 years.

Guangdong Alpha Animation and Culture Co., Ltd

ADD: Auldey Industrial Area, Wenguan Rd., Chenghai, Guangdong, China

Http://www.auldey.com E-mail: auldey_lmd@auldey.cn

Tel: +86-754-5862278 Fax: +86-754-5870278

Zip code: 515800

Awarded Certificates of ISO9001:2000 & ISO14001:2004



Suitable for aged 8 years (97 months) above