



## LED Light Party Show Bluetooth Speaker System



**SLP-500CLR / SLP-500CLW / SLP-500CLB**

### **User Manual**

Copyright 2018 LINSAY. All right reserved.

[www.LINSAYdigital.com](http://www.LINSAYdigital.com)

### **FCC Class B:**

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

#### **NOTICE:**


1. The changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
2. Shielded interface cables and AC power cord, if any, must be used in order to comply with the Emission limits.

3. The manufacture is not responsible for any radio or TV interference caused by unauthorized modification to the equipment. It is the responsibilities of the user to correct such interference.





This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

#### **SAFETY PRECAUTIONS**

- Do not subject the device to severe impact or drop it from heights.
- Do not use the device in extreme hot or cold, dusty or damp conditions. Do not expose it to direct sunlight.
- Avoid using the device near strong magnetic fields.
- Normal functioning of the product may be disturbed by ESD. If so, simply reset and restart the device following the instruction manual. During file transmission, please handle with care and operate in a static-free environment.
- Keep the device away from water and other liquids. In the event that water or other liquids enter the device, power off the product immediately and clean the device.
- Do not use chemicals to clean the device in order to avoid corrosion. Clean it with a dry cloth.

- Do not install this equipment in a confined space such as a book case or similar unit. The ventilation should not be impeded by covering the ventilation openings with items such as newspaper, table-cloths, curtains etc.
- No naked flame sources, such as lighted candles, should be placed on the apparatus.
- Attention should be drawn to environmental aspects of battery disposal.
- Use the apparatus in moderate climates.
- We are not responsible for damage caused by malfunction, misuse, modification of the device or battery replacement.
- Do not attempt to disassemble, repair or modify the product. This will invalidate the warranty.
- If the device will not be used for an extended period of time, please charge the battery at least once per month to maintain battery life.
- Charge the battery if: a) The battery level icon displays  (An empty battery) b) The device powers off automatically when restarted. c) There is no response when pressing keys with keys unlocked and battery full.
- Please refer to the information on the bottom of the device for electrical and safety information before installing data or operating the device.
- To reduce the risk of fire or electric shock, do not expose this device to rain or moisture. The device should not be exposed to dripping or splashing. Never place objects filled with liquids, such as vases, on the device.
- There is danger of explosion if the battery is replaced incorrectly. Replace only with the same or equivalent type.

- The battery (battery or batteries or battery pack) should not be exposed to excessive heat such as sunlight, fire or the like.
- Please follow responsible procedures for battery disposal.
- If the power adaptor disconnected from the device, the device will remain operable as long as the battery has sufficient charge.
- The power adaptor is a CLASS II apparatus with double insulation, and no external ground is provided.
- Safety Symbol Explanation:

 <div style="border: 1px solid black; padding: 5px; text-align: center;"> <b>CAUTION</b>  <small>RISK OF ELECTRIC SHOCK DO NOT OPEN</small> </div> 	
	This symbol indicates: Danger of high voltage. Be careful of electric strike!
	This symbol indicates: Safety parts in the equipment. They cannot be replaced during repair job.

- -The lightning flash with arrowhead symbol within an equilateral triangle is intended to alert the user to the presence of non-insulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock.
- -To reduce the risk of electric shock, do not remove the cover (or back) as there are no user-serviceable parts inside. Refer servicing to qualified

personnel.

- -The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance instructions in the literature accompanying the device.



- -Correct Disposal of this product. This marking indicates that this product should not be disposed of with other household waste in the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To dispose of your used device, please use the return and collection systems available in your area or contact the retailer where the product was purchased. They can take this product for safe environmental recycling.

- This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.
- CE in which countries where the product may be used freely: Germany, UK, Italy, Spain, Belgium, Netherlands, Portugal, Greece, Ireland, Denmark, Luxembourg, Austria, Finland, Sweden, Norway and Iceland. In France, except the channel 10 through 13, law prohibits the use of other channels.

#### Cautions

- The LINSAY SLP-500CLR / SLP-500CLW and SLP-500CLB respect the current regulations for limiting the output volume of consumer audio devices to a safe level. Reduce the volume of your device to a reasonable level to avoid

permanent hearing damage. If you hear ringing in your ears, reduce the volume or shut off your device. In order to preserve your hearing, it is advised that you use only the following headphone models: the earphones supplied with your device, or any other headphones that respect the current regulations.

- Do not use while operating a motorized vehicle. It may create a traffic hazard and is illegal in many areas.
- You should use extreme caution or temporarily discontinue use in potentially hazardous situations created by obstructed hearing.
- Sound can be deceiving. Over time your hearing "comfort level" adapts to higher volumes of sound. What sounds "normal" can actually be loud and harmful to your hearing. Guard against this by setting the volume of your device at a safe level BEFORE your hearing adapts.
- To establish a safe volume level:
  - a. Start your volume control at a low setting.
  - b. Slowly increase the sound until you can hear it comfortably and clearly, and without distortion. Once you have established a comfortable sound level, leave it there.

*This manual may not reflect your actual device's operation. All information is subject to change without prior notification. Please follow your actual device's operational procedures*

**Dear Sir/Madam:**

Thanks you for purchasing LINSAY SLP-500CLR / SLP-500CLW and SLP-500CLB Bluetooth Speaker.

This product adopts high-capacity lithium battery, bass and noise reduction techniques, general Bluetooth audio module and A2DP for audio transmission to give you hi-fi music.

Also, it has built-in microphone to support hands-free talking and satisfy you with excellent user experience. Please read this manual carefully and completely before using the device. Please keep this manual for future reference.


#### **Safety Notes**

1. Please adjust the volume properly to avoid excessive output power, which may impair your hearing.
2. Please keep the device away from moisture, rain water, sand, heat source and any container with liquid.
3. Please clean this device with slightly wet cloth instead of alcohol or benzene containing solvent.

\*Please charge the speaker every three months if the speaker doesn't play for long time.



#### DESCRIPTION OF PARTS



- 1 Light Mode Switch
- 2 Skip Backward / Volume Decrease
- 3 Play / Pause / Hands Free Calling
- 4 Skip Forward / Volume Increase
- 5 ON/OFF/Mode Switch



- 6 Charging Port
- 7 LED Light Indicator
- 8 Micro SD (TF) Card Slot
- 9 Auxiliary Port
- 10 USB (Flash Drive) Slot

9

#### Charging the Speaker

The speaker has built-in rechargeable battery. When the battery is drained out, speaker would turn OFF automatically. Please recharge the battery every time it drains out.

Plug the Micro USB end of the included USB rechargeable cable into the charging port. Plug the other end into a USB port on your computer or other devices made for USB charging. Red LED Light illuminates indicating that the device is being charged.

It takes hours to fully charge the speaker. Once the speaker is fully charged LED Light would turn OFF.

#### Turning ON/OFF the Speaker

Before Turning ON the speaker, please ensure that it is fully charged.

To Turn ON the device – Long Press the ON/OFF switch to turn on the speaker. To Turn OFF the device – Long Press the ON/OFF switch to turn off the speaker.

#### Connect using Wireless Technology

Long Press the ON/OFF switch to open the power, you would hear an indication tone showing the device is turned on, and you will hear another indication tone, showing that you are now in Wireless Pairing Mode.

Activate the Bluetooth function on your source device (Mobile Phone, Tablet or other devices). Please refer to manufacturer's instructions for instructions on enabling Bluetooth wireless connection on your device.

10