



Manual

Table of Contents

<i>Troubleshooting</i>	5
Let your itablet acclimatise itself	5
Where to use your itablet	5
<i>Introduction</i>	6
Introducing your itablet	6
Unpacking your itablet.....	6
Getting to know your itablet	7
Front View.....	7
Right View.....	8
Left View.....	8
Back View	9
<i>Getting Started</i>	10
Setting up your itablet	11
Connecting your itablet to an external power source.....	11
Setting Up.....	11
Software Introduction	26
<i>Troubleshooting</i>	29
General hardware problems / Possible causes and solutions	30
Contacting your dealer	31
<i>Specifications</i>	32

Safety Notices

- ⌘ Please read these safety instructions carefully.
- ⌘ All precautions and warnings on the equipment should be carefully noted.
- ⌘ Please disconnect the computer from the AC outlet before cleaning.
- ⌘ Never pour any liquids into any openings or directly onto the computer unit. This could result in fire or electrical shock.
- ⌘ Ensure the voltage range of the power outlet is between 100V and 240V before connecting the computer unit. Exceeding the maximum rated voltage may cause damage to the AC adapter or to the computer. This could result in fire or electrical shock.
- ⌘ Always use the supplied AC adapter.
- ⌘ Do not leave this equipment in a non-temperature controlled environment; storage temperatures below 4°C (39°F) or above 35°C (95°F) may damage the unit. 9%The warranty will be voided if the itablet casing is opened.
- ⌘ Do not use your itablet near water.

! CAUTION To reduce the risk of an electric shock, which could cause personal injury, please follow all safety notices. The symbols shown are used in your documentation and on your equipment to indicate safety hazards.

! CAUTION Under no circumstances should the user attempt to disassemble the power supply. The power supply has no user-replaceable parts. Inside the power supply are hazardous voltages that can cause serious personal injury. A defective power supply must be returned to your dealer.

Notice of EMC Compliance

Federal Communications Commission Notice

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses, and can radiate radio frequency energy and if not installed and used in accordance with the instruction manual may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced technician for help.

Use only shielded I/O cables to connect I/O devices to this equipment.

Any changes or modifications not expressly approved by the manufacturer could void your authority to use the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device will not cause harmful interference, and (2) this device must accept any interference that may cause undesired operation.

This device and its antenna(s) must not be co-located or operating in conjunction with any other antenna or transmitter.

RF exposure

This equipment must be installed and operated in accordance with provided instructions and must

not be co-located or operating in conjunction with any other antenna or transmitter.

End-users and installers must be provide with antenna installation instructions and transmitter operating conditions for satisfying RF exposure compliance.
SAR Value: 0.308W/kg

BEFORE YOU START

This manual will help you get the most from your itablet. If you are a less experienced user, please read through the manual carefully before starting.

First Steps

Let your itablet acclimatise itself



NOTE: Do not power up your system immediately if it has been exposed to hot or cold conditions. Instead, allow the system to adjust gradually to room temperature over a three to four hour period.

Where to use your itablet

Your itablet will run well under most conditions but avoid extreme temperatures and humidity levels

- Allow sufficient air circulation around the computer when you are working indoors to prevent overheating
- Do not block the ventilation opening or place your itablet in direct sunlight
- There are some things you can tolerate that your itablet can't – things like static electricity, dust, water, steam and oil.
-



NOTE: Before you start your itablet please insure that the battery is fully charged.

INTRODUCTION

Introducing Your itablet

Your itablet features the latest advances in portable computing technology with a modular design that provides maximum expandability without compromising portability.

 **WARNING** Never try to disassemble or reverse engineer the computer as we will not be responsible for any damage caused if you do so and your warranty will voided

Unpacking your itablet


Your itablet comes securely packaged in a shipping carton. Please contact your dealer if you find that anything is missing or damaged after examining the contents.

Please do not throw the packaging materials away. You may need them later if you have to ship the computer.

 **NOTE:** Some of the features mentioned in this manual might not be included on your itablet or may vary slightly.

Getting to Know Your Computer

Front View




1. CMOS Camera 2MP

This is the built-in camera which can be used for video conferencing applications or just taking pictures.

2. Power LED Indicator

This lights up when the device is powered on.

Right View




1. 3in1 Card reader

SD, MS, MMS card reader (please note that convertors may be required)

2.External HDMI Port

The HDMI port is for connecting an external TV, monitor or projector

Left View



1.DC IN Connector

Plug the AC adapter into this connector.

2.Stereo Headphone

The stereo headphone jack (3.5-mm diameter) is where you connect the headphones or external speakers

3.USB Ports

The Universal Serial Bus (USB2.0-compliant) ports allow you to connect a wide variety of devices to your itablet at rates of up to 480 Mbps. These ports conform to the latest USB2.0 plug-and-play standards

Back View



1.Power button

Press to turn on your itablet

2.Sound volume button

Press to control sound volume.

3.Home page button

Press to return previous page.

GETTING STARTED

Setting Up Your itablet

- Remove your itablet from its package.
- Connect your itablet to an external power source and charge the battery.
- Press the power on button.

Connecting Your itablet To An External Power Source

- Plug the AC adapter cable into the AC power connector on the computer.
- Plug one end of the power cord into an electrical outlet and the other end into the AC adapter.

 **WARNING:** To prevent damage to your itablet, please do not use inferior extension cables. An AC adapter comes with your itablet. Never use a different kind of adapter to power the computer or other electrical devices.


Whenever possible, keep the AC adapter plugged into the computer and an electrical outlet to recharge the battery.

 **WARNING:** Don't try to turn off your itablet while the hard disk is in use as it may result in the loss or destruction of your data.

Setting Up

[Power on]

On connecting the power adapter for the first time, the calibration application will run.




When your itablet has fully booted up the welcome page will be displayed.



[Setting Wifi]

Unlock




To set up wireless and networks select "Settings "




Select "Wireless & networks "



Select "Wi-Fi settings "




Select "Wi-Fi " to turn on Wi-Fi. Your itablet will scan all available access points before connecting to an available access point.




On connecting, the following display will be seen.




[Setting Bluetooth]



Select “Bluetooth” and your itabket will scan all available devices before making a connection.



On connection, the following display will be seen.




[Setting Sound & Display]


Select "Settings"



Select "Sound & display"



In Display settings, you can adjust the brightness of the screen or adjust the delay before the screen automatically turns off




[Setting Date & Time]

Select "Settings"



Select "Date & time"




Disable the “Automatic” setting to manually set date, time zone and time



[Media player]
Select "Gallery"



In the picture below, the arrow depicts video files whilst the others are all still image files



To play a video file, select Movies/Camera or Movies/Gallery



When viewing pictures, you can use the arrows to view next / previous image or plus / minus to zoom-in or zoom-out




[Music player]


Select "Music"



Select "Songs" to show all audio files



Select an audio file to play



As the below picture.



: List all audio files



: Shuffle mode



: Repeat mode



: Previous / Back




: Play / Pause



: Next / Forward

Software Introduction



Alarm Clock : Alarm Clock



AnCal : Calendar



Browser : Browser



Calculator : Calculator



Calibration : Calibration



Camcorder : Camcorder



Camera : Camera



Dev Tools : Android Development Tools



Email : E-mail



ES File Explorer : ES File Explorer



Forecast info : Weather Forecast info



Gallery : Gallery(Media Player)



Gallery : Media Player



Music : Music Player



Settings : Settings



Sound Recorder : Sound Recorder



Spare Parts : Android Spare Parts



Threegnetwork : Threegnetwork (3G)

TROUBLESHOOTING

This chapter describes how to locate and solve problems that you may experience when using your itablet.

General Hardware Problems / Possible Causes and Solutions

A freeze on the system during program operation

- In the event of an error with the Android OS, reboot your itablet. Turn off using the power switch, wait 3 seconds then turn it back on again.

System Not Resuming Operation

If your itablet will not display and resume normal operation, check the following possible causes:

- The battery may be defective or discharged to a critically low level. To correct this problem, connect the AC adapter to the nearest power supply.

The system can not shutdown properly

Press and hold the power button for 4~6 seconds until the system shutdown manually.

How to extend battery life

- Adjust the display brightness to minimum level.
- Adjust the volume to minimum level.
- Disconnect all PC card not often used.

The wireless LAN connection disconnects after 2~3 minutes and does not reconnect.

This may be caused by channel interference or poor signal strength. Try changing the access point channel and reconnect or move the tablet nearer your wireless access point.

The computer is unable to connect to the Internet.

- Check that your account with your Internet service provider (ISP) is properly configured. Ask your ISP for further assistance.
- Check that your wireless is enabled.

The signal strength is excellent but you cannot connect to the network.

- Check the TCP/IP properties are configured properly. When you connect to an access point, click the Wireless Network Connection icon on the taskbar and select the Support tab,
- Check your Wireless security access key is correct.

Contacting Your Dealer

If you still have a problem after reading the preceding section, your next step is to contact your dealer who will be able to determine if the itablet needs to be returned to the shop. Before you call your dealer, please have the following information available:

- How is your itablet configured?
- What peripheral devices you are using.
- What messages, if any, are on the screen?
- What software were you running at the time?
- itablet serial number?
- Place and date of purchase?
- What have you done already to try to solve the problem? If you have overlooked a step, your dealer may be able to solve the problem over the phone.

SPECIFICATIONS

Photo		
CPU	Platform	Freescall IMX51 ARM Cortex A8 CPU 800MHz
	Cooling Method	Heat Sink
Memory	Memory	512MB DDR2 SDRAM
	Maximum	2G DDR2 SDRAM
Mass Storage	Storage	1GB NAND Flash
	Card Reader	Micro-SD Card up to 16GB.
	CF card slot	NA
Video	Display Controller	LCD single touch panel controller
	LCD Display	10.1" 1024X600 Glare type panel, LED backlight
	External Display	HDMI
	Camera	Camera 2M(Built-in)
Audio	Audio Features	Built in stereo speakers
		Built-in analogue microphone
		Stereo headphones (3.5mm)

Other I/O Devices	Communication	802.11 b/g/n WiFi
		Bluetooth
		3G (option)
		GPS(option)
	Keyboard	NA
	Sensors	Ambient light sensor
I/O Ports	External connectors	DC-in Jack
		3.5mm stereo headphone socket
		USB 2.0 Ports x 2
Power System	AC/DC Adapter	AC 110~220Volt, (5V DC) output Color : Black
	Battery Pack	6400m AH
	Power Management	yes
	Dimension	283.5x163x14
	Weight	1.0kg
OS		Android