





The gang's all here

Use iPhone to plan a night out

It's easy to keep everyone in the loop when you use your iPhone to plan a night out. From tossing around ideas, to finding a restaurant, to arranging transportation, iPhone has you covered.





Make a plan

Start a group conversation in Messages and begin brainstorming potential activities. When you have a couple contenders, take a poll to decide. Tap , then swipe left to reach the Poll option

Reserve a table

In Maps, pinch open to zoom in on the area you want to search. Tap the search field, tap Food, then tap Restaurants.

After reading up on a few spots, choose one and tap Reservations. If you don't see a reservation option, just tap  to give them a call.






Call your ride

When it's almost time to go, choose your destination in Maps. Tap Directions, tap Ride, then request a ride through an app.

Running late?

Share your location with your friends so they know you're on your way. In a Messages conversation, tap ⓘ, then tap Send My Current Location.



Want to learn more about what you can do in Messages or Maps? Start with [Find places](#) in Maps, or [Messages at a glance](#).



Be well

Create habits that support your health and well-being

Move more, sleep better, or schedule some uninterrupted time. Use iPhone to support your goals for a healthier body and mind.




Steps count

Carry iPhone with you to track how far you walk or run each day. To check your progress, open the Health app, then tap Activity. To see how many steps you've traveled over time, tap Steps, then tap Week, Month, or Year.


Sleep better

Use Bedtime in the Clock app to help you build healthy sleep habits by consistently going to bed and waking at the same time. Tap Bedtime, then follow the onscreen instructions.





Unplug

Enjoy a family dinner, write in your journal, or just sit quietly without interruptions from alerts or notifications. Swipe up from the bottom of the screen to open Control Center, then turn on Do Not Disturb . To schedule daily quiet time, go to Settings > Do Not Disturb.

Want to learn more about using iPhone to support your health and well-being? Start with [Your health at a glance](#).

Welcome

[Set up and get started](#)

[What's new in iOS 10](#)

[Basics](#)

[Personalize your iPhone](#)

[Apps](#)

[Sharing](#)

[iPhone and other devices](#)

[Privacy and security](#)

[Restart, update, reset, and restore](#)

[Accessibility](#)


[Safety, handling, and support](#)

Set up and get started

A quick look at iPhone

iPhone overview

This guide describes iOS 10 for:



COMMENT: ##The image will be updated.

2016 IPHONE



COMMENT: ##Placeholder image.

| | Feature |
|---|-----------------------------|
| A | Volume buttons |
| B | Ring/Silent switch |
| C | Status bar |
| D | FaceTime camera |
| E | Receiver/front microphone |
| F | Sleep/Wake button |
| G | SIM card tray |
| H | iSight camera |
| I | Rear microphone |
| J | True Tone Flash |
| K | Lightning connector |
| L | Speaker |
| M | Home button/Touch ID sensor |
| N | Bottom microphone |
| O | Headset jack |

2016 IPHONE PLUS



COMMENT: ##Placeholder image.

Feature

- A Volume buttons
- B Ring/Silent switch
- C Status bar
- D FaceTime camera
- E Receiver/front microphone
- F Sleep/Wake button
- G SIM card tray
- H iSight camera
- I Rear microphone
- J True Tone Flash
- K Lightning connector
- L Speaker
- M Home button/Touch ID sensor
- N Bottom microphone
- O Headset jack

iPhone SE



| | Feature |
|---|-----------------------------|
| A | Volume buttons |
| B | Ring/Silent switch. |
| C | Status bar |
| D | FaceTime camera |
| E | Receiver/front microphone. |
| F | Sleep/Wake button |
| G | SIM card tray |
| H | iSight camera |
| I | Rear microphone |
| J | True Tone Flash |
| K | Lightning connector |
| L | Speaker |
| M | Home button/Touch ID sensor |
| N | Headset jack |


Your features and apps may vary depending on the model of iPhone you have, and on your location, language, and carrier. To learn which features are available on your iPhone, see the [Compare iPhone models](#) website. To find out which features are supported in your area, see [iOS 10 Feature Availability](#).

Note: Apps and services that send or receive data over a cellular network may incur additional fees. Contact your carrier for information about your iPhone service plan and fees.


Sleep/Wake button

Use the Sleep/Wake button to turn on or wake iPhone, lock it, or turn it off. Locking iPhone puts the display to sleep, saves the battery, and prevents anything from happening if you touch the screen. You can still listen to music and adjust the volume using the buttons on the side of iPhone, and you can receive phone calls and FaceTime calls, text messages, alarms, notifications, and other updates.

On 2016 IPHONE, 2016 IPHONE PLUS, iPhone 6s, iPhone 6s Plus, iPhone 6, and iPhone 6 Plus, the Sleep/Wake button is on the right side:



On iPhone SE and iPhone 5s and earlier, the Sleep/Wake button is on the top edge:



iPhone locks automatically if you don't touch the screen for a minute or so. To adjust the timing, go to Settings > Display & Brightness > Auto-Lock.

Turn on iPhone. Press and hold the Sleep/Wake button until the Apple logo appears.

Turn off iPhone. Press and hold the Sleep/Wake button until the slider appears, then drag the slider.

Wake iPhone. On iPhone 5s and later, lift iPhone or press the Sleep/Wake button to see the Lock screen. To turn Raise to Wake on or off, go to Settings > Display & Brightness. On iPhone 5, press either the Sleep/Wake or Home button.

From the Lock screen you can check notifications and recent app activity, take photos and more. For more information, see [Lock screen](#).

Unlock iPhone. On iPhone 5s and later, wake iPhone, then press the Home button. On iPhone 5, wake iPhone, press the Home button, then enter the passcode if required.

Set a passcode. For additional security, you can [require a passcode](#) to unlock iPhone. If you didn't create a passcode during setup, go to Settings > Touch ID & Passcode (iPhone 5s and later) or Settings > Passcode (other models).

Home button

The Home button takes you to the Home screen, where you can tap an app to open it. The Home button also provides other convenient shortcuts.



Go to the Home screen. Press the Home button.

Choose the right click for you. On 2016 IPHONE and 2016 IPHONE PLUS, go to Settings > General > Home Button, then choose a click.

See apps you've opened. Double-click the Home button when iPhone is unlocked to show the app switcher, then swipe left or right. See [Switch between apps](#).

Use Siri or Voice Control. Press and hold the Home button. See [Make requests](#) and [Voice Control](#).


On iPhone 5s and later, you can use the sensor in the Home button to unlock iPhone or make purchases in the iTunes Store, App Store, and iBooks Store (instead of using your passcode or Apple ID password). With iPhone SE, iPhone 6, iPhone 6 Plus, or later, you can also use the Touch ID sensor when using Apple Pay (in countries where Apple Pay is supported) to make a purchase. [Touch ID About Apple Pay](#)

You can also use the Home button to turn accessibility features on or off. See [Accessibility Shortcut](#).

Volume controls

When you're on the phone or listening to songs, movies, or other media, the buttons on the side of iPhone adjust the audio volume. Otherwise, the buttons control the volume for the ringer, alerts, and other sound effects. You can also use Siri to turn the volume up or down. Just say "Turn up the volume" or "Turn down the volume."

WARNING: For information about avoiding hearing loss, see [Important safety information](#).



Lock the ringer and alert volumes. Go to Settings > Sounds & Haptics (called Sounds on devices without 3D Touch), then turn off Change with Buttons. To limit the volume for music and videos, go to Settings > Music > Volume Limit.

Note: To limit the maximum headset volume, go to Settings > Music > Volume Limit. To prevent changes to the volume limit, go to Settings > General > Restrictions > Volume Limit.

Use Control Center to adjust the volume. When iPhone is locked or when you're using another app, swipe up from the bottom edge of the screen to open Control Center, swipe left, then adjust the volume.

You can also use either volume button to [take a picture or record a video](#).


Lightning connector

Connect your Lightning to USB Cable to the Lightning connector to charge or sync your iPhone. For more information about charging, see [Charge and monitor the battery](#). For more information about syncing, see [Sync with iTunes](#).

On 2016 IPHONE and 2016 IPHONE PLUS, you use the Lightning port with EarPods or adaptor with other headphones to listen to audio.

Ring/Silent switch


Flip the Ring/Silent switch to put iPhone in ring mode  or silent mode .



In ring mode, iPhone plays all sounds. In silent mode, iPhone doesn't ring or play alerts and other sound effects (but iPhone may still vibrate).

Important: Clock alarms, audio apps such as Music, and many games play sounds through the built-in speaker, even when iPhone is in silent mode. In some areas, the sound effects for Camera and Voice Memos are played, even if the Ring/Silent switch is set to silent.

For information about changing sound and vibration settings, see [Sounds and silence](#).

Use Do Not Disturb. You can silence calls, alerts, and notifications using [Do Not Disturb](#). Swipe up from the bottom edge of the screen to open Control Center, then tap .


SIM card

If you were given a SIM card to install, install it before setting up iPhone.

Important: A Nano-SIM card is required to use cellular services when connecting to GSM networks and some CDMA networks. iPhone that's been activated on a CDMA wireless network may also use a SIM card for connecting to a GSM network, primarily for international roaming. Your iPhone is subject to your wireless service provider's policies, which may include restrictions on switching service providers and roaming, even after conclusion of any required minimum service contract. Contact your wireless service provider for more details. Availability of cellular capabilities depends on the wireless network.

Eject the SIM card tray. Insert a paper clip or the SIM eject tool into the small hole of the SIM card tray on the right side of iPhone, then press firmly to eject and remove the tray. Place the SIM card in the tray—the angled corner determines the correct orientation—then insert the SIM card tray back into iPhone.

Set a SIM PIN. To protect your SIM card from others using it for phone calls or cellular data, you can use a SIM PIN. To create one, go to Settings > Phone.



Status icons

The icons in the status bar at the top of the screen give information about iPhone:

Status icon





Cell signal








What it means

You're in range of the cellular network and can make and receive calls. If there's no signal, "No service" appears.



Airplane mode


| | | |
|---|------------------|---|
| | | Airplane mode is on—you can't make phone calls, and other wireless functions may be disabled. See Travel with iPhone . |
| LTE | LTE | Your carrier's LTE network is available, and iPhone can connect to the Internet over that network. (iPhone 5 and later. Not available in all areas.) See Cellular data settings . |
| 4G | UMTS | Your carrier's 4G UMTS (GSM) or LTE network (depending on the carrier) is available, and iPhone can connect to the Internet over that network. (Not available in all areas.) See Cellular data settings . |
| 3G | UMTS/EV-DO | Your carrier's 3G UMTS (GSM) or EV-DO (CDMA) network is available, and iPhone can connect to the Internet over that network. See Cellular data settings . |
| E | EDGE | Your carrier's EDGE (GSM) network is available, and iPhone can connect to the Internet over that network. See Cellular data settings . |
| GPRS | GPRS/1xRTT | Your carrier's GPRS (GSM) or 1xRTT (CDMA) network is available, and iPhone can connect to the Internet over that network. See Cellular data settings . |
| Wi-Fi | Wi-Fi call | iPhone is set up for Wi-Fi calling. iPhone also displays a carrier name next to the icon. See Make a call . |
|  | Wi-Fi | iPhone is connected to the Internet over a Wi-Fi network. See Connect to Wi-Fi . |
|  | Do Not Disturb | Do Not Disturb is turned on. See Do Not Disturb . |
|  | Personal Hotspot | iPhone is providing a Personal Hotspot for another device. See Personal Hotspot . |
|  | Syncing | iPhone is syncing with iTunes. See Sync with iTunes . |
|  | Network activity | Shows that there's network activity. Some third-party apps may also use it to show an active process. |
|  | Call Forwarding | Call Forwarding is set up. See Call forwarding, call waiting, and caller ID . |
|  | VPN | You're connected to a network using VPN. See VPN settings . |

| | | |
|---|----------------------------------|--|
|  | TTY | iPhone is set to work with a TTY machine. See Support for TTY hardware . |
|  | Portrait orientation lock | The iPhone screen is locked in portrait orientation. See Change the screen orientation . |
|  | Alarm | An alarm is set. See Alarms and timers . |
|  | Location Services | An item is using Location Services. See Privacy . |
|  | Bluetooth® | <p><i>Blue or white icon:</i> Bluetooth is on and paired with a device.</p> <p><i>Gray icon:</i> Bluetooth is on. If iPhone is paired with a device, the device may be out of range or turned off.</p> <p><i>No icon:</i> Bluetooth is turned off.</p> <p>See Bluetooth devices.</p> |
|  | Bluetooth battery | Shows the battery level of a paired Bluetooth device. |
|  | Battery | <p><i>Gray icon:</i> Shows the iPhone battery level or charging status. See Charge and monitor the battery.</p> <p><i>Yellow icon:</i> Low Power Mode is on. See Low Power Mode.</p> |
| Water resistance icon [TK] | Water resistant [TK] | Description [TK] |

iPhone accessories

The following accessories are included with iPhone:

Apple headset. Use EarPods (2016 IPHONE and 2016 IPHONE PLUS) or EarPods with 3.5mm Headphone Plug (earlier iPhone models) to listen to music and videos, and make phone calls. See [Use your Apple headset](#).




COMMENT:##Will add image of adaptor for 2016 IPHONE.


Use adaptor to connect headphones that have a 3.5mm headphone plug.

COMMENT:##Will add image of adaptor for 2016 IPHONE.

Connecting cable. Use the Lightning to USB Cable to connect iPhone to your computer to sync and charge.



Apple USB power adapter. Use with the Lightning to USB Cable to charge the iPhone battery.




SIM eject tool. Use to eject the SIM card tray. (Not included in all areas.) See [Sim Card](#).



Gestures

A few simple gestures—tap, drag, swipe, and pinch—are all you need to use iPhone and its apps.





3D Touch

3D Touch gives you an additional way to interact with iPhone. On supported devices, you can press the display to see previews, access useful shortcuts, and more.

3D Touch is supported on:

- 2016 IPHONE
- 2016 IPHONE PLUS
- iPhone 6s
- iPhone 6s Plus

For example, in Mail, press a message in the mailbox list for a peek at the message contents, then slide up to see a list of actions. Or press a little deeper to pop the message open. In Photos, press an image to peek at it, then swipe up to share or copy it; press a little deeper to pop the image to full screen. Press a notification on the Lock screen to respond to it. In this document, look for other examples of 3D Touch, which are marked with .



DRAFT