

ASNII-100 User's Manual

Aramo Smart Navigator SKIN DIAGNOSIS SYSEM



FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference. and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Caution

Any changes or modifications (including the antenna) made to this device that are not expressly approved by the manufacturer may void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.


This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- —Reorient or relocate the receiving antenna.
- —Increase the separation between the equipment and receiver.
- —Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- —Consult the dealer or an experienced radio/TV technician for help.

Content

- 1. How to use
- 2. How to operate
 - System setting
 - Wireless & network setting
- 3. How to diagnosis
 - Full mode
 - View mode
- 4. How to set
- 5. Additional information
 - Standard & Features
 - Troubleshooting Guide & FAQ
 - CAUTION UPON INSTALL & USE

System and components





Number	Function	Number	Function
1	Moisture/Elasticity sensor	8	SD memory card slot
2	LED light & Lens	9	On / Off
3	Touch screen	10	No function
4	Go to "Setup"	11)	Volume on MP3
(5)	Capture button	12	Volume on MP3
6	Go to "Back"	13	Capture button
7	External Adaptor connection	14	Battery cover











Manual

2 Batteries

Charger

USB cable

Cleaning cloth







Cradle



Leather case


Touch pen

Sebum paper (100 paper)

Hand strip


Battery uses

Open the cover.



Close the cover.








How to charge

By Battery charger

Charge the unit after connecting the cable.



By Cradle

Plug the charger into the cradle and connect the device to the cradle.



Available to re-charge the spare bat tery on back side of cradle.

Note

* Available to check the charging status on system main page




Use the touch screen

The touch screen lets you select items or perform function. Learn basic actions to use touch screen.

- Tap: Touch once with your finger to select or launch the menu option, or application
- Drag: Tap and drag your finger up, down, left, or right to move to items on lists.
- Tap and hold: Tap an item and hold it for more than 2 seconds to open pop-up option list
- Double-tap: Tap twice quickly with your finger to zoom in or out while viewing photos.

Enter text

Enter text by selecting characters on the virtual keypads



No.	Function	
1	Shortcuts for frequent use	
2	Capitals lock key	
3	Switch between ABC and Number(symbol) mode	
4	Space	
5	Delete	
6	Start new line	

Icons to operate in Manual

Icons	To do	
	Touch to take images from the device	
	Go to capturing page	
ОК	ОК	
Cancel	Go back to previous page	
USE	Use the image taken for diagnosis	
Analysis	Analyze the image	
3D	3D Image	
	Go back to previous page on skin image	
Mode	Change the lighting mode	

^{*} Touch the ">" or fling the screen to go to next page.

^{*} Tap the screen to focus.

Turn on / off & System main page



- On/Off button: Press and hold for 3 seconds
- "Sleep" mode on / off : Press the button






Turning on...

Turning off...











Icons	To do	Icons	To do
	Diagnosis application	(0:	Alarm
	Gallery (album)	0	Add alarm
8	MP3		Internet
\Diamond	System setting		





>> Application setting






Check the "√" mark.

The setting have to be a ctivated to download ap plication.

» Brightness setting








Adjust the Brightness to display the application more effectively.

>> Language setting

Keyboard language


















Changed the keyboard language

>> Language setting

How to change the keyboard language




Press and hold the "space-bar" to show the language selection




Drag left or right to choose the language

How to change the System language









Select the language you want to use

>> Date & Time setting

How to set date








Enter the current date


How to set time zone & time







Select user's time zone or city name








Enter the current time

>> Wi-Fi connection

















Check the Wi-Fi mark



On System main page




Find and connect the available Wi-Fi

>> Bluetooth Pairing

How to pair the diagnosis system with the host device

Note


* Host device : all kinds of PC including tablet PC you want to send the diagnosed result or the related images.




Check the name of host device

Activate the Bluetooth function on host device for the diagnosis system to search and pair with host device.

← Example image








Select the host device



On host device

Accept the paring request sent from diagnosis system. Password: 0 (number)





•••••• Check the pairing status

* 🔋 5:14

How to set the system

» Bluetooth Pairing

How to change the name of diagnosis system













Enter the device name what you want








Tap "setup".

» Language



Select the language


≫ Option





- * Show measurement page before starting diagnosis.
 - Green: activate status
 - Gray: deactivate status

>> Measurement



Green : activate → Analyze

··> Gray : deactivate → Do not analyze

* Show the diagnosed result by number on the capture page.

Select what you want to diagnose








Tap "setup".

» Language



Select the language


≫ Option





- * Show measurement page before starting diagnosis.
 - Green: activate status
 - Gray: deactivate status

>> Measurement



Green : activate → Analyze

··> Gray : deactivate → Do not analyze

* Show the diagnosed result by number on the capture page.

Select what you want to diagnose


Diagnosis Process >> How to setup

>> Advance

≫ Network




Check the version of application



Set Wireless connection; Wi-Fi or Bluetooth

>> Email



Register the sender's email account

>> Start diagnosis






Note

- * Gray : deactivate status
- * Black : activate status





Enter age group and gender of customer

>> Hydration & Elasticity

Place the sensor onto your skin and tap













- * Do NOT move during the measurement.
- * "Please, rescan..." : To measure again by taping



Sebum (T & U zone)

Put the below sebum tape (pink area) onto the U or T-zone of your face for 3 seconds.



→ How to hold the sebum paper

T - ZONE







How to put the sebum paper on **T-zone**

U - ZONE







How to put the sebum paper on **U-zone**

≫ Sebum (T & U zone)








Tap Analysis

Tap each image to magnify





Tap to go back to "Sebum-U/T" page.

- * Touch the ">" or fling the screen to go to next page.
- * Tap the screen to focus.
- * Take the image without any white blank.












≫ Pore



- * Touch the ">" or fling the screen to go to next page.
- * Tap the screen to focus.

>> Melanin








Tap. (Analysis)

>> Sensitivity









Tap. Analysis

>> Wrinkle








Wrinkle

Choose the area by moving the white box

Tap. (Analysis)


- * Touch the ">" or fling the screen to go to next page.
- * Tap the screen to focus.

» Wrinkle



3D image





- * Touch the ">" or fling the screen to go to next page.
- * Tap the screen to focus.

» Analysis result



Note

* Product recommendation : to be updated


≫ Send







Enter the customer's email address.





Recognized as a Removabl e disk on PC





Note

* Bluetooth : to be updated

Diagnosis Process >> View mode

» NL mode (for Wrinkle)









Choose the area by moving the white box







3D image

» PL mode (for Melanin)

Tap Mode to change the lighting mode.








- Note
- * Touch the ">" or fling the screen to go to next page.
- * Tap the screen to focus.

Diagnosis Process >> View mode

>> UV mode (for Acne)

Tap Mode to change the lighting mode.



- * Touch the ">" or fling the screen to go to next page.
- * Tap the screen to focus.

How to update the application


Note * Check the Wi-Fi connection before updating























How to remove the application























1

How to re-install the application after removing






http://www.google.co... Web ge not available The Web page at http://www.google.com/ m?client=ms-androidgoogle&source-android-home might be temporarily down or it may have moved permanently to a new web address. Here are some suggestions: · Check to make sure your device has





View a cached copy of the web page from Google


Drag down 90%

Enter the address below and download the application www.aramhuvis.com/data/asn2/smartnavi.apk









Standard & Features

Section	ltem	Contents
Optical/Camera	Camera	5M pixel CMOS
Sensor		X30,X60 TPL
	AF	VCM
	Sensor	Hydration
	Light	Normal, Polarize, UV-[3CH]
НW	CPU	S5PV210 ARM-CORTEX A8 [1GHz]
	Memory	DDR2 SDRAM (512MB) / NAND FLASH (512MB)
	SD Memory	T-Flash (Micro SD)
	LCD	2.2Inch TFT LCD QVGA (240*320)
	Touch	R-TOUCH
	Wi-Fi	Wireless 802.11b/g/n (Wi-Fi Direct Avail)
	Bluetooth	BT ver3.0+HS
	Audio	AC97 , Codec (WM1800)
	SPEAKER	Max 1.0 W, Internal Speaker
	USB	USB 2.0 HOST/DEVICE
	Battery	Li-ion (1150mAh)
	Adaptor	AC Adaptor DC 5V / 2000mA
	Key Pad	Power , 4-direction navi Key ,Left , Right
	Microphone	Internal MIC
	Storage	Micro SD ver2.0 (2GB)
	Weight	127g (with battery)
	Dimension (mm)	57(W) x 116(H) x 18 (D)
SW	Bootloader	u-boot-1.3.2
	OS	Android Gingerbread 2.3
	Media	MPEG4(SP/ASP)/H.263(Profile3)/H.264(BP/MP/HP)
	Applications	Google app.
	Debugging Port	USB Client/UART

Troubleshooting Guide & FAQ

I cannot turn on the device.

• Connect and charge the device (or the battery) using the adaptor provided the supplier. (The battery charging indicator will be shown on the system main page.)

I cannot power on the device even the battery is still full.

• The battery might be dislocated on the device. Please separate the battery from the de vice and put it on, and then power on again.

The battery is not charging very well.

- Separate the battery from the device and put it on again.
- Check the connection among a device, a battery, and a charger.
- A battery cannot be charged if there is an alien substance on the charging port. In this case, please use the device after cleaning the charging port of the device or check whe ther the sticker is attached on charging port.

The using time of the battery is different from the manual.

- The battery using time will be shorten if you put the charged battery in a low or high t emperature.
- The battery using time vary in service type, using environment, using period of the batt erv.
- The battery is consumed without using the device, and the battery using time will be s horten if you use additional functions of the device.

The device turns on but the diagnosis doesn't work.

Check the smart card is correctly inserted (SD card slot on the button of the device).

There are dust on the device.

• Clean the dust by using a smooth fabric. Do not use benzene, alcohol, and a synthetic d etergent.

The screen is frozen and the keys not working when using the device.

Separate the battery from the device and put it on again.
 If the device is still not working, please contact to the customer service center.

A "force close" message appears on the screen.

• The repetition of commands can trigger a bug. Sometimes there may be a brief delay before the command is completed. Do not repeat/multiply the tasks as the device will no longer be able to follow them.

Troubleshooting & FAQ

I cannot connect to Wi-Fi.

- Check the connection status on setting page.
- Try to connect to another Wi-Fi.
- - Bluetooth : Check the pairing status and try to re-pair the device with host device.

I cannot connect to Blue-tooth.

- Make sure to use the Bluetooth hosting devices that have Bluetooth certified with the logo. You may need an external Bluetooth dongle for those devices that do not have Bluetooth feature.
- Bring the device to closer with the Bluetooth hosting device.
- Try to re-pair the device with host device.
- The password of pairing is "0"(number).

The touchscreen doesn't react to my finger commands.

- Before using for the first time remove the protective plastic film.
- Use the stylus-pen provided from supplier.

The screen was turned off.

• The device has a power save function that turns the screen OFF after 1 minute. Press the on/off button to turn on the screen.

I can see the black screen only during measurement.

• Check the LED light inside lens on the head part when you try to measurement. If you cannot see the light, please connect the customer service center.

The image is not clear.

• Tap the screen while capturing to focus.

I cannot update the diagnosis application.

Check the network connection, the update process can be done after connect to Wi-Fi.

CAUTION UPON INSTALL & USE

Thanks for using the product of Aram HUVIS Co., Ltd.. The product undergoes strict quality management and inspection process before production and introduction to market. Product defect or trouble during warranty period is entitled to free repair.

Model	Serial No.	
Date of Purchase	Customer Name	
Place of Purchase	Contact Information	

Please, fill out warranty and keep it with receipt to enjoy better service in the future.

▶ Warranty Period

14 MONTHS from the products arrival.

▶ Service Free of Charge

Service is provided free of charge only if product defect occurs within 1 year from the date of purchase (within Warranty Period).

	Service		
Case	Within Warranty Period	After Warranty Period	
Functional or operational defect which occurs under normal condition of use within 10 days after purchase	Product replacement		
Functional or operational defect which occurs under normal condition of use within 14 year after purchase	Free of charge		
Defect which results from the mistreatment by the user	Partial free repair Or Repair with charge	Repair with charge	

► Repair with Charge

* Cases except for product defect

If service is requested due to the reasons except for defect, service fee may be charged.

- Defect resulting from the mistreatment by the user
- Defect resulting from the lack of caution (leakage or shock) or unauthorized repair or remodeling
- Defect due to natural disasters such as fire, earthquake or flood

CAUTION UPON INSTALL & USE

1. Humidity

Do not install the product in the place with rain leakage or of high humidity. If the product is leaking, it may cause damage or fire.

2. Repair

Do not disassemble or remodel the product because it may cause danger such as an electric shock. When a problem occurs, do not attempt to repair it. Instead, contact the seller.

3. Electricity

Do not use electricity except for what is prescribed here. Using improper electricity may cause an electric shock or danger.

4. Installation Environment

Do not install the product in a too hot or cold place. (Recommended Temperature : 15°C ~ 35°C)

5. Sunlight

Do not expose the camera of the product to the sun or a direct ray of light. It may cause product damage

6. Shock or Vibration

Do not drop the product or give it a strong shock or vibration.

7. If the product does not work properly

If a problem occurs while using the product (unidentified noise, smell or smoke), stop using it and turn the power off and contact the seller.

8. Dirt on Lens

Make sure that keep camera lenses clean and away from pollution. If it polluted by finger print or external dirt, cleanse it with cotton stick socked with 70% Ethyl Alcohol solution or use air blower to remove the dust. Those products are available at camera shop.

9. For After-Service

When any of the following occurs, turn the power off and have the product repaired at the place of purchase.

- i. Power Connector is damaged
- ii. The product is leaking
- iii. Liquid is spilt over the product or it has alien substance.
- iv. Product does not work as indicated in this manual.

 (Attempting to operate the product against manual may cause more serious damage.)
- v. Product is dropped to the floor and seriously damaged.



World leader of skin & hair diagnosis system Aram HUVIS Co.,Ltd.