## **User Interface**

The ATH-BT03 Stereo headset contains the following devices as user interface:

- 2 color LED (Red, Blue) to indicate different status of ATH-BT03 Stereo headset
- 8 buttons for software defined functions
- 1 reset button to reset ATH-BT03 Stereo Headset in case the headset is in abnormal condition
- 1 mini-USB connector for battery charge
- 1. Turning on or off the headset
  - 1) To turn on the headset, press and hold the Power button until indicator light flashes blue.
  - 2) To turn off the headset, press and hold the Power button for more than 3 seconds.
  - The indicator light flashes red several times and then the headset is powered off.
- 2. Paring the headset
- \* You must pair the headset with a Bluetooth mobile phone or other Bluetooth device to use before you can connect it to them.
- \* When pairing the headset, it is recommended to keep the interval in less than 1 meter between two devices.
  - 1) In the power-off condition, press and hold the Pair button for 4 seconds.
  - \* The indicator light blinks blue and red alternately.
  - 2) Select the Bluetooth menu on the Bluetooth device you use.
  - 3) Select <Stereo Headset> on that device to use and choose < ATH-BT03 > in the search result.
  - \* For more information, refer to the device's user manual.
  - 4) If the PIN code input window appears, enter <0000>.
  - \* Pairing is completed and connection between Bluetooth device and headset will be automatically made.

#### Notes

- \* You only need to pair it once.
- \* Check the PIN code of a Bluetooth universal adapter if you use it to connect this headset to other device.

  If the PIN code is other than <0000>, the connection will not be made.
- \* Bluetooth connection may not be automatically made to some Bluetooth devices, depending on the device.

  If this happens, refer to 'Connecting the Headset' for help.
- 3. Using Call Functions
  - 1) Answering a call
    - Press the MFB button when you receive an incoming call.
  - 2) Ending a call
    - Press the MFB button during a call.
  - 3) Rejecting a call
    - Press and hold the MFB button for more than 3 seconds when you receive an incoming call.
  - 4) Dialing a recent call
    - Press and hold the MFB button for more than 3 seconds. The most recent call number will be dialed.
  - 6) Transferring a call
    - If you want to switch a call from your mobile phone to the headset, or the headset to your mobile phone, press and hold the MFB button for 3 seconds during a call.
    - \* There may be a malfunction of the headset depending on the mobile phone model you use.

#### 4. Listening to Music

- 1) Play a music file on the connected Bluetooth device.
- Pressing the Play/Pause button on the headset may play the music automatically needless to manipulate the connected Bluetooth device.
- 2) Button operation
  - Pause : Press the Play/Pause button during music playback.
  - Stop : Press the Play/Pause button for 1 second.
  - Vol. control: Use the Volume control button to adjust the volume. You can adjust the volume level from 1 to 16.
  - Previous/Next track : Press the Previous/Next track button.
  - SRS Effect: Press the Power button to turn SRS effect Mode 1 and Mode 2.
- 5. Making Phone Conversations While Listening to Music.
  - 1) Answering a call while listening to music.
    - Press the MFB button when you hear a ring from the headset.
    - \* The music stops and you can make conversations.
  - 2) Ending a call
    - Press the MFB button during a call.

## 6. Charging Operation

- 1) Plug USB cable into the charging jack on the headset.
- 2) Headset will be reset automatically by hardware pin.
- 3) Red LED solid on during charging state.
- 4) Red LED turned off after full charging.

#### 7. Battery Operation

- 1) Headset enters low battery state on 3.5V battery
- 2) Headset indicates low battery state by LED, beep
- 3) Headset will be turned off automatically on 3.2V battery

# 8. DFU Operation

- 1) Plug UART data cable into the charging jack on the headset.
- 2) Press and hold Reset and Power buttons at once for 3 seconds
- 3) Headset will be changed to DFU mode with blinking blue LED.
- 4) CSR DFU wizard tool can make firmware upgrade.