

AUDIO TECHNICA MODEL ATW-7000

UHF WIRELESS MICROPHONE SYSTEM

USER INFORMATION.

INTRODUCTION

Thank you for purchasing the ATW-7000 series wireless microphone system. It is our hope that the system will bring you years of trouble free pleasure and performance. Please follow the information contained in this manual closely as it will assist you in using your equipment effectively.

PART 1. REGULATORY REQUIREMENTS.

FCC PART 15 COMPLIANCE STATEMENT

CANADA RSS-210 COMPLIANCE STATEMENT

" This device complies with Part 15 of the FCC rules. Operation is subject to the condition that this device does not cause harmful interference."

" This device complies with INDUSTRY CANADA R.S.S. 210, en conformite avec IC: RSS-210/CNR210. Operation is subject to the following conditions: (1) This device may not cause harmful interference and (2) this device must accept any interference received, including interference which may cause undesired operation. "

Please note that your ATW-7000 system operates in a frequency band and in a way which may make its use subject to certain FCC and other regulatory agency restrictions and licensing requirements. For further information, please contact your local office of the FCC as applicable.

PART 2. USING THE ATW-T75 BELTPACK TRANSMITTER

The beltack transmitter operates on a 9V battery. Please make sure that your batteries are fresh. We recommend that you use Alkaline batteries and that you avoid using NiCad if possible.

Insert the batteries into the battery compartment and slide the battery compartment back into place.

Open the rubber cover over the channels selector switch and set the group and channel to the corresponding channel as set on the receiver. Replace the cover over the rotary switches.

Connect your microphone or guitar cable to the connector on the top side of the transmitter.

Turn the transmitter switch to the on position. Confirm that the receiver is receiving RF and that audio is passing through the receiver.

You are now set to use the system.

PART 3. USING THE ATW-T76 HANDHELD TRANSMITTER

The handheld transmitter operates on one 9V battery. Please make sure that your batteries are fresh. We recommend that you use Alkaline batteries and that you avoid using NiCad if possible.

Insert the batteries into the battery compartment and gently screw the battery cover back into place.

To change the channel of operation, unscrew the battery compartment cover and pull the cover back. Locate the channel selector rotary switches. Set the group and channel to the corresponding channel as set on the receiver. Replace the cover over the rotary switches.

Turn the transmitter switch to the on position. Confirm that the receiver is receiving RF. Speak directly into the microphone and confirm that audio is passing through the receiver.

You are now set to use the system.

PART 4. USING THE ATW-R73 RECEIVER

The ATW-R73 diversity receiver operates on a 110-120 VAC. Plug the unit into an AC outlet. Push the on off switch. Confirm that the LED read out comes on. Check the group and channel setting to confirm that they correspond to the settings of the transmitter.

Connect the balanced or unbalanced audio output to your mixer or PA system. Adjust the volume setting to the desired level. Speak into the microphone and listen to the audio out at the speaker. If satisfied with the audio quality, you can use the system.