

## Sensor Communication

**Wireless Communication** – Place the sensor on the PAD in area marked by lines

## Launching MaxiTPMS PAD Software




### MaxiTPMS PAD

Click on **All Programs** from Windows Start Menu, locate and click on to start the program. If you haven't already, connect your PAD to your PC.



## Software Operation

Select the vehicle manufacturer from the **Car Brand** menu. Then select the model and year from the menu list that follow that click.



You will now be ready to do one of these three operations:

- 1. Test Sensor** - Click the **Test Sensor** button. Place the OE sensor on the PAD. Click **TEST** to activate the sensor.
- 2. Copy Sensor** - Click the **Copy Sensor** button. Place the OE sensor on the PAD. Click **TEST** to activate and retrieve the sensor data, after this is successfully done, place the Autel MX-Sensor on the PAD. Click **PROGRAM** to write in the retrieved original sensor data to the MX-Sensor.
- 3. Create Sensor** - Click **Generate ID** to create a sensor ID compatible with the selected vehicle. Place the MX-Sensor on the PAD. Click **PROGRAM** to write in the generated sensor ID to the MX-sensor and activate it.

**AUTEL**<sup>®</sup>

# MaxiTPMS PAD

TPMS SENSOR PROGRAMMING ACCESSORY DEVICE



## Quick Start Guide

**Autel MaxiTPMS Support: [www.auteltech.com](http://www.auteltech.com)**

Tel: 86-755-86147779 Email: [sales@auteltech.com](mailto:sales@auteltech.com)

## What comes with this kit

- MaxiTPMS Programming Accessory Device (PAD)
- USB Cable
- Quick Start Guide
- CD with PC Software

## Installing the PC Software

Insert the CD comes with this kit into the CD drive. In most cases the software will launch automatically for installation and all you need to do is to follow the instructions on the PC screen. If the software does not launch automatically, follow these steps:

1. From the Start menu, click on **My Computer**.
2. Locate the Removable Storage drive displays as **MaxiTPMS PAD**.
3. Double click it to launch the auto install process.

The MaxiTPMS PAD program will launch automatically once successfully installed. The start screen will prompt you to connect the PAD to the PC.

## Minimum Computer Requirements

- Laptop or PC with 100 MB of free disc space
- Windows XP, Vista or Version 7
- Available USB Port
- CD Drive

## Connecting the PAD

Connect the PAD to the PC using the supplied USB cable. The MaxiTPMS PAD program will always prompt you to connect the PAD before letting you start the process.



Connect Type A plug to the PC.



Connect Type B plug to the PAD.

## Indications of the Working Status

**Power-on** - Illuminates solid green light

**Successful read or program** - Illuminates green light with quick beeps

**Failed read or program** - Illuminates red light with a long beep



**FCC Caution:**

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment .

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

**IC Warning:**

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence.

L'exploitation est autorisée aux deux conditions suivantes:

- (1) l'appareil ne doit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le

brouillage est susceptible d'en compromettre le fonctionnement.

Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by Industry Canada. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication.

Conformément à la réglementation d'Industrie Canada, le présent émetteur radio peut fonctionner avec une antenne d'un type et d'un gain maximal (ou inférieur) approuvé pour l'émetteur par Industrie Canada.

Dans le but de réduire les risques de brouillage radioélectrique à l'intention des autres utilisateurs, il faut choisir le type d'antenne et son gain de sorte que la puissance isotrope rayonnée équivalente (p.i.r.e.) ne dépasse pas l'intensité nécessaire à l'établissement d'une communication satisfaisante.

This device complies with RSS-310 of Industry Canada. Operation is subject to the condition that this device does not cause harmful interference.

Ce dispositif est conforme à RSS-310 d'industrie Canada. L'opération est sujette à la condition que ce dispositif ne cause pas l'interférence nocive.