


Installation and operating instructions for UX24A Transmitter and UX25A Receiver, both included in the UX2400 Set.

1. Insert two AAA alkaline batteries in the UX24A transmitter, and place it in the room where you want to use your remote control (up to 20 feet away from where you normally sit). Make sure the front of the unit is facing you.
2. Plug the UX25A receiver's power supply jack into the back of the UX25A and plug the power supply into an AC wall outlet in the room where your TV, VCR, stereo, etc., that you want to control is located
3. Plug the IR extender cable into the back of the UX25A.
4. Attach the IR emitters on the cable to the front of up to two A/V devices that you want to control.



5. Point your remote control at the UX24A Powermid Transmitter and press any button. The Powermid Transmitter receives the Infrared (IR) signals from your remote and converts them to Radio Frequency (RF) codes. It sends these codes (even through walls and ceilings) to the UX25A Powermid Receiver which converts the codes back to IR codes to control your TV, VCR, etc.

Note: The Transmitter and Receiver can be in different rooms, up to 100 feet away from each other. You can add more Transmitters to use your remotes in more than one room. Add more Receivers to control A/V equipment in more than one room.

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRE OPERATION.

This equipment generates and uses radio frequency energy, and if not installed and used properly, that is, in strict accordance with the manufacturers instructions, it may cause interference to radio and television reception. It has been type tested and found to comply with the limits for remote control devices in accordance with the specifications in Sub-Parts B and C of Part 15 of FCC Rules, which are designed to provide reasonable protection against such interference in a residential installation. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause interference to radio or television reception, which can be determined by unplugging the equipment, try to correct the interference by one or more of the following measures.

- Reorient the antenna of the radio/TV experiencing the interference.
- Relocate the equipment with respect to the radio/TV.
- Move the equipment away from the radio/TV.
- Plug the equipment into an outlet on a different electrical circuit from the radio/TV experiencing the interference.
- If necessary, consult your local Dealer for additional suggestions.

NOTE: Modifications to this product will void the user's authority to operate this equipment.

X10 Wireless Technology, Inc. LIMITED 1-YEAR WARRANTY

X10.com, a division of X10 Wireless Technology, Inc. (X10) warrants X10 products to be free from defective material and workmanship for a period of one (1) year from the original date of purchase at retail. X10 agrees to repair or replace, at it's sole discretion, a defective X10 product if returned to X10 within the warranty period and with proof of purchase.

If service is required under this warranty:

1. Call 1-800-675-3044 or visit www.x10.com, or e-mail sales@x10.com to obtain a Return Merchandise Authorization (RMA) number.
2. Return the defective unit postage prepaid to X10 (see address on back).
3. Enclose a check for \$4.00 to cover postage and handling.
4. Enclose a dated proof of purchase.
5. X10 is not responsible for shipping damage. Units to be returned should be packed carefully.

Please visit www.x10.com/warranty

to complete your on-line warranty registration. Thank you.

For help or more information on setup, please visit: www.x10.com/support