

Phone layout

The phone has ASARI A24 keypad keys, and a charger/headset port.

| | |
|------------------|-------------------|
| 1.Earpiece | 2.Display |
| 3.Left key | 4.Center / OK key |
| 5.Rewind | 6.Play/Pause |
| 7.Fast Forward | 8.Navigation Keys |
| 9.Center key | 10.Right Key |
| 11.End/Power Ker | 12.Camera |
| 13.Flash Light | 14.Back Cover |
| 15.Speaker | |



Basic operation

1、 Switch On/Off the Phone

To turn on/off the phone, press and hold the End/Power key.

If you have enabled the SIM Lock function then enter the PIN code (the 4 to 8 digits secret code of your SIM card). It is preconfigured and provided to you by your network operator or retailer. If you enter an incorrect PIN code 3 times in succession, your SIM card will be locked. To unlock it, you must obtain a code from your network operator.

2、 To Make Calls

If the icon  appears on the screen, then you can make or receive calls.

- Input the phone number (should affix the international/national/regional code or district code if necessary) and then press the dial/call key to make a call.
- Press call key to make a call and select the desired SIM.
- You can select a contact number from the phonebook and call the contact person.
- In talk state, press up key and down key to Adjust volume

Tip: The signal strength may influence the quality of connection.

3、 To Dial International Number

The phone supports dialing the international emergency phone number, such as 112 and 911. With the phone, you can dial an emergency call in any country or region under the normal situation regardless of SIM card inserted when the phone is located within the coverage of the GSM/WCDMA network. Input the emergency phone number and press **Call Key** to dial.

The phone will select the main network automatically after powered on if it is located within the coverage of the main network. The phone can use other network, called as roaming, if the phone is not located within the coverage of the main network when the network operator protocol permits.

You can dial or answer a call when the symbol of the network operator appears on the screen.

4、 Answer/Reject an Incoming Call

- Press **Call Key** to receive the incoming call. You can use the earphone to answer the call when the generic earphone or Bluetooth earphone is inserted in the phone.
- Press **End Key** to reject an incoming call.

5、 Options During a Call


Press <Menu> to use the following functions during the call:

- **End single call:** end the current call.
- **Add new Call:** call the opposite party to build a Call to Many.
- **Hold:** temporarily hold the current call.
- **Start recording:** record the current call.
- **Mute:** mute in the current call.
- **Adjust volume:** adjust the volume.
- **Contacts:** enter in the phonebook menu.
- **Call logs:** enter in the call history.
- **Message:** enter in the SMS menu.


Frequently Asked Questions

1. How to install and charge the phone


1. Open the battery cover




2. Insert the SIM card




3. Insert the Memory card



4. Install the battery



5. Plug the travel adapter into the phone



2. How to Lock/Unlock keypad

To lock: In IDLE, press left key and then * key to lock keypad.

To unlock: Press the Left key and then press the * key.

3. How to activate Silent mode

In standby mode, long press “#” to set vibrate mode

4. How to enable Data access

From main menu, select settings/Connectivity, then choose GPRS service, and choose on. The data service is default open.

5. How to activate Phone Lock

Please go into main menu, select Settings/Security/Phone locked. You will be asked for a password, Please default passcode as 0000, the phone is now locked. When you turn it on, you will be asked for the password. To deactivate, repeat the process.

6. How to use FM radio

Please plug in earphone, from main menu, enter the Multimedia to choose the FM radio to listen to the radio. Press [OK key] to turn on/off FM radio, select Options/Auto search and save to open the automatic search function, press left/right navigation key to select last channel or next channel, , and you can adjust the volume by down navigation key and up navigation key.

8. How to add a Bluetooth device and through the Bluetooth pass file.

When you power on the Bluetooth, you can choose 'Add new device' to search new device, you can see some devices in the list, choose any one, and press left soft key to Pair, enter the Passcode matched, and allow this device to connect automatically, So you are successful match to a Bluetooth device. At that time you can choose any file via Bluetooth send to you have paired Bluetooth device.

9. How to read e-books.

E-book can support file of TXT format. You can copy TXT file to [E-book] folder on the T-FLASH card by PC. In standby mode, enter the function menu, then select [E-book].

Randomly select a book in the bookshelf to read; slide to turn pages.

10. How to use calendar

Enter the Menu, Press [options] to set the followings:

Add new schedule: Write the schedule details.

View schedules: Select the date on the calendar, and check the events on special date.

All schedules: View all schedules.

Delete today's tasks: Delete task.

Clear all: Clear all schedules.

Go to date: Jump to today.

Weekly: View calendar by weekly.

Daily: View calendar by daily.

11. How to use alarm

In the alarm interface, you can press [OK] key to edit the alarm. In edit mode, press [Center key] to set the followings: Message, Time, Ringtone and Repeat mode to save the alarm.

12. How to use STK

Enter the Menu and select [SIM Claro].

Entering the STK sub-menu, you can use the value added service offered by network operator.

This mobile supports STK function but this service is offered by network operator. If your SIM card and network operator don't support this service then you cannot use it. Please contact your network operator for more information.

| | | |
|-------------------------------|-----------|-----------------------------|
| Corriente eléctrica encendido | 220mA | |
| Corriente eléctrica pantalla | 39mA | |
| Voltaje Pantalla | 3.8-4.2V | |
| Corriente eléctrica Llamada | 130-260mA | |
| Voltaje Llamada | 3.8-4.2V | |
| Voltaje celular apagado | 3.55V | |
| Voltaje de teléfono | 3.7-4.2V | |
| Cargador | Entrada | 100-240Vca , 50/60HZ , 0.1A |
| | Salida | 5.0Vcc , 500mA |

Precautions for users

Before using your Azumi handset, it is important that all users read the following recommendations:

- Do not get your Azumi phone wet
- Use only Azumi parts
- Do not open the housing of the phone, this voids the warranty.
- If the phone or any accessory is not working properly, take it to a qualified service center.
- Using the stereo headphones or earphones for a long time (at high volume), it can cause serious damage to your hearing.
- Do not use the phone while it is charging.
- In extreme heat or cold: Avoid temperatures below -10 ° C / 14 ° F or above 40 ° C / 104 ° F.

Note: Remember to visit our website www.azumi-mobile.com and our Facebook page www.facebook.com/AzumiMobile if you have questions. Our Team is always available to answer your queries.

FCC Statement

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference.

(2) This device must accept any interference received, including interference that may cause undesired operation.

2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

SAR Information Statement

Your wireless phone is a radio transmitter and receiver. It is designed and manufactured not to exceed the emission limits for exposure to radiofrequency (RF) energy set by the Federal Communications Commission of the U.S. Government. These limits are part of comprehensive guidelines and establish permitted levels of RF energy for the general population. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons, regardless of age and health. The exposure standard for wireless mobile phones employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit set by the FCC is [1.6 W/kg](#). * Tests for SAR are conducted with the phone transmitting at its highest certified power level in all tested frequency bands. Although the SAR is determined at the highest certified power level, the actual SAR level of the phone while operating can be well below the maximum value. This is because the phone is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are to a wireless base station antenna, the lower the power output. Before a phone model is available for sale to the public, it must be tested and certified to the FCC that it does not exceed the limit established by the government adopted

requirement for safe exposure. The tests are performed in positions and locations (e.g., at the ear and worn on the body) as required by the FCC for each model. The highest SAR value for this model phone when tested for use at the ear is [0.722W/Kg](#) and when worn on the body, as described in this user guide, is [1.194W/Kg](#)(Body-worn measurements differ among phone models, depending upon available accessories and FCC requirements). While there may be differences between the SAR levels of various phones and at various positions, they all meet the government requirement for safe exposure. The FCC has granted an Equipment Authorization for this model phone with all reported SAR levels evaluated as in compliance with the FCC RFexposure guidelines. SAR information on this model phone is on file with the FCC and can be found under the Display Grant section of <http://www.fcc.gov/oet/fccid> after searching on

[FCC ID: QRP-AZUMIASARIA24](#) Additional information on Specific Absorption Rates (SAR) can be found on the Cellular Telecommunications Industry Association (CTIA) web-site at <http://www.wow-com.com>. * In the United States and Canada, the SAR limit for mobile phones used by the public is 1.6 watts/kg (W/kg) averaged over one gram of tissue. The standard incorporates a substantial margin of safety to give additional protection for the public and to account for any variations in measurements.

Body-worn Operation

This device was tested for typical body-worn operations. To comply with RF exposure requirements, a minimum separation distance of [10mm](#) must be maintained between the user's body and the handset, including the antenna. Third-party belt-clips, holsters, and similar accessories used by this device should not contain any metallic components. Body-worn accessories that do not meet these requirements may not comply with RF exposure requirements and should be avoided. Use only the supplied or an approved antenna