

# **Hero JR**

## **User Manual**

# Content

<b>1</b>	<b>Getting started.....</b>	<b>5</b>
1.1	Installing the SIM Cards and the Battery .....	5
1.2	Charging the Battery .....	5
1.3	Linking to the Network.....	6
<b>2</b>	<b>Input method .....</b>	<b>6</b>
2.1	To Shift Entry Methods.....	6
2.2	Numeric and English Input .....	6
2.3	Inserting a Symbol .....	6
<b>3</b>	<b>Using the Menus.....</b>	<b>7</b>
3.1	Messaging .....	7
3.2	Dialer .....	7
3.3	Media player .....	7
3.4	Phonebook.....	7
3.5	Call logs .....	8
3.6	Image viewer.....	8
3.7	Settings.....	8
3.8	Profiles .....	10

3.9	Camcorder.....	10
3.10	File manager.....	10
3.11	Alarm .....	11
3.12	Connectivity .....	11
3.13	Tasks .....	11
3.14	FM Radio .....	11
3.15	Calendar .....	11
3.16	Ebook reader .....	11
3.17	Calculator.....	11
3.18	Bluetooth.....	11
3.19	Web .....	12
3.20	Sound recorder.....	12
3.21	Notes .....	12
3.22	STK Service .....	12

## Phone Specifications



Dimensions (W×D×H): 117.5\*62.5\*11.4mm

Camera: 1.3 M pixel

Cable: Mini USB

Lithium battery

Rated capacity: 3.7V 1050mAh

Continuous standby duration: (Relates to network status) 290 hours

Continuous conversation duration: (Relates to network status) 610 min

Please refer to their labels for other data related to the battery and the charger.

# 1 Getting started

## 1.1 Installing the SIM Cards and the Battery

A SIM card carries useful information, including your mobile phone number, PIN (Personal Identification Number), PUK (PIN Unlocking Key), IMSI (International Mobile Subscriber Identity), network information, contacts data, and short messages data.

## 1.2 Charging the Battery

The lithium battery delivered with the mobile phone can be put into use immediately after being unpacked. Your mobile phone can monitor and display the battery state.

- ◆ Normally the remaining energy of the battery is indicated by the battery level icon at the upper right corner of the display screen.
- ◆ When the battery energy is insufficient, the mobile phone prompts "Battery low". If you have set an alert tone, an alert tone will be given off when the battery level is too low.
- ◆ A charging animation appears when the battery is being charged. When the charging is complete, the animation disappears.
- ◆ It is normal of the battery to become hot during the charging period.
- ◆ The battery icon does no longer flicker when the charging process ends.
- ◆ Use only the battery provided by the vendor. Otherwise, damages or even injuries could be caused during the charging.
- ◆ Power off the mobile phone before removing the battery.
- ◆ The charging process lasts a longer time for a new battery or a battery not in use for long. If the battery voltage is too low to enable the mobile phone to be powered on, charge the battery for a longer time.
- ◆ During the charging, ensure the battery is placed in a room temperature environment or in an

environment close to room temperature.

Immediately stop using the battery if the battery produces odor, overheats, cracks, distorts or has other damage, or if the electrolyte leaks.

- ◆ The battery wears out with use. A longer charging time is required as the battery is put into use for a long time.


### **1.3 Linking to the Network**

After the SIM card and the mobile phone are successfully unlocked, the mobile phone automatically searches for an available network.

## **2 Input method**

This mobile phone provides multiple input methods, including English input in both upper and lower case, Portuguese and numeric input method.


### **2.1 To Shift Entry Methods**

In any mode, tap the icon  to switch between input methods. When writing text message/multimedia message, you can tap “Option” to choose the input method as well.

### **2.2 Numeric and English Input**

You can input numbers with the numeric input method. Tap a number key to input the corresponding number.

### **2.3 Inserting a Symbol**

Tap the icon  to enter the **Select symbol** interface and select a symbol you want. When writing text message/multimedia message, you can tap “Option” to choose “Insert symbol” as well.

## **3 Using the Menus**

### **3.1 Messaging**

If the short message memory is full, a blinking message icon appears on the top of the screen. While you enter the messaging interface, you can have the corresponding operation as follows:

- Write message: you can write Text/Multimedia message here.
- Inbox: The message(s) received is saved.
- Drafts: The message(s) not being sent out is saved.
- Outbox: The message(s) failed to be sent out that is saved.
- Sent Messages: The message(s) being sent out is saved.
- Broadcast messages: Cell broadcast is a kind of information service such as weather report, traffic etc that the network operator sends to the GSM users within certain area.
- Message Settings: you can set the corresponding parameters about Text message, Multimedia message and Service message.

### **3.2 Dialer**

In the interface, input a complete number to make a call, or enter your Phonebook to pick up a contact to make a call.

### **3.3 Media player**

You can use it to play music and video. It might be not sufficient space for you to store music in Phone, you'd better insert a micro SD card for your choice.

### **3.4 Phonebook**

The mobile phone can store up to 300 telephone numbers.

### 3.5 Call logs

#### ◆ Missed Calls / Dialed Calls/ Received Calls

You can view a list of the above.

#### ■ Advanced settings

Through this function, you can view Call timers and GPRS counter.

### 3.6 Image viewer

You can view the photos you captured and pictures you stored.

### 3.7 Settings

#### Dual SIM settings

You have four modes for your choice.

- ◆ Dual SIM open
- ◆ Only SIM 1 open
- ◆ Only SIM 2 open

#### Phone Settings

- ◆ **Time and date:** set the date format, the time format, and detail time of the location.
- ◆ **Schedule power on/off:** Set the time when the mobile phone will be automatically powered on or off.
- ◆ **Language:** Select the display language for the mobile phone.
- ◆ **International keyboards:** Choose multi-language or one language.
- ◆ **Widget order**
- ◆ **Shortcut manager:** You can add three functions as shortcuts.
- ◆ **Display:** Users can access this item to set wallpaper and Screen auto lock.

- ◆ **Flight mode:** when this function is engaged, it will suspend many of the device's signal transmitting functions – thereby disabling the device's capacity to place or receive calls or text messages– while still permitting use of other functions that do not require signal transmission (e.g., games, built-in camera, MP3 player.)
- ◆ **Misc. settings:** Set brightness and time of LCD backlight.

## Network Settings

After successfully unlock the SIM card and phone, the phone will automatically search for an available network. After finding a network, the phone went into standby. When the phone is registered on the network, the network operator name is displayed on the screen. Then you can dial or receive calls.

## Security Settings

This function provides you with related settings about safety use

### SIM1/SIM 2 Security

- ◆ **PIN lock:** To set the SIM lock, you need to input the PIN. You can set the SIM lock only after inputting the correct PIN. If you set SIM1 lock to On, you need to input the PIN each time you power on the mobile phone. In the case you input a wrong PIN for three consecutive times, you need to input the PIN Unblocking Key (PUK). The PUK is used to unlock and change the locked PIN. To obtain the PUK, contact the network operator.

**Change PIN/PIN 2:** If you need to change the PIN code, please get your original PIN code and then change it. For more information, please contact the network operator.

### Phone security

- ◆ **Phone lock:** The function enables you to lock/unlock the phone. Entering password to switch on or off the phone. Password is required when the phone is locked. The password is 4 to 8 digits.

◆ **Change password:** The default password is 1122.

### **Notification settings**

It allows you to manage the information on the notification bar.

### **Call settings**

Call ID/Call waiting/ Call divert/ Call barring/Line switching.

You can browse a list of above.

◆ **Advanced settings:** Through this function, you can set auto redial, Call time display, Call time reminder, Reject by SMS, Connect notice and Answer mode.

### **Restore Settings**

Use this function to restore factory settings. Note: The initial phone lock code is 1122.

## **3.8 Profiles**

The mobile phone provides multiple user profiles, **General, Meeting, Outdoor, Silent** and **My style**.

When you insert an earpiece to the mobile phone, the mobile phone automatically enters the Headset mode, and incoming calls will be automatically answered. There is no option for activating the Headset mode on the screen.

## **3.9 Camcorder**

Use this function to capture pictures and shoot videos.

## **3.10 File manager**

The phone provides a certain space for users to manage files and supports the T-Flash card. You can use the file manager to conveniently manage various directories and files on the phone and the T-Flash card.

### **3.11 Alarm**

Five alarm clocks are set but deactivated by default.. For each alarm clock, the ringing date and the ringing time can be set.

### **3.12 Connectivity**

Data account: you can add data account. It depends on your SIM network operation.

### **3.13 Tasks**

Add a new task, what you need do is to fill in Subject, Priority, Due time, Alarm etc.

### **3.14 FM Radio**

The device gives you a convenient to listen to radio. Before using the function, please plug in earphone.

### **3.15 Calendar**

You can view the calendar.

### **3.16 Ebook reader**

The device supports ebooks in TXT format.

### **3.17 Calculator**

This phone contains a mini calculator. You can have a simplified calculation.

### **3.18 Bluetooth**

You can use Bluetooth to transfer data and files after you pair your device with other device.

### **3.19 Web**

This function enables you to view the internet. Your phone will ask you with existed way. You can start to view only by starting corresponding way.

### **3.20 Sound recorder**

This function enables you to record the sound and other audios.

### **3.21 Notes**

You can make some quick notes to remind you of the importance data and meetings etc.

### **3.22 STK Service**

STK service is the tool kit of SIM card. This phone supports the service function .The specific items are depended by SIM card and network.

**FCC Regulations:**

This mobile phone complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This mobile phone has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiated radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**FCC Note:**

Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

## **RF Exposure Information (SAR)**

This phone is designed and manufactured not to exceed the emission limits for exposure to radio frequency (RF) energy set by the Federal Communications Commission of the United States.

During SAR testing, this device was set to transmit at its highest certified power level in all tested frequency bands, and placed in positions that simulate RF exposure in usage against the head with no separation, and near the body with the separation of 15 mm. Although the SAR is determined at the highest certified power level, the actual SAR level of the device while operating can be well below the maximum value. This is because the phone is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are to a wireless base station antenna, the lower the power output.

The exposure standard for wireless devices employing a unit of measurement is known as the Specific Absorption Rate, or SAR. The SAR limit set by the FCC is 1.6W/kg.

This device is complied with SAR for general population /uncontrolled exposure limits in ANSI/IEEE C95.1-1992 and had been tested in accordance with the measurement methods and procedures specified in IEEE1528. This device has been tested and meets the FCC RF exposure guidelines when tested with the device directly contacted to the body.

The FCC has granted an Equipment Authorization for this model phone with all reported SAR levels evaluated as in compliance with the FCC RF exposure guidelines. SAR information on this model phone is on file with the FCC and can be found under the Display Grant section of [www.fcc.gov/oet/ea/fccid](http://www.fcc.gov/oet/ea/fccid) after searching on FCC ID: YHLBLUHEROJR.

For this device, the highest reported SAR value for usage against the head is 0.61 W/kg, for usage near the body is 0.63 W/kg.

While there may be differences between the SAR levels of various phones and at various positions, they all meet the government requirements.

SAR compliance for body-worn operation is based on a separation distance of 15 mm between the unit and the human body. Carry this device at least 15 mm away from your body to ensure RF exposure level compliant or lower to the reported level. To support body-worn operation, choose the belt clips or holsters, which do not contain metallic components, to maintain a separation of 15 mm between this device and your body.

RF exposure compliance with any body-worn accessory, which contains metal, was not tested and certified, and use such body-worn accessory should be avoided.