


# QUICK GUIDE/ GUIDE DE DÉMARRAGE RAPIDE




## QUICK GUIDE

EN English

FR Français

### PLUGGING IN THE AC ADAPTER

Connect one end of the AC adapter to the DC jack of the unit and the other end to an electrical outlet.



### CHARGING THE BUILT-IN BATTERY BY THE AC POWER/SOLAR ENERGY

The unit has a built-in Lithium ion battery for portable power when not using the AC adapter. When the adapter is plugged in or the unit is exposed under the sunshine, the unit will start charging. During charging, the  indicator on the display starts blinking.

To fully charge an empty battery:

AC/DC: 3 hours

Solar: 6 hours

\*Charge times may vary depending on solar conditions.

**Note:** To maximize battery life, charge the unit through AC for 12 hours prior to first use.

### PLAYING BACK VIA BLUETOOTH

- 1 Press the ON/OFF  button to turn on the unit. The power indicator lights up.
- 2 Press the Bluetooth button to switch the sound source to Bluetooth mode. The  indicator appears on the display.
- 3 Hold the  button for 3 seconds to place the unit in pairing mode. The indicator starts blinking rapidly. Unit will give off two short beeps.
 

**Note:** The indicator turns solid after the unit is successfully connected. If the indicator turn to blink slowly after 3 minutes, the pair was unsuccessful.
- 4 Open the Bluetooth settings menu on your Bluetooth-enabled mobile device or computer. Once it is recognized, "rukus solar" will appear on the display of the Bluetooth-enabled device. Select "rukus solar" to pair and connect with your device.
 

**Note:** On an iPhone or iPad, tap "rukus solar" to select. If prompted for a password, enter "1234".
- 5 Once Bluetooth is connected, select the music and press  button on your device. The unit will playback music automatically.

**Note:** Playback time on built-in battery is ~8 hours, depending on music level and other factors.

### PLAYING BACK VIA AUX

You can enjoy the sound from an external device such as a portable digital music player. Be sure to turn off the power of the external device before making any connections. For details, refer to the instruction manual of the device to be connected.

- 1 Connect any device with headphone or line out jack with a 3.5mm line in cable to **AUX IN** jack on the bottom of the unit.
- 2 Press the  button to turn on the unit.
- 3 Press the  button to switch the sound source to AUX mode, if the unit is not in AUX mode.
- 4 Turn on your external device and press  button.
- 5 The unit will playback the music from the external device automatically.

### USB PORT FOR MOBILE DEVICE CHARGING (5V, 500mAh)

The USB jack can be used to charge most devices that allow for USB charging (including many mobile phones, smart phones and wireless headsets).

- 1 Connect one end of the USB cord to your device and the other end to the USB jack of the unit.
- 2 Press the  button to start charging for your device. Press the button again to stop charging.

**Note:** Use the USB power cord that came with your device to connect to the unit.

### ADJUSTING THE VOLUME LEVEL

Press the  and  buttons to adjust the volume levels.

**Note:** During volume adjustments, if the LED indicator starts to blink, minimum or maximum volume level has been reached.

### BASS BOOST

Press the  button to turn on bass boost. Press the button again to turn off.

### SWITCHING E INK DISPLAY BACKGROUND COLORS

Press and hold the  for 5 seconds to toggle between black and white backgrounds on the E Ink display.

### AUTOMATIC ENERGY SAVING

If unit is idle for 10 minutes (no sound output or operation), the unit will turn off automatically.

# ETON

## Safety Information

	<b>CAUTION</b> RISK OF ELECTRIC SHOCK DO NOT OPEN	
	The lightning flash with arrowhead symbol, within an equilateral triangle is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.	
	The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.	
<b>WARNINGS:</b> TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, DO NOT EXPOSE THIS APPLIANCE TO RAIN OR MOISTURE. <b>DO NOT REMOVE COVER or OPEN THE CABINET.</b> Dangerous high voltages are present inside the enclosure. No user serviceable parts inside. Leave all servicing to qualified service personnel.		

### IMPORTANT SAFETY INSTRUCTIONS

1. Read these instructions.
2. Keep these Instructions.
3. Heed all Warnings.
4. Follow all instructions.
5. Do not use this apparatus near water.
6. Clean only with dry cloth.
7. Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
8. Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
9. Do not defeat the safety purpose of the polarized or grounding - type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong is provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
10. Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
11. Only use attachments/accessories specified by the manufacturer.
12. Use only with the cart, stand, tripod, bracket or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over. 
13. Unplug this apparatus during lightning storms or when unused for long periods of time.

14. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
15. Apparatus shall not be exposed to dripping or splashing and no objects filled with liquids, shall not be placed on the apparatus.
16. The mains plug is used as disconnect device and it shall remain readily operable during intended use. In order to disconnect the mains plug from the mains completely, the mains plug should be disconnected from the mains socket outlet completely.
17. The batteries (battery pack & batteries installed) shall not be exposed to excessive heat such as sunshine, fire or the like.
18. Do not place any naked flame sources, such as lighted candles, on the apparatus.
19. The battery used in this product must be properly recycled or disposed of. Please contact your local recycling center for proper battery handling and disposal instructions.

For compatibility between the RK100/RKS100 system and another device with Bluetooth technology, consult the device's documentation and dealer. In some countries, there may be restrictions on using Bluetooth devices. Check with your local authorities.

Bluetooth is a registered trademark of Bluetooth SIG, Inc

**WARNING!** Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type.

**WARNING!** Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Please read rating label at the bottom of system for power input and other safety information.

### FCC and IC Information:

This device complies with Part 15 of the FCC Rules and RSS-210 of the IC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

**Warnings:** The device meets the exemption from the routine evaluation limits in section 2.5 of RSS 102 and users can obtain Canadian information on RF exposure and compliance from the Canadian Representative Burnport Holdings Ltd. 72MT Belcher Pls, East, Calgary, Alberta, T2Z 2G1, CANADA. Tel: 403-257-4961

### Canada IC statments

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

### FCC&IC Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment and meets the exemption from the routine evaluation limits in section 2.5 of RSS 102.

1. This Transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.
2. This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20 centimeters from user and bystanders.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio TV technician for help.

### Information for Users on Disposal of Old Equipment

#### [European Union]

This symbol indicates that the electrical and electronic equipment should not be disposed as general household waste at its end-of-life. Instead, the product should be handed over to the applicable collection point for the recycling in accordance with your national legislation.



Attention:  
This symbol is only valid in the European Union.

By disposing of this product correctly, you will help to conserve natural resources and will help prevent potential negative effects on the environment and human health that could otherwise be caused by inappropriate waste handling of this product. For more information about collection point and recycling of this product, please contact your local municipal office, your household waste disposal service or the shop where you purchased the product.

Penalties may be applicable for incorrect disposal of this waste, in accordance with national legislation.

### [Other Countries outside the European Union]

If you wish to dispose of this product, please do so in accordance with applicable national legislation or other rules in your country for the treatment of old electrical and electronic equipment.

### CAUTION - Proper Installation

- Install the system in a place which is level, dry and neither too hot nor too cold. The appropriate temperature is between 5 °C and 35 °C.
- Install the system in a location with adequate ventilation to prevent internal heat from building up inside the unit.
- Leave sufficient distance between the system and TV.
- Keep the system away from TV to avoid interference with TV.

### CAUTION - Proper Ventilation


To avoid risk of electric shock and fire, and to prevent damage, locate the apparatus as follows:

**Front:** No obstructions and open spacing.


**Sides / Top / Back:** No obstructions should be placed in the areas shown by the dimensions.

**Bottom:** Place on the level surface. Maintain an adequate air path for ventilation by placing on a stand with a height of 10 cm (3-15/16") or more.

Front View:



Side View:



QDID: