

## LIMITED WARRANTY OF CHOICEMMED AMERICA

To obtain full warranty coverage, please be sure to complete your product registration within 30 days from date of purchase. If you choose not to register your product, this Limited Warranty will be void.

### ONLINE:

- Go to [www.choicemmedamerica.com/register](http://www.choicemmedamerica.com/register)
- Fill out required information

### MAIL:

- Complete the Warranty Registration Card
- Include a COPY of your sales receipt
- Send to:

ChoiceMMed America Co.

2558 Pearl Buck Road, Suite 8A, Bristol PA, 19007

Please read the warranty conditions carefully.

For detailed warranty information, please visit: [www.choicemmedamerica.com/warranty](http://www.choicemmedamerica.com/warranty)

### Warranty Registration Card

Model No. \_\_\_\_\_ LOT# \_\_\_\_\_

(LOT# - located at the bottom of the packaging)

Serial NO. (SN) \_\_\_\_\_

(SN - located on the back on the unit)

Purchase Date \_\_\_\_\_

Purchaser Name (M F) \_\_\_\_\_

Age: ☐ Under 18 ☐ 18-34 ☐ 35-49 ☐ Over 50

E-Mail: \_\_\_\_\_

Phone: \_\_\_\_\_

Address1: \_\_\_\_\_

Address2: \_\_\_\_\_

City/State: \_\_\_\_\_ Zip: \_\_\_\_\_

### Warranty Conditions

ChoiceMMed America Co. warrants to the original purchaser that this equipment will be free from defects in materials and workmanship for a period of two years from the date of purchase. This warranty shall be limited to the repair adjustment or replacement at the manufacturer's option of defective parts free of charge except the cost of transportation to ChoiceMMed America Co. Manufacturer's responsibility is limited to actual cost of item. When returning equipment for warranty service, all shipping and insurance charges must be prepaid and the proof of purchase must be enclosed. A payment of \$10.00 must be included to cover the return shipping and handling. Returns will only be shipped to locations within the USA. ChoiceMMed America Co. will not be responsible for expenses or inconveniences, or consequential damages occasioned by equipment or by breach of any expressed or implied warranty with respect there to.

### Limitations

This warranty covers all defects encountered in normal use of the equipment and does not apply in the following cases.

- 1) If the equipment has been serviced by other than a certified center.
- 2) Damage to the equipment due to mishandling, abuse, accident or failure to follow the operating instructions.
- 3) INSTRUMENTS: Warranty does not extend to display face, batteries and electrode pads.

Service Phone: (215)-874-0458

Customer Service Representatives are available  
Monday through Friday - 9:30am to 4:30pm EST

[www.choicemmedamerica.com](http://www.choicemmedamerica.com)

# OPERATOR'S MANUAL

iChoice A42\_Ver1.0

## Wireless Activity Tracker

### 1. Box Contents


- 1 iChoice A42 Activity Tracker
- 1 USB charging cable
- 1 user guide

If any of the above contents are not included, please contact the Distributor from which you originally purchased this product. To obtain service under warranty, please read our warranty terms at <http://www.ichoicelife.com/support/warranty-services>.

For more products information, please visit <http://www.ichoicelife.com>

### 2. Understanding your unit

The iChoice A42 is the newest generation of activity trackers that allow the user to track personal activities, interact with an online interface. iChoice A42 is your perfect companion. It fits comfortably around your wrist so you can wear it on your wrist. It tracks steps and goal efficiency. Just check out from the App to see how you stack up against your personal goal. It is the motivation you need to get out and be more active.



Keep the device screen up and shake it, one of the LED lights will be lit up. The white LED light is a signal light. When the white light is on, indicate the device is working in normal. The white light will flash when the tracking data is successful to sync to the App or the settings have been uploaded to the device successfully.


The red LED light is the battery power indicator only.

### 3. Using Your Unit

#### 1. Download the free iChoice App

Scan the QR code on the outside of the package or visit [www.ichoicelife.com/app](http://www.ichoicelife.com/app) to download and install iChoice App on your smartphone.

Note: the App is compatible with the following devices:



#### 2. Sign up an Account

Open the iChoice App, tap Sign up, fill out your personal information, enter email address and password, and then click Submit to get a new account. If you already have an account, log in.

#### 3. Link Your Device

Plug your iChoice A42 into the charging cable, connect the charging cable to a computer's USB port or any USB charging outlet, the white LED light will be on and last 10s.

Move your iChoice A42 close to your mobile device, tag Link or Change Device on your App, then select iChoice A42, the App will search and link your iChoice A42 automatically. When the link is successful, the white LED light will flash three times and the App will show Successful.

#### NOTE:

1. You need to link your A42 to the App within 30s after you plug the charging cable to a computer's USB port or any USB charging outlet, if that fails, you can plug out and plug in the charging cable again to retry.
2. Only one tracker can be paired to your account at a time. If you have multiple trackers, you'll need to have multiple iChoice accounts.

#### 4. Sync Data

If the link is successful, your fitness data will sync from your iChoice A42 to the App automatically. You can also force your A42 to sync to the iChoice App on demand (just click the A42 product image on the main dashboard page). Note: You must have Bluetooth enabled to sync your tracker to your phone.

#### 5. View Your Fitness Data

View the steps and goal efficiency track by your iChoice A42 on the iChoice App.

#### NOTE:

When you shake your iChoice A42 with its screen up, the white light on means the iChoice A42 is in normal now and the red light on means the battery power is lower than 20%, you need to charge it as soon as possible.

### 4. Cleaning your iChoice A42

Wipe your iChoice A42's surface with a soft dry cloth.

- When oil and dirt are difficult to remove, a soft dry cloth moistened with clear water or usable neutral solvent to clean surface may be used. Wipe with dry cloth.
- Do not immerse or splash water into the device.
- Do not use volatile liquid such as ethanol and/or gasoline.

### 5. Battery life

- Your iChoice A42 runs on a chargeable lithium battery.
- The battery will last 7 days on a full charge with regular use.
- When the battery power is lower than 20%, every time you wake up your unit, the red LED light is on for 5s to indicate that your iChoice A42 need to be charged.

### 6. Battery charge

Plug your iChoice A42 to the charging cable, connect the charging cable to a computer's USB port or any USB charging outlet. The red LED light flashes while charging and turns to be on when the charging is complete.

#### Note:

If the iChoice A42 is on a charge after it has powered off, when your iChoice A42 is charged already and you wear it to track again, please sync your iChoice A42 with the App one time to update the time.

### 7. Memory

The history data will be uploaded to the App and removed from your iChoice A42 every time iChoice A42 syncs with the App successfully. If you cannot sync your iChoice A42 to the App for a long time, your iChoice A42 will track and store your fitness data up to 30 days.

**NOTE:**

The iChoice A42 will override old data. To ensure no data is lost, we recommend you to sync your iChoice A42 to the App regularly.

Charging voltage is 5V, working voltage is 3.7V.

The USB port only for charging.

## 8. Unit Specs

### 1. Screen

LED display screen

### 2. Size and weight

● 9.45" x 0.75" x 0.39"

● Lower than 0.26lbs

## 9. Environmental Conditions

Operation Temperature: 5°C ~ 40°C (41 °F ~ 104 °F)

Storage/ transport Temperature: -20°C ~ 55°C (-4 °F ~ 131 °F)

Ambient humidity: ≤80%, no condensation in operation;

≤93%, no condensation in storage/ transport

Atmosphere pressure: 86kPa ~ 106kPa

Note: keep unit in dry conditions. Damp conditions may shorten the life of your unit and even damage the product.

## 10. Frequently Asked Questions

### 1. *Do I have to charge my iChoice A42 before the first use?*

Keep your iChoice A42's screen up and shake it, if the red LED light is on or there is no lights on, you need to charge your iChoice A42 before using it.

### 2. *How do I adjust the time on my iChoice A42?*

Download the FREE iChoice App and link your iChoice A42 with the App. The time will update to the current time automatically.

### 3. *Does the iChoice A42 show the battery status?*

When the battery is low, the red LED light will be on when you keep your iChoice A42 screen up and shake it. The battery lasts about 7-10 days after being fully charged.

### 4. *When does my iChoice A42 reset my activity data?*

The iChoice A42 resets all data to zero everyday at midnight.

## 11. FCC Declaration

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) This device must accept any interference received, including interference that may cause undesired operation.

Note: This product has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This product generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this product does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.

-Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver

is connected. Consult the dealer or an experienced radio/TV technician for help.

Please take attention that changes or modification not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

© 2015 ChoiceMMed America Co.  
ALL RIGHTS RESERVED  
Revised Date: July 21, 2015

**Distributed By:**

**ChoiceMMed America Corporation**

2558 Peel Buck Road, Suite 8A

Bristol, PA 19007

[www.choicecmmmedamerica.com](http://www.choicecmmmedamerica.com)

# iChoice

**ChoiceMMed America Co.**  
**Bristol, PA**