

P200 Printer Quick Installation Guide




Version 1.0

Packing List



Contact your distributor for replacement parts

Front




Back




Load Paper

1. Open the lid.
2. Install paper roll with paper pointing up.
3. Pull out a small amount of paper, close lid.




Install Battery

1. Remove the battery cover.
2. Plug in the battery cable into the connector.
3. Install the battery into the slot and install the battery cover.



Power & Charging


1. Insert the DC plug of power adapter* into the power jack of printer.
2. Plug power adaptor into AC power outlet.



*Optional 3Amp power supply required when running without battery.


Install SAM Card

1. Remove the battery cover and battery.
2. Open the card holder and insert the SAM card with the electronic chip facing down and the cut-out corner on top.
3. Close the card holder and lock it into place.
4. Install the battery and the battery cover.




Smart Card

Position the smart card and insert it into the smart card reader slot with the chip facing down.



MSR

1. Position the card with the magnetic stripe facing down and towards the printer.
2. Swipe it through the reader in either direction.



Bluetooth

The P200 printer can communicate with other Bluetooth SPP compatible devices, such as peripheral equipment PDAs, mobile phones, and computers. Confirm that your host device supports the SPP (Serial Port Profile) before using the P200 printer. Bluetooth communication distance is up to 10m.

Default Device Name: P200
Default PIN Code: 1234

Operating Temperature:
0~40°C (+32° to 104°F)

Operating Humidity:
20~85%, no condensation

Storage Temperature:
-20~60°C (-4° to 140°F)

Storage Humidity:
10~90%, no condensation

FCC Statement

FCC ID: UWJP200

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation.

PART 15.21 STATEMENT

- (3) Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
- (4) For receivers and Class B digital This product has been tested and complies with the specifications for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide

reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used according to the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which is found by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment or devices
- Connect the equipment to an outlet other than the receiver's
- Consult a dealer or an experienced radio/TV technician for assistance

Europe-R&TTE Compliance Statement

Hereby, Blue Bamboo declares that this equipment complies with the essential requirement and other relevant provision of Directive 1999/5/EC OF THE EUROPEAN PARLIAMENT AND THE COUNCIL of march 9, 1999 on radio equipment and telecommunication terminal Equipment and the mutual recognition of their conformity(R&TTE).

CE NB Mark:



CE Statement

WARNING:

- Do not disassemble the Printer, battery or AC adapter. Only qualified technicians may service the device.
- Do not use batteries, AC adapters or Printer near water.

Caution

For warranty period, repair and service issues, please contact your distributor:



Environment