

Your YARDAGE PRO TOUR is a precision instrument designed to provide many years of enjoyment. This booklet will help you achieve optimum performance by explaining its adjustments and features as well as how to care for this precise laser rangefinding instrument. To ensure optimal performance and longevity, please read these instructions before using your YARDAGE PRO TOUR.

INTRODUCTION

Your Bushnell YARDAGE PRO TOUR is the worlds smallest and most advanced laser rangefinder made exclusively for golf. Using Digital Technology and measuring a mere 1.5x4x2.75 inches and weighing 6.8 ounces, the YARDAGE PRO TOUR delivers superb and accurate range performance to +/- one yard to virtually any object found on a golf course. The BUSHNELL YARDAGE PRO TOUR DDES NOT require the use of reflectors. Range to a golf flag as far as 225 yards out or to a tree or bunker 570 yards away for a reference point. With YARDAGE PRO TOUR, you can determine club selection, save strokes, and build confidence. The unique shape and palm size allows outdoors enthusiast to easily grip with a single hand. When not using, place it in the convenient carrying case and clip to your golf bag. The rugged and weather resistant Yardage Pro Tour features popular Scan mode providing continuous distance measurements as multiple targets in the field of view are scanned.

The YARDAGE PRO TOUR emits invisible, eyesafe, infrared energy pulses. Sophisticated digital technology and a high-speed clock are used to instantaneously calculate distances, by measuring the time it takes for each pulse to travel from the rangefinder, to the target, and back.

The ranging accuracy of the YARDAGE PRO TOUR is plus or minus one yard / meter under most circumstances. The maximum range of the instrument depends on the reflectivity of the target. The maximum distance for most objects is 570 yards / 521 meters while for highly reflective objects the maximum is 700 yards / 640 meters. Note: You will get both longer and shorter maximum distances depending on the reflective properties of the particular target and the environmental conditions at the time the object is being distanced to.

The color, surface finish, size and shape of the target all affect reflectivity and range. The brighter the color, the longer the range. Red is highly reflective, for example, and allows longer ranges than the color black, which is the least reflective color. A shiny finish provides more range than a dull one. A small target is more difficult to range than a larget target at a 90 degree angle (where the target surface is perpendicular to the flight path of the emitted energy pulses) provides good range while a steep angle on the other hand, provides limited ranging. In addition, lighting conditions (e.g. the amount of sunlight) will affect the ranging capabilities of the unit. The less light (e.g. overcast skies) the farther the unit's maximum range will be. Conversely, very sunny days will decrease the unit's maximum range. Ranging through a glass window is not possible in most circumstances due to the reflection caused by glass.

OPERATIONAL SUMMARY

While looking through the monocular, depress the power button once to activate the inview display system (LCD). Aim the YARDAGE PRO TOUR at a target at least 10 yards away, depress and hold the power button down until range reading is displayed. Release the power button. Your Yardage Pro TOUR features an adjustable eyepiece. Simply rotate the monocular until the reticle and

object distanced to are in focus to your eye. Note: Once activated, the YARDAGE PRO TOUR'S LCD will remain active and display the last distance measurement for 6 seconds. You can depress the power button again at any time to distance to a new target. As with any laser device, it is not recommended to directly view the emissions for long periods of time with magnified lenses.




FEATURES

The YARDAGE PRO TOUR's sophisticated digital technology allows you to select between various units of measure and targeting modes. In addition, your YARDAGE PRO TOUR's LCD incorporates illuminated indicators that advise you when the laser is active and when the battery charge is low. A summary of these features is presented below:

<u>UNIT OF MEASURE OPTIONS</u> The YARDAGE PRO TOUR can be used to measure distances in yards or meters. The unit of measure indicators are located in the upper right portion of the LCD. To select between yards and meters, look through the monocular, depress the "mode" button (left side of the unit underneath the BUSHNELL YARDAGE PRO logo) and hold it down for approximately 2 seconds. If you are changing from yards to meters, a change in unit of measure will be indicated by the illumination of the letter M for METER indicator while the YD for YARD indicator is turned off. If you are changing from meters to yards, the opposite will occur. Note: The YARDAGE PRO TOUR will return to the last setting used, each time the unit is turned on.

TARGETING MODES The YARDAGE PRO TOUR incorporates exclusive targeting modes that allow you to adjust the performance parameters of the unit to suit your specific situation and environment. The different targeting modes available are listed below:



Standard (LCD Indicator - none) This setting allows most targets to be distanced up to 570 yards. Used for moderately reflective targets that are typical of most distancing situations. The minimum distance in the standard mode is 10 yards.

SCAN (LCD Indicator - "SCAN") When the Power button is held down longer than 3 seconds, the unit transitions to SCAN mode. This mode allows the range to be continuously updated as long as the Power button remains depressed. The word "SCAN" will blink and appear in the left side of the LCD once this mode is activated.

ILLUMINATING INDICATORS Low Battery Charge (LCD Indicator -) When both dashes inside the battery symbol are displayed, the battery is fully charged. When the dashes start to fade away, it means the battery charge is getting low and the 3-volt lithium battery should be replaced.

ROLL DOWN EYECUP The YARDAGE PRO TOUR's monocular is equipped with a rubber eyecup designed for your comfort and to exclude extraneous external light. If you wear sun / eyeglasses, roll down the eyecup. This will bring your eye closer to the ocular lens, thus providing improved field of view.

SPECIFICATIONS

OPTICAL DESIGN A liquid crystal display (LCD) is mounted within the optical system and when activated, displays a reticle for targeting, yard / meter and mode designations, and low battery indicators. Inherent in the manufacturing process are small black spots that appear in the optical system. These are a natural characteristic of the LCD, cannot be fully eliminated in the manufacturing process and do not affect the distancing performance of the unit.

SPECIFICATIONS (cont'd)

Dimensions: Pocket Size, measuring 1.5x4x2.75 inches Weight: 6.8 oz. Accuracy: +/- 1 yard Magnification: 6x Display: LCD (even and odd numbers) Power Source: 3- volt lithium battery included FOV: 320 ft. @ 1000 yards Total Eye Relief: 20mm Exit Pupil: 4 mm Water resistant Modes: Standard, Scan 10-yard minimum, 700 yards to a reflective target, 250 yards to a flag, 570 yards to a tree Includes case and strap

CLEANING

Gently blow away any dust or debris on the lenses (or use a soft lens brush). To remove dirt or fingerprints, clean with a softcotton cloth, rubbing in a circular motion. Use of a coarse cloth or unnecessary rubbing may scratch the lens surface and eventually cause permanent damage. For a more thorough cleaning, photographic lens tissue and photographic-type lens cleaning fluid or isopropyl alcohol may be used. Always apply the fluid to the cleaning cloth - never directly on the lens.

Before returning for repair, consult the Trouble Shooting Table below.

TROUBLE SHOOTING TABLE

If unit does not turn on - LCD does not illuminate:

- · Depress power button.
- · Check and if necessary, replace battery.

If unit powers down (display goes blank when attempting to power the laser):

The battery is either weak or low quality. Replace the battery with a good quality lithium battery.

There is no reset button to clear last range reading before ranging another target:

The last range reading does not need to be cleared before ranging another target. Simply aim at the new target using the LCD's reticle, depress the power button and hold until new range reading is displayed.

If target range cannot be obtained:

- · Make sure LCD is illuminated.
- Make sure that the power button is beingdepressed (as opposed to mode button).
- Make sure that nothing, such as your hand or finger, is blocking the objective lenses
- (lenses closest to the target) that emit and receive the laser pulses.
- Make sure unit is held steady while depressing power button

WARRANTY / REPAIR

One-Year LIMITED WARRANTY

Your Bushnell® Laser Rangefinder is warranted to be free of defects in materials and workmanship for one year after the date of purchase. In the event of a defect under this warranty, we will, at our option, repair or replace the product, provided that you return the product postage prepaid. This warranty does not cover damages caused by misuse or improper handling, installation or maintenance of the product.

> Any return made under this warranty must be accompanied by the items listed below:

1) A check in the amount of \$15.00 to cover the cost of handling 2) Name and address for product return

- 3) An explanation of the defect
- 4) Product should be well packed in a sturdy outside shipping carton to prevent damage in transit and return postage prepaid to the address listed below:

IN U.S.A. Send To: **Bushnell Performance Optics** 8500 Marshall Drive Lenexa, Kansas 66214

IN CANADA Send To:

Bushnell Performance Optics 25A East Pearce Street, Unit 1 Richmond Hill, Ontario L4B 2M9

For products purchased outside the United States and Canada please contact your local dealer for applicable warranty information. This warranty gives you specific legal rights. You may have other rights which vary from country to country.

©2001 Bushnell Performance Optics