



CASTLES TECHNOLOGY

S1L2 POS Terminal

Book 2

User Manual

S1L2

Confidential

Version 1.0

Sep. 2023

CRT-S1-23-1.0- /FCC/IC/UL/CB/CE-EN

Castles Technology Co., Ltd.

6F, No. 207-5, Sec. 3, Beixin Rd., Xindian District,
New Taipei City 23143, Taiwan R.O.C.

<http://www.castech.com.tw>

WARNING

Information in this document is subject to change without prior notice.

No part of this publication may be reproduced, transmitted, stored in a retrieval system, nor translated into any human or computer language, in any form or by any means, electronic, mechanical, magnetic, optical, chemical, manual, or otherwise, without the prior written permission of **Castles Technology Co., Ltd.**

All trademarks mentioned are proprietary to their respective owners.

Castles Technology

Revision History

<i>Version</i>	<i>Date</i>	<i>Descriptions</i>	<i>Author</i>
1.0	2023.09.18	Initial creation.	Yao

Castles Technology

Contents

1. Introduction	5
2. Regulatory Instruction of Usage	6
3. Hardware Setup	7
3.1. Parts of the Terminal	7
3.2. Insert SAM Card	10
3.3. Insert GSM SIM Card	11
3.4. Insert Memory card.....	12
3.5. Device Wall Mount.....	13
4. Appendix	14
4.1. UL/IEC 62368-1	14
4.2. FCC.....	15
4.3. IC.....	16

1. Introduction

This document provides a guideline for operating and configuring Castles S1L2 POS terminal.

The scope of this document includes setting up the terminal, basic operation, application lifecycle, and some advanced features.

Regulatory instruction of usage

- Before using the terminal, please check the does it has been disassembled, modified, or happened the abnormal situation. If yes, please do not continue to use.
- Please stay away from strong electromagnetic waves.
(Example) Microwave ovens, magnets, shoplifting prevention devices, high-voltage wires, automatic doors, communication antennas, etc.
- Condensation can occur when moving from a cold place to a warm place. If condensation occurs, do not use the unit until the connected water droplets evaporate.
- Static electricity may occur in some places (such as where you are using a carpet).
- Please do not leave it in the sun for a long time.
- Please operate the unit carefully as it is a precision instrument. Do not apply impact, drop or heavy objects on top of the unit.
- Do not attach dust, oil, etc. to a part of the power terminal. Also, please do not scratch.


2. Regulatory Instruction of Usage

- Before using the terminal, please check has it been disassembled, modified, or showed abnormal situation. If yes, please do not use.
- Please stay away from strong electromagnetic waves.
(Example) Microwave ovens, magnets, shoplifting prevention devices, high-voltage wires, automatic doors, communication antennas, etc.
- Condensation can occur when moving from a cold place to a warm place. If condensation occurs, do not use the unit until the connected water droplets evaporate.
- Static electricity may occur in some places (such as where you use a carpet).
- Please do not leave it in the sun for a long time.
- Please operate the unit carefully as it is a precision instrument. Do not apply impact, drop or heavy objects on top of the unit.
- Do not attach dust, oil, etc. to a part of the power terminal. Also, please do not scratch.

3. Hardware Setup


3.1. Parts of the Terminal

Front




- | | |
|-------------------------|----------------------------------|
| 1. Touch Pen Holder | 4. Smart Card Reader |
| 2. Camera (2 Megapixel) | 5. Magnetic Stripe Reader |
| 3. LCD Display (5") | 6. Contactless Card Landing Zone |

Rear




- 7. GSM SIM card slots 1-2
- 8. Micro SD card slot
- 9. SAM slots 1-2
- 10. SAM slots 3-4

Upper side



- 11. COM Port
- 12. 12V Power Connector
- 13. Type C USB slot
- 14. Ethernet Port

3.2. Insert SAM Card



Step 1: Remove the four screws and rear cover.

Step 2: Insert SAM card into desire slot.




SAM 1 & 2 & 3 & 4:

Gold contact is on the lower side of the card and facing down.

Step 3: Reverse the operation of step 1 to install the rear cover.

3.3. Insert GSM SIM Card



Step 1: Remove the four screws and rear cover.

Step 2: Open SIM socket and insert GSM SIM card into desire slot.





SIM 1:

Gold contact is on the lower side of the card and facing down.

Step 3: Reverse the operation of step 1 to install the rear cover.

3.4. Insert Memory card



Step 1: Remove the four screws and rear cover.

Step 2: Open the slot cover and place Micro SD memory card.




Gold contact is on the lower side of the card and facing down.

Step 3: Close and lock up the slot cover.

Step 4: Reverse the operation of step 1 to install the rear cover.

3.5. Device Wall Mount

The S1L2 can support wall mount by 4 screws using the 4 screw holes on the rear side of the device.



4. Appendix

4.1. UL/IEC 62368-1

- **Warning:**

Power cord shall be connected to a socket-outlet with earthing connection.

- **Warning:**

Risk of explosion if battery is replaced by an incorrect type. Dispose of expended battery in accordance with local disposal regulations.

- **Warning:**

This product is intended to be supplied by a Listed Power Adapter "L.P.S." (Or "Limited Power Source") and is rated at 12 Vdc, 1 A min., Tma = 50 degrees C.

- **Warning:**

The equipment is only suitable for mounting wall at height $\leq 2m..$

- **Attention:**

le cordon d'alimentation doit être branché sur une prise secteur avec mise à la terre.

- **Attention:**

Risque d'explosion si la batterie est remplacée par une de type incorrect Éliminer la pile usagée conformément à la réglementation locale en vigueur.

- **Attention:**

Le produit est destiné à être alimenté par un adaptateur secteur répertorié « L.P.S. » (ou "Source d'alimentation limitée") et est évalué à 12 Vdc, 1A min., Tma = 50 degrés C.

- **Attention:**

L'équipement ne convient que pour un montage mural à une hauteur $\leq 2 m..$

4.2. FCC

Federal Communication Commission Interference Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution:

- Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.
- This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

RF Exposure Information (SAR)

This device meets the government's requirements for exposure to radio waves. This device is designed and manufactured not to exceed the emission limits for exposure to radio frequency (RF) energy set by the Federal Communications Commission of the U.S. Government. The exposure standard employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit set by the FCC is 4 W/kg. Tests for SAR are conducted using standard operating positions accepted by the FCC with the EUT transmitting at the specified power level in different channels.

The FCC has granted an Equipment Authorization for this device with all reported SAR levels evaluated as in compliance with the FCC RF exposure guidelines. SAR information on this device is on file with the FCC and can be found under the Display Grant section of www.fcc.gov after searching on FCC ID: WIYSLM500QA

4.3. IC

Industry Canada statement

This device complies with ISED's licence-exempt RSSs. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Le présent appareil est conforme aux CNR d'ISED applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) le dispositif ne doit pas produire de brouillage préjudiciable, et (2) ce dispositif doit accepter tout brouillage reçu, y compris un brouillage susceptible de provoquer un fonctionnement indésirable.

Radio Frequency (RF) Exposure Information

The radiated output power of the Wireless Device is below the Industry Canada (IC) radio frequency exposure limits. The Wireless Device should be used in such a manner such that the potential for human contact during normal operation is minimized.

This device has been evaluated for and shown compliant with the IC Specific Absorption Rate ("SAR") limits when operated in portable exposure conditions.

Informations concernant l'exposition aux fréquences radio (RF)

La puissance de sortie émise par l'appareil de sans fil est inférieure à la limite d'exposition aux fréquences radio d'Industry Canada (IC). Utilisez l'appareil de sans fil de façon à minimiser les contacts humains lors du fonctionnement normal.

Ce dispositif a été évalué pour et démontré conforme à la Taux IC d'absorption spécifique ("SAR") des limites lorsqu'il est utilisé dans des conditions d'exposition portatifs.

Caution :

(i) the device for operation in the band 5150-5250 MHz is only for indoor use to reduce the potential for harmful interference to co-channel mobile satellite systems.

Avertissement: *(i) les dispositifs fonctionnant dans la bande 5150-5250 MHz sont réservés uniquement pour une utilisation à l'intérieur afin de réduire les risques de brouillage préjudiciable aux systèmes de satellites mobiles utilisant les mêmes canaux.*

~ END ~