

Bluetooth USB Adapter

Quick Start Guide

v 1.0

© All rights reserved.

All trade names are registered trademarks of respective manufacturers listed.

The Bluetooth name and the Bluetooth trademarks are owned by Bluetooth SIG, Inc.

This manual may not be copied in any media or form without the written content of original maker.

Table of Contents

Welcome.....	3
Features	3
System Requirements	3
Create a Bluetooth Device in Windows.....	4
In Windows 10.....	4
In Windows 8.1.....	5
In Windows 7.....	5
Bluetooth In-Box Profiles.....	6
Windows 10 for desktop editions.....	6

Welcome

Thank you for your purchase of the Bluetooth USB Adapter. Featuring Bluetooth wireless technology, Bluetooth USB Adapter creates cable-free connections between your PCs and other Bluetooth devices. Bluetooth USB Adapter supports Bluetooth 4.2 standard and is compatible with all Bluetooth certified devices.

Features

- Compliant with Bluetooth specification version 4.2
- Support for Microsoft Windows 7 / 8.1 / 10
- Easy operation and setting up.

System Requirements

Processor:

- Intel / AMD Dual/Quad Core x86/x64 CPU

Operating System:

- Microsoft Windows 7 / 8.1 / 10
- Linux (Get Technical Support from Manufacture)



Bluetooth Software

- No extra driver/Bluetooth software installation under Windows
- Applies to Windows In-box Bluetooth specification support and profiles

Create a Bluetooth Device in Windows


In Windows 10

■ *To connect a Bluetooth headset, speaker, or other audio device*



1. Turn on your Bluetooth audio device and make it discoverable.
2. Turn on Bluetooth on your PC if it's not on already. To do this, select the **Start**  button, then select **Settings**  >



Devices  > **Bluetooth & other devices**  and turn on **Bluetooth**.

You can also use action center to turn on Bluetooth. To do this, on the taskbar, select **action center**  > **Bluetooth**.

3. In action center, select **Connect**  and then select your device.
4. Follow any more instructions that might appear. Otherwise, you're done and connected.

■ *To connect a Bluetooth keyboard, mouse, or other device*

1. Turn on your device and make it discoverable.
2. Turn on Bluetooth on your PC if it's not on already. To do this, select the **Start**  button, then select **Settings**  >





Devices  > **Bluetooth & other devices**  and turn on **Bluetooth**.

3. Select **Add Bluetooth or other device** > **Bluetooth**. Choose the device and follow additional instructions if they appear, then select **Done**.


■ *To connect a Bluetooth printer or scanner*

1. Turn on your Bluetooth printer or scanner and make it


discoverable.

2. Turn on Bluetooth on your PC if it's not on already. To do this, select the **Start**  button, then select **Settings**  > **Devices**  > **Bluetooth & other devices**  and turn on **Bluetooth**.
3. Select **Printers & scanners** > **Add a printer or scanner**. Wait for it to find nearby printers, then choose the one you want to use and select **Add device**.

In Windows 8.1

1. Turn on your Bluetooth device and make it discoverable.
2. The way you make it discoverable depends on the device.
3. Select the **Start**  button > type **Bluetooth** > select **Bluetooth settings** from the list.
4. Turn on **Bluetooth** > select the device > **Pair**.
5. Follow any instructions if they appear. Otherwise, you're done and connected.

In Windows 7

1. Turn on your Bluetooth device and make it discoverable.
2. The way you make it discoverable depends on the device. Select the **Start** button  > **Devices and Printers**.
3. Select **Add a device** > select the device > **Next**.
4. Follow any other instructions that might appear. Otherwise, you're done and connected.

Bluetooth In-Box Profiles

■ Windows 10 for desktop editions

Profile	Description
GATT	Bluetooth LE GenericAttribute (GATT) Client
A2DP 1.2	Advanced Audio Distribution Profile
AVRCP 1.3	Audio/Video Remote Control Profile
DI 1.3	Device ID Profile
DUN 1.1	Dial-Up Networking
HCRP 1.0	Hardcopy Cable Replacement Profile
HFP 1.5	Hands-Free Profile
HID 1.1	Human Interface Device
HOGP 1.0	HID over GATT Profile
OPP 1.1	Object Push Profile
PANU 1.0	Personal Area Network User
SPP 1.2	Serial Port Profile

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.