

EQUIPMENT APPROVAL INFORMATION

Your telephone equipment is approved to the Public Switched Telephone Network and is in compliance with parts 15 and 68, FCC Rules and Regulations and the Technical Requirements for Telephone Terminal Equipment published by ACTA.

1. Notification to the Local Telephone Company

On the bottom of this equipment is a label that contains, among other information, a product identifier in the form US:AAAEQ##TXXXX. You must, upon request, provide this information to your telephone company.

The digits represented by ## in the product identifier indicate the Ringer Equivalency Number (REN) for this equipment. The REN is useful in determining the number of devices you may connect to your telephone line and still have all of these devices ring when your telephone number is called. In most (but not all) areas, the sum of the RENs of all devices connected to one line should not exceed 5. To be certain of the number of devices you may connect to your line as determined by the REN, contact your local telephone company.

A plug and jack used to connect this equipment to the premises wiring and telephone network must comply with the applicable FCC Part 68 rules and requirements adopted by the ACTA. A compliant telephone cord and modular plug is provided with this product. It is designed to be connected to a compatible modular jack that is also compliant. See installation instructions for details.

Notes

- This equipment may not be used on coin service provided by the telephone company.
- Party lines are subject to state tariffs, and therefore, you may not be able to use your own telephone equipment if you are on a party line. Check with your local telephone company.
- Notice must be given to the telephone company upon permanent disconnection of your telephone from your line.
- If your home has specially wired alarm equipment connected to the telephone line, ensure the installation of this product does not disable your alarm equipment. If you have questions about what will disable alarm equipment, consult your telephone company or a qualified installer.

2. Rights of the Telephone Company

Should your equipment cause trouble on your line which may harm the telephone network, the telephone company shall, where practicable, notify you that temporary discontinuance of service may be required. Where prior notice is not practicable and the circumstances warrant such action, the telephone company may temporarily discontinue service immediately. In case of such temporary discontinuance, the telephone company must: (1) promptly notify you of such temporary discontinuance; (2) afford you the opportunity to correct the situation; and (3) inform you of your right to bring a complaint to the Commission pursuant to procedures set forth in Subpart E of Part 68, FCC Rules and Regulations.

The telephone company may take changes in its communications facilities, equipment, operations or procedures where such action is required in the operation of its business and not inconsistent with FCC Rules and Regulations. If these changes are expected to affect the use of performance of your telephone equipment, the telephone company must give you adequate notice, in writing, to allow you to maintain uninterrupted service.

Your Caller ID phone enables you to:

- Identify callers before you answer the phone.
- Record up to 48 Caller ID messages sequentially.
- Know the caller number while you were away.

To get the most from your new phone, we suggest that you take a few minutes right now to read through this user's guide.

CAUTION: When using telephone equipment, there are basic safety instructions that should always be followed. Refer to the IMPORTANT SAFETY INSTRUCTIONS provided with this product and save them for future reference.

HEARING AID COMPATIBLITY (HAC)

This telephone system meets FCC standards for Hearing Aid Compatibility.

US NUMBER LOCATED ON THE CABINET

REN NUMBER IS LOCATED ON THE CABINET

INTERFERENCE INFORMATION

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference; and (2) This device must accept any interference received, including interference that may cause undesired operation. interference that may cause undesired operation. Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna (that is, the antenna for radio or television that is "receiving" the interference).
- Reorient or relocate the increase the separation between the telecommunications equipment and receiving antenna.
- Connect the telecommunications equipment into an outlet on a circuit different from that to which the receiving antenna is connected.

If these measures do not eliminate the interference, please consult your dealer or an experienced radio/television technician for additional suggestions. Also, the Federal Communications Commission has prepared a helpful booklet, "How To Identify and Resolve Radio/TV Interference Problems." This booklet is available from the U.S. Government Printing Office, Washington, D.C. 20402. Please specify stock number 004-000-00345-4 when ordering copies.

INTRODUCTION

Your Caller ID phone stores and displays specific information, provided by your local telephone company, to subscribers of Caller ID or similar caller identification services. You must subscribe to one of these services in order to use this unit.

IMPORTANT: In order to use this unit, you must subscribe to either the standard Name/Number Caller ID Service.

IMPORTANT: Because cordless phones operate on electricity, you should have at least one phone in your home that isn't cordless, in case the power in your home goes out.

THE LIGHTNING FLASH AND ARROW HEAD WITHIN THE TRIANGLE IS A WARNING SIGN ALERTING YOU OF "DANGEROUS VOLTAGE" INSIDE THE PRODUCT.	CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER (OR BACK). NO USER SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL	THE EXCLAMATION POINT WITHIN THE TRIANGLE IS A WARNING SIGN ALERTING YOU OF IMPORTANT INSTRUCTIONS ACCOMPANYING THE PRODUCT.
SEE MARKING ON BOTTOM / BACK OF PRODUCT		


WARNING: TO PREVENT FIRE OR ELECTRICAL SHOCK HAZARD, DO NOT EXPOSE THIS PRODUCT TO RAIN

WARNING: TO PREVENT FIRE OR ELECTRICAL SHOCK HAZARD, DO NOT EXPOSE THIS PRODUCT TO RAIN OR MOISTURE.

BEFORE YOU BEGIN PARTS CHECKLIST

Make sure your package includes the items:-

- Base Unit
- Handset Coiled Cord
- Corded Handset
- Cordless Handset
- Handset Battery
- Telephone Line Cord
- AC Power Supply
- Cordless Handset Charger



MODULAR JACK REQUIREMENTS

You need an USOC Jack RJ11C/BABT 431A type modular phone jack type modular phone jack, which is the most common type of phone jack. If you don't have a modular jack, call your local phone company to find out how to get one installed.

INSTALLATION NOTE: Some cordless telephones operate at frequencies that may cause interference to nearby TVs microwave ovens, and VCRs. To minimize or prevent such interference, the base of the cordless telephone should not be placed near or on top of a TV, microwave ovens, or VCR. If such interference continues, move the cordless telephone farther away from these appliances.


DIGITAL SECURITY SYSTEM

Your cordless phone uses a security system to provide protection against false ringing, unauthorized access, and charges to your phone line.

INSTALLATION

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

DESKTOP INSTALLATION



NOTE : For desktop charging only, the handset is only able to charge

- Remove the battery compartment door of handset.
- Insert battery pack and connect the cord into the jack inside the handset.
- Put the compartment door back on.
- Place the handset in the base.
- Raise the base antenna.
- Plug the adaptor to the socket-outlet that near the equipment and shall be easily accessible and the other end into the power jack on the back of the base. The IN USE/ CHARGE indicator comes on indicating that the battery is charging.
- Allow the phone to charge for 12 hours prior to first use. If you don't properly charge the phone, battery performance will be

- compromised.
- After charging, plug the telephone line cord into the modular jack and into the LINE jack on the bottom of the base.
 - Set the RINGER program on the handset to ON, if “免打擾” displays on screen. (Please see the details on chapter of Ringer Setting)

Note: The phone automatically defaults to touch-tone dialing. To change to pulse (rotary) dialing, see “Tone/Pulse Dialing”. If you don't know which type of service you have, check with the phone company.

CAUTION: Use only the ATLINKS power supply that came with this unit. Using other power supplies may damage the unit.

NOTE : The phone is shipped in Tone Dialing Mode from the manufacturer.

DISPLAY ICON OF CORDLESS HANDSET

- : Talk
- 00 : Number of incoming calls
- 頻道 : Channel (Handset)
- 貴賓 : VIP memory
- : Battery level indicator (Handset)
- : Low level indicator (Handset)
- 新來電 : (New)Caller ID record
- 去電 : Redial record
- 存儲 : Memory
- 重複 : Repeated incoming caller ID
- 免打擾 : Do not Disturb
- 00:00 : Time (HH:MM)
- 00—00 : Date (DD:MM)(Handset)
- 00 月 00 日 : Date (DD:MM)(Base)
- 密碼鎖 : Number lock (Base)
- ⌂ : ✕ Key display
- ⌂ : # Key display

KEYPAD AND INDICATOR DESCRIPTION

-ON HANDSET

- : IP Speed Dial
- : - 設置: Program Setting
- : - 存儲: Memory Store
- : - 頻道: Channel
- : - 對講: Handset intercom with base
- : - 退出: Exit
- : - 刪除: Delete
- : - 閃斷: Flash