Wireless Charger

User Manual



CONETNES

1.0	INTRODUCTION	1
2.0	FEATURES	1
3.0	SPECIFICATIONS	1
4.0	PACKAGE CONTENTS	2
5.0	OPERATION	2
6.0	CONNECTION DIAGRAM	3

Wireless Charger

DEAR CUSTOMER

Thank you for purchasing this product. For optimum performance and safety, please read these instructions carefully before connecting, operating or using this product. Please keep this manual for future reference.

1.0 INTRODUCTION

This product is a high-performance wireless charger. This product is suitable for mobile phones, MP3, MP4, digital productions, and other productions based on wireless charging 5W or 10W. Connect the wireless to a power charger, and then you can charge your device supported wireless charging (MP3, mobile phones, etc) by put it on the charger directly. It is helpful in long time journey and convenient for business!

2.0 FEATURES

- Transmitting terminal input: 5V/2A,9V/2A,12V/1.5A
- Transmitting terminal output: 5W/7.5W/10W
- Intelligent red/white indicator to show working condition
- Compliant with QI, CE, FCC standards
- It is light, smart and convenient to use

3.0 SPECIFICATIONS

Input	Type-C 5V/2A, 9V/2A, 12V/1.5A
Output	10W Max
Switch Frequency	110~205kHz
Operating Temperature Range	0~30°C
Storage Temperature Range	-20 ~ 70°C
Operation Humidity	10% ~ 80% RH
Storage Humidity	5% ~ 95% RH
Size	W92.5mm*H105mm*T96.5mm
Weight	95g±3g

4.0 PACKAGE CONTENTS

Before attempting to use this unit, please check the packaging and make sure the following items are contained in the shipping carton:

- Main unit×1
- User Manual×1

5.0 OPERATION

Operation Procedures

- 1. Connect the wireless charger to the power adapter, the white light will turn on for 3s then go off.
- 2. Place your device (which supports wireless charging) on the charger and the white light will stay on.
- 3. When finished charging, the white light will stay on.
- 4. Please take out the device after it is fully charged.

Note: red light for staying on when malfunction occurs.

Operation Notes

- 1. For optimum performance, please use the wireless charger according to this user manual.
- 2. Please connect the wireless charger to a power adapter which output should be 5V/2A, 9V/2A,12V/1.5A.
- 3. Please unplug the wireless charger after using.
- 4. Do not use the wireless charger with an electronic product which is not in conformity with the specifications, so as to avoid any problem caused by specification mismatching.
- 5. It's normal that wireless charger will be a little overheated in the use process.
- 6. When the wireless charger stops working under some accidents , you need to check whether the device is compatible with this charger.
- 7. Do not let the wireless charger close to fire, such as stove, candles and etc.
- 8. Do not let the wireless charger soak into liquid, such as swimming pool, bathtub, etc.
- 9. Do not wash the wireless charger with corrosive cleaner.
- 10. If the wireless charger cannot work properly, please contact the store or distributor in your area.
- 11. Do not place metal objects on the back of the phone while it is charging wirelessly. Please check that there is no metal foreign body on the back of your mobile phone when using this product.

6.0 CONNECTION DIAGRAM



FCC Warning

This device complies with part 18 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20 centimeters between the radiator and your body.

P/N