

## Product port introduction:



## Product Description:

1. Product size: 260 \* 111.2 \* 235 M M Carton size:. 645 \* 454 \* 354MM.
- 2 built M P 3 decoder. Support M P 3 audio format player. And built-in memory storage chip.
3. T F with a card slot, maximum support 1 6 G..
4. The integrated U S B 2. 0 controller with U disk flash universal jack, maximum support 1 6 G..
5. Built-in 8 7 5 -. 1 0 8 M H z FM digital radio module, can automatically store 50 radio stations
6. 10 W digital amplifier built-in low power / low distortion rate, the maximum output distortion is 0.5%. N = 8 5 d B
- 7 with 15 W / 4Ω 5.25-inch full-band high-fidelity speakers, loud sound frequency range: 5 0 H z - 2 0 K H z
- 8 with built-in high-capacity 7.4 V / 1600mA lithium-ion battery,
9. External 9V charging interface and 3.5MM AUX input interface.
10. L E D with multifunction digital display.

## Features:

1. M P 3 can play audio formats, fun in perfect sound quality.
2. Low distortion digital amplifier, with full-band high-fidelity full-range speakers, truly perfect sound quality.
3. ready to replace larger capacity T F card to enjoy more music.

- 4 with a U disk flash universal jack, a multi-function socket, one more choice.
  - 5. Digital FM F M, so you always listen to the latest events consultative letter and pop music.
  - 6. Built-in memory storage chip, while power and memory and radio songs and volume data storage and memory function.
- Without losing your selected functions and settings.
- 7: Multi-function L E D digital display, can be shown in the current state of play, easy viewing.
  - 8: With remote control, front of the product with 15 bright LED, a full-power flashes; Packing: neutral box packing, accessory remote control, charger. 3.5 two audio input lines.

## Key features. Interface function introduction:

- 1: MIC.PRI microphone priority: a single press;
- 2: Recording key: single press
- 3: Mode keys: one-touch function mode switch AUX / recording good content / FM / U disk / TF / Bluetooth /, long press for voice on / off;
- 4: a / rewind: press on a single, long press rewind (when playing with the U disk under the TF model only rewind function, FM mode, press and other semi-automatic station search mode is not):
- 5: Pause / Play: single press to pause / play, press the Chinese / English tone switch (single press of the FM auto search)
- 6: Next / Fast-forward: Press a single, long press fast forward; in the U disk player with TF model only fast forward function, press and semi-automatic mode when the FM station search mode no other).
- 7: power switch: O/OFF
- 8: MIC.VOL: microphone volume control;
- 9: ECHO: volume control;
- 10: VOLUME: master volume control;
- 11: CHAR/FULL: charging indicator, charging for the red light, full of blue lights;
- 12: 9V: charging interface;
- 13: MIC: microphone interface;
- 14: USB: disk interface;
- 15: TF CARD: TF Card interface;

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.