



kitsound.co.uk

ks™

KITSOUND

POCKETBOOM
WIRELESS
SPEAKER



Li-PO

Do not dispose of Lithium Polymer
batteries with general waste.
Please return it to battery recycling
collection point

JB. 3186 / Made in China. © KitSound™ 2014
Christchurch, Dorset. BH23 4FL

USER MANUAL




We are craftspeople. We are musicians. We are KitSound™

And we all commit ourselves to achieving one shared goal: Bringing people closer to their music. By truly understanding music we stay true to its craft. Pure, rich, incredible sound. We'll settle for nothing less.



At KS we believe your music deserves to be showcased on great quality products that don't cost the earth. We might not all share the same taste in music (the ferocious disputes on music forums prove that), but whether it's Irish folk, death metal or any number of obscure genres which seem to be multiplying by the minute, the artists responsible for connecting with you through their craft have bared their souls to do so. And we think that's worth celebrating.






Like the musicians we're honouring, we're obsessed with our craft; fine-tuning and tweaking our products to make sure we constantly deliver full-bodied, symphonic sound. So from a single note played on a piano, to the full impact of a bass guitar, you can rest assured that you'll always be doing justice to your music.



Box contents

- KS PocketBoom portable speaker
- Mini USB charge cable
- User manual


Functions

1. Hands-free button
2. ON/OFF switch
3. Microphone
4. Aux-in socket
5. Bluetooth pairing indicator light
6. Mini USB Port
7. Speaker
8. Radiator





Charging the battery for the first time




The unit has a built-in rechargeable lithium battery. Connect one end of the power cable to the mini USB port of the main unit and connect the other end to your PC or USB mains charger. The battery will start charging.

Note:

- It takes approx 1.5 hours to fully charge the battery
- A fully charged unit has approximately 3 hours of playback time

10


Bluetooth pairing

1. Switch the power button to the ON position. The Bluetooth indicator light will flash blue quickly.
 2. When you search for the speaker with your Bluetooth device, you should see 'PocketBoom'. Enter the password '0000' if requested.
 3. When pairing is successful, the Bluetooth indicator light will flash slowly.
 4. If no pairing occurs within 5 minutes, the unit will automatically enter standby mode.
- 

11



Hands-free



There is a hands-free button on the top of the unit. When your phone is paired with the unit, you can press and hold the hands-free button to call back the last answered phone number. During a phone conversation, you can short press the hands-free button to discontinue the conversation. Additionally, you can short press the hands-free button to answer an incoming call.

Aux-in


Use a 3.5 mm aux-in cable (not supplied) to connect your Bluetooth speaker through the aux-in socket at the bottom of the unit.

12

Note:

When you plug the aux-in cable into the aux-in socket, the current Bluetooth connection will disconnect. When you unplug the aux-in cable, the Bluetooth connection will resume.

Care and maintenance



Wipe the unit with a soft dry dust cloth. Do not use any wax, polish sprays or abrasive cleaners on it

Caution:


Never allow any water or other liquids to get inside the unit while cleaning.

13




Specifications

Bluetooth	V2.1 +EDR
Play time	up to 3 hours (at 80% volume)
Frequency response	100 Hz – 15 kHz
Battery type	rechargeable
Aux-in	3.5 mm



Troubleshooting

We hope you've now got all the information you need to get started, but if you're having problems with anything, please feel free to contact us at: support@kitsound.co.uk




We apologise for any inconvenience caused by minor inconsistencies in these instructions, which may occur as a result of product improvement and development.



FCC Statement:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.



This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radi or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

