Installation (!)


After you have programmed the Uni-Sensor, follow installation procedures below.

Important:


Each time the TPMS sensor is changed or disassembled, it is MANDATORY to replace the TPMS sensor washer, nut, screw, and valve core accessories (use only CUB service component kits designed for TPMS sensor) to ensure proper sealing.


Installation Procedure:

- 1. Insert sensor, metal valve stem and valve stem screw into wheel. Hold in place by hand. Loosely screw into place so sensor drop angle can be adjusted. From outside wheel, put on valve stem nut.
- 2. While holding sensor down against wheel bottom, hand tighten the nut. With torque wrench, tighten the nut to 4.0Nm.
- 3. Holding sensor down against wheel bottom, with torque wrench, tighten valve stem screw to 2.0Nm and place the plastic cap.









Clamp-In Assembly

Step 2

Step 3

Caution:

It is recommended to seek the service of a qualified technician. Pay special attention and follow all instructions to all cautions and warnings included in the shop manual. Failure to do so could result in failure of the vehicle's Tire Pressure Monitor System (TPMS) Sensors to function properly, or result in damage to the TPMS Sensor.

The PUR-sensor(Uni-Sensor) is blank software inside, be sure to program the sensor by CUB's sensor-AID or compatible tool for your specific motor vehicle make, model and year before installation. Only install programmed TPMS sensors to the application listed in the tool. Improper TPMS installation or the use of unauthorized TPMS Sensors will cause the failure of TPM system. Upon completion of installation, test the TPMS System following the original manufacturer's service guide to confirm proper installation. Check all installation procedures to ensure proper installation and retest. If the System continues to fail consult with CUB support or an authorized motor vehicle dealership.

These TPMS sensor assemblies are designed and manufactured to be operated in Original Equipment wheels and tires only. While using non-OE wheels/tires, the vehicle owner has responsibility to ensure that the TPMS is working correctly. Failure to ensure that the TPMS is working correctly can result in severe injury or death.

Warranty:

CUB warrants that the TPMS sensor shall be free from defects in workmanship and material during warranty period. CUB does not assume any liability in case of faulty, incorrect installation of the product, or by using other products causing TPMS sensor malfunction on the part of customer or user.

Always check our website for detail installation procedures, safety information and warranty policy.

http://www.cubautoparts.com/download_data.php?url=download/tpms_download4/& date=20140523132641 en.pdf

Product Name: Uni TPMS Sensor

Model: VS-62U009



FCC regulations

This tire pressure monitoring system has complied with Article 15 of the FCC regulatory requirements of the USA, but it is still needed to pay attention to the following two items:

- (1) Other harmful interferences may affect the system's normal operation.
- Abnormal operation may cause the system to fail.

Note

This system has been tested by instruments and complies with the digital Class B limits. According to the provisions of Article 15 of the FCC, these limits are designed to provide meaningful protection against occurrences of interfering signals in residential areas. Because these devices will generate radio frequency signals and, if not installed and used in accordance with the right way, they will produce some signal interference to radio communications; even if installed correctly we cannot guarantee that there will be no interference generated.

If this product will cause interference to radio or television frequencies, you can decide whether to turn off this product, or try the following solutions:

- Re-install or adjust the antenna.
- Increase the distance between the equipment and system.
- Change the position of the receiver and way of connection.

WARNING: Any modification or change of this system or hardware cannot be guaranteed for continuous user right.

IC Warnig:

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:

- (1) this device may not cause interference, and
- (2) this device mustaccept any interference, including interference that may cause undesired operation of the device.

Le présentappareilestconforme aux CNR d'Industrie Canada applicables aux appareils radioexempts de licence. L'exploitationestautorisée aux deux conditions suivantes :

- (1) l'appareil nedoit pas produire de brouillage, et
- (2) l'utilisateur de l'appareildoit accepter tout brouillageradioélectriquesubi, mêmesi le brouillageest susceptible d'encompromettre le fonctionnement.