



motorola
Bluetooth®
Stereo PC Adapter



MOTOSTART
Get connected in 4 quick steps.

D200

Motorola, Inc.
Consumer Advocacy Office
1307 East Algonquin Road
Schaumburg, IL 60196

www.hellomoto.com
1-877-MOTOBLU
1-888-390-6456 (TTY/TDD United States for hearing impaired)

Guide Number: 6809508A57-O

MOTOROLA and the Stylized M Logo are registered in the US Patent & Trademark Office. The use of wireless devices and their accessories may be prohibited or restricted in certain areas. Always obey the laws and regulations on the use of these products. The Bluetooth trademarks are owned by their proprietor and used by Motorola, Inc. under license. Microsoft and Windows Media are registered trademarks of Microsoft Corporation in the United States and/or other countries. Apple and iTunes are registered trademarks of Apple Computer, Inc., registered in the U.S. and other countries. RealNetworks and RealPlayer are registered trademarks of RealNetworks, Inc. Nullsoft and Winamp are registered trademarks of AOL LLC. Skype is a trademark of Skype Limited. All other product or service names are the property of their respective owners.

© Motorola, Inc. 2006.

BEFORE YOU BEGIN

Before using this product, read the Important Safety and Legal Information pamphlet and follow its instructions.

Take a moment before you get started to familiarize yourself with your new D200 Adapter.



Note: The D200 is a Class 1-capable Bluetooth device. Bluetooth features and Bluetooth Class 1 power levels are not allowed for outdoor operation in France. To avoid unlawful interference with radio signals, do not use the Bluetooth features in France unless you are indoors.

① PUT YOUR HEADPHONES/HEADSET IN PAIRING MODE

To use your adapter to connect your computer to your Bluetooth stereo headphones or Bluetooth handsfree (mono) headset, you must pair (link) your adapter with your Bluetooth device.

To do this, your headphones or headset must first be placed into pairing (discoverable) mode. On most Motorola Bluetooth stereo headphones and handsfree headsets, you simply press and hold the Call button until the indicator light turns on and remains steadily lit.

For details on placing your Bluetooth device into pairing mode, see your device's user's guide.

② PLUG IN ADAPTER AND PAIR WITH HEADPHONES/HEADSET

Your adapter is a plug-and-play device. For first time use, simply plug the adapter into a USB port on your computer. After a few moments, your adapter begins to search for your Bluetooth headphones or headset.

While searching, the indicator light flashes quickly until the adapter successfully finds and pairs with your Bluetooth device.

When your adapter and headphones or headset are successfully paired, the adapter's indicator light changes from flashing blue to steadily lit.

③ TEST AND USE STREAMING MUSIC

To confirm proper streaming music operation with your adapter and stereo headphones:

- 1 Place your headphones over your ears.
- 2 On your computer, play music from your music playing application. Ensure the application remains the active (top) window on your computer.

If your adapter and headphones are successfully paired and connected for streaming music, you will hear music on your headphones.

After successfully pairing and connecting your adapter and stereo headphones, you don't need to repeat these steps. For daily use, ensure that your adapter is plugged into your computer and that your headphones are turned ON.

④ TEST AND USE VOICE OVER IP CALLING

To confirm proper voice-over-IP (VoIP) calling operation with your adapter and stereo headphones or handsfree headset:

- 1 Place your headphones over your ears.
- 2 On your computer, make a call from your VoIP calling application.

If your adapter and headphones are successfully paired and connected for VoIP calling, you will hear ringing on your headphones or headset.

After successfully pairing and connecting your adapter and headphones or headset, you don't need to repeat these steps. For daily use, ensure that your adapter is plugged into a computer and that your headphone or headset is turned ON.

PAIRING WITH ADDITIONAL DEVICES

Your adapter stores pairing information for up to five Bluetooth devices. After pairing your adapter with your initial device (steps 1-4), you can subsequently pair (link) your adapter with an additional Bluetooth stereo headphone or handsfree (mono) headset as follows:

- 1 Place your headphone or headset device in pairing mode.
- 2 Press and hold the adapter's button for three seconds until the indicator light begins flashing quickly. The adapter drops the current connection (if active), and begins searching for your Bluetooth device.

Your adapter searches for discoverable Bluetooth devices for up to 2 minutes. If no device is found, your adapter enters an Idle state (indicator light not lit).

USING YOUR D200

See **Features and Functions Guide** on the reverse side for information on using your D200



TROUBLESHOOTING

My adapter does not find my headphones. Make sure your headphones are in pairing (discoverable) mode when your adapter is searching for your device.

My adapter did not find my previously paired headphones. Make sure your headphones are turned on before plugging in the adapter to ensure the adapter will find it.

My music playing application is playing music but I don't hear it through my headphones. If the music playing application was being used before the adapter was plugged into the computer, the application may need to be restarted.

Features and Functions Guide

D200 Bluetooth® Stereo PC Adapter


IMPORTANT:
Be sure to first follow the **MOTOSTART** Quick Start Guide on the reverse side of this guide to complete initial setup of your D200.

European Union Directives Conformance Statement



Hereby, Motorola declares that this product is in compliance with:

- The essential requirements and other relevant provisions of Directive 1999/5/EC.
- All other relevant EU Directives.



The above gives an example of a typical Product Approval Number.

You can view your product's Declaration of Conformity (DoC) to Directive 1999/5/EC (to R&TTE Directive) at www.motorola.com/rtte. To find your DoC, enter the product Approval Number from your product's label in the "Search" bar on the web site.

HOW YOUR ADAPTER OPERATES

When plugged into the USB port, your adapter automatically attempts to establish a wireless Bluetooth connection between your computer and the last connected headphone or headset. If unsuccessful, the adapter tries to connect to one of the other paired headphones or headsets stored in your adapter's memory.

If no connection can be established when plugged in, your adapter reverts to an Idle state until one of your paired devices is turned on and within range to establish a connection. You can also manually reattempt a connection to one of your paired devices by tapping (quick pressing) the adapter's button while in the Idle state.

Once a connection is established with your headphones or headset, audio and VoIP calls are routed between your computer and device over the Bluetooth link.

USING MULTIPLE DEVICES WITH YOUR ADAPTER

Although only one Bluetooth link is maintained between your computer and device, your adapter provides the ability to "shift" the connection between up to 5 different paired headphones or headsets.

To shift an active Bluetooth connection from one device to another paired device that is turned on, tap the adapter's button. Your adapter's indicator light flashes slowly to indicate searching mode, drops the active connection to the current device, and attempts a new connection with each of the other paired devices (one at a time). Once a new connection is established, the indicator light changes to steadily lit.

If attempts to shift the connection are unsuccessful, your adapter attempts to reestablish connection with the original device. If this connection cannot be made, your adapter reverts to Idle state.

WORKING WITH MUSIC PLAYING APPLICATIONS

When connected, your adapter streams music from your favorite music playing application to your Bluetooth stereo headphones (handsfree headsets do not support this feature).

While all music playing operations can be performed within the music application itself, you can also perform certain operations remotely from your Bluetooth stereo headphones when using popular music playing applications including:

- Microsoft® Windows Media® audio player
- Apple® iTunes® audio player
- RealNetworks® RealPlayer® audio player
- Nullsoft® Winamp® audio player

To perform operations remotely, your music playing application must be the currently active (top) application on your computer (not required for Windows Media Player). Also, your Bluetooth stereo headphones must support AVRCP profile.

The following remote music playing operations are supported by the adapter when listening to music from the listed applications:

- Stop/play/pause music
- Skip to next/previous track
- Increase/decrease music volume

Details on how to perform these operations are dependent on your Bluetooth headphones. See your device's user's guide for more information.

Use the following tips when using your adapter with your music playing application:

- When using the Winamp application, ensure Hotkeys are enabled. To do this, select **Options > Preferences > Global Hotkeys** and ensure the **Enabled** box is checked.

WORKING WITH VOIP CALLING APPLICATIONS

When connected, your adapter routes audio from your favorite voice-over-IP (VoIP) calling application to your Bluetooth stereo headphones or handsfree headset.

While all calling operations can be performed within the VoIP application itself, you can also perform certain operations remotely from your Bluetooth stereo headphones or handsfree headset when using the Skype™ application. The following remote calling operations are supported by the adapter when making and receiving VoIP calls using Skype:

- Answer/end a call
- Mute/unmute call audio
- Increase/decrease call volume

Details on how to perform these operations are dependent on your Bluetooth headphones or headset. See your device's user's guide for more information.

Use the following tips when using your adapter with your VoIP calling application:

- When using the Skype application, ensure Hotkeys are enabled. To do this, select **Tools > Options** and click **Hotkeys**. Ensure **Enable global hotkeys** is checked, **Answer call** is set to **Alt-PgUp**, and **Reject/Hang up call** is set to **Alt-PgDn**.

INDICATOR LIGHT

The indicator light provides information about your adapter's status when plugged into your computer.

Adapter Indicator	Status
On (steady)	Connected
Off	Idle (not connected)
Quick flash	Pairing mode
Slow flash	Shifting mode



MOTOROLA

intelligence everywhere™



***Important Safety and
Legal Information >***

Motorola, Inc.
Consumer Advocacy Office
1307 East Algonquin Road
Schaumburg, IL 60196
www.hellomoto.com

1-800-331-6456 (United States)

1-888-390-6456 (TTY/TDD United States for
hearing impaired)

1-800-461-4575 (Canada)

The use of wireless devices and their accessories
may be prohibited or restricted in certain areas.
Always obey the laws and regulations on the use
of these products.

MOTOROLA and the Stylized M Logo are
registered in the US Patent & Trademark Office.
All other product or service names are the
property of their respective owners.

© Motorola, Inc., 2005.

Manual Number: 6809494A55-0

The information contained in Motorola's user's guides is believed to be correct at the time of printing. Motorola reserves the right to change or modify any information or specifications without notice. The contents of Motorola's user manuals are provided "as is." Except as required by applicable law, no warranties of any kind, either express or implied, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose, are made in relation to the accuracy, reliability, or contents of this document.

Software Copyright Notice

The Motorola products described in this manual may include copyrighted Motorola and third-party software stored in semiconductor memories or other media. Laws in the United States and other countries preserve for Motorola and third-party software providers certain exclusive rights for copyrighted software, such as the exclusive rights to distribute or reproduce the copyrighted software. Accordingly, any copyrighted software

contained in the Motorola products may not be modified, reverse-engineered, distributed, or reproduced in any manner to the extent allowed by law. Furthermore, the purchase of the Motorola products shall not be deemed to grant either directly or by implication, estoppel, or otherwise, any license under the copyrights, patents, or patent applications of Motorola or any third-party software provider, except for the normal, non-exclusive, royalty-free license to use that arises by operation of law in the sale of a product.

Contents

Safety Information	6
Warranty	11
Export Law Assurances	22
Wireless Phone Safety Tips	23

Safety and General Information

IMPORTANT INFORMATION ON SAFE AND EFFICIENT OPERATION. READ THIS INFORMATION BEFORE USING YOUR DEVICE.

Users are not permitted to make changes or modify the device in any way. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. See 47 CFR Sec. 15.21.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. See 47 CFR Sec. 15.19(3).

Electromagnetic Interference/Compatibility

Note: Nearly every electronic device is susceptible to electromagnetic interference (EMI) if inadequately shielded, designed, or otherwise configured for electromagnetic compatibility.

Facilities

To avoid electromagnetic interference and/or compatibility conflicts, turn off your device in any facility where posted notices instruct you to do so. Hospitals or health care facilities may be using equipment that is sensitive to external RF energy.

Aircraft

When instructed to do so, turn off your device when on board an aircraft. Any use of a device must be in accordance with applicable regulations per airline crew instructions.

Medical Devices

Hearing Aids

Some devices may interfere with some hearing aids. In the event of such interference, you may want to consult with your hearing aid manufacturer to discuss alternatives.

Other Medical Devices

If you use any other personal medical device, consult the manufacturer of your device to determine if it is adequately shielded from RF energy. Your physician may be able to assist you in obtaining this information.

Industry Canada Notice to Users

Operation is subject to the following two conditions: (1) This device may not cause interference and (2) This device must accept any interference, including interference that may cause undesired operation of the device Ref IC RSS 210 Sec. 5.11. The term "IC:" before the

certification/registration number only signifies that registration was performed based on a Declaration of Conformity indicating that Industry Canada technical specifications were met. It does not imply that Industry Canada approved the equipment. See Ref IC Self-Marking 6(f) and RSP-100 Sec. 4.

FCC Notice to Users

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be

determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Motorola Limited Warranty for the United States and Canada

What Does this Warranty Cover?

Subject to the exclusions contained below, Motorola, Inc. warrants its telephones, pagers, messaging devices, and consumer and professional two-way radios (excluding commercial, government or industrial radios) that operate via Family Radio Service or General Mobile Radio Service, Motorola-branded or certified accessories sold for use with these Products ("Accessories") and Motorola software contained on CD-ROMs or other tangible media and sold for use with these Products ("Software") to be free from defects in materials and workmanship under normal consumer usage for

the period(s) outlined below. This limited warranty is a consumer's exclusive remedy, and applies as follows to new Motorola Products, Accessories and Software purchased by consumers in the United States or Canada, which are accompanied by this written warranty:

Products and Accessories

Products Covered	Length of Coverage
Products and Accessories as defined above, unless otherwise provided for below.	One (1) year from the date of purchase by the first consumer purchaser of the product unless otherwise provided for below.
Decorative Accessories and Cases. Decorative covers, bezels, PhoneWrap™ covers and cases.	Limited lifetime warranty for the lifetime of ownership by the first consumer purchaser of the product.

Products Covered	Length of Coverage
<p>Monaural Headsets. Ear buds and boom headsets that transmit mono sound through a wired connection.</p>	<p>Limited lifetime warranty for the lifetime of ownership by the first consumer purchaser of the product.</p>
<p>Consumer and Professional Two-Way Radio Accessories.</p>	<p>Ninety (90) days from the date of purchase by the first consumer purchaser of the product.</p>
<p>Products and Accessories that are Repaired or Replaced.</p>	<p>The balance of the original warranty or for ninety (90) days from the date returned to the consumer, whichever is longer.</p>

Exclusions

Normal Wear and Tear. Periodic maintenance, repair and replacement of parts due to normal wear and tear are excluded from coverage.

Batteries. Only batteries whose fully charged capacity falls below 80% of their rated capacity and batteries that leak are covered by this limited warranty.

Abuse & Misuse. Defects or damage that result from: (a) improper operation, storage, misuse or abuse, accident or neglect, such as physical damage (cracks, scratches, etc.) to the surface of the product resulting from misuse; (b) contact with liquid, water, rain, extreme humidity or heavy perspiration, sand, dirt or the like, extreme heat, or food; (c) use of the Products or Accessories for commercial purposes or subjecting the Product or Accessory to abnormal usage or conditions; or (d) other acts which are not the fault of Motorola, are excluded from coverage.

Use of Non-Motorola Products and Accessories. Defects or damage that result from the use of Non-Motorola branded or certified Products, Accessories, Software or other peripheral equipment are excluded from coverage.

Unauthorized Service or Modification. Defects or damages resulting from service, testing, adjustment, installation, maintenance, alteration, or modification in any way by someone other than Motorola, or its authorized service centers, are excluded from coverage.

Altered Products. Products or Accessories with (a) serial numbers or date tags that have been removed, altered or obliterated; (b) broken seals or that show evidence of tampering; (c) mismatched board serial numbers; or (d) nonconforming or non-Motorola housings, or parts, are excluded from coverage.

Communication Services. Defects, damages, or the failure of Products, Accessories or Software due to any communication service or

signal you may subscribe to or use with the Products Accessories or Software is excluded from coverage.

Software

Products Covered	Length of Coverage
Software. Applies only to physical defects in the media that embodies the copy of the software (e.g. CD-ROM, or floppy disk).	Ninety (90) days from the date of purchase.

Exclusions

Software Embodied in Physical Media. No warranty is made that the software will meet your requirements or will work in combination with any hardware or software applications provided by third parties, that the operation of the software products will be uninterrupted or error free, or that all defects in the software products will be corrected.

Software NOT Embodied in Physical Media.

Software that is not embodied in physical media (e.g. software that is downloaded from the internet), is provided “as is” and without warranty.

Who Is Covered?

This warranty extends only to the first consumer purchaser, and is not transferable.

What Will Motorola Do?

Motorola, at its option, will at no charge repair, replace or refund the purchase price of any Products, Accessories or Software that does not conform to this warranty. We may use functionally equivalent reconditioned/refurbished/pre-owned or new Products, Accessories or parts. No data, software or applications added to your Product, Accessory or Software, including but not limited to personal contacts, games and ringer tones, will be reinstalled. To avoid losing such data, software

and applications please create a back up prior to requesting service.

How to Obtain Warranty Service or Other Information

USA	Phones 1-800-331-6456 Pagers 1-800-548-9954 Two-Way Radios and Messaging Devices 1-800-353-2729
Canada	All Products 1-800-461-4575
TTY	1-888-390-6456
For Accessories and Software , please call the telephone number designated above for the product with which they are used.	

You will receive instructions on how to ship the Products, Accessories or Software, at your expense, to a Motorola Authorized Repair Center. To obtain service, you must include: (a) a copy of your receipt, bill of sale or other comparable proof of purchase; (b) a written description of the problem; (c) the name of your service provider, if applicable; (d) the name and location of the installation facility (if applicable) and, most importantly; (e) your address and telephone number.

What Other Limitations Are There?

ANY IMPLIED WARRANTIES, INCLUDING WITHOUT LIMITATION THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, SHALL BE LIMITED TO THE DURATION OF THIS LIMITED WARRANTY, OTHERWISE THE REPAIR, REPLACEMENT, OR REFUND AS PROVIDED UNDER THIS EXPRESS LIMITED WARRANTY IS

THE EXCLUSIVE REMEDY OF THE CONSUMER, AND IS PROVIDED IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED. IN NO EVENT SHALL MOTOROLA BE LIABLE, WHETHER IN CONTRACT OR TORT (INCLUDING NEGLIGENCE) FOR DAMAGES IN EXCESS OF THE PURCHASE PRICE OF THE PRODUCT, ACCESSORY OR SOFTWARE, OR FOR ANY INDIRECT, INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES OF ANY KIND, OR LOSS OF REVENUE OR PROFITS, LOSS OF BUSINESS, LOSS OF INFORMATION OR DATA, SOFTWARE OR APPLICATIONS OR OTHER FINANCIAL LOSS ARISING OUT OF OR IN CONNECTION WITH THE ABILITY OR INABILITY TO USE THE PRODUCTS, ACCESSORIES OR SOFTWARE TO THE FULL EXTENT THESE DAMAGES MAY BE DISCLAIMED BY LAW.

Some states and jurisdictions do not allow the limitation or exclusion of incidental or consequential damages, or limitation on the length of an implied warranty, so the above limitations or exclusions may not apply to

you. This warranty gives you specific legal rights, and you may also have other rights that vary from state to state or from one jurisdiction to another.

Laws in the United States and other countries preserve for Motorola certain exclusive rights for copyrighted Motorola software such as the exclusive rights to reproduce and distribute copies of the Motorola software. Motorola software may only be copied into, used in, and redistributed with, the Products associated with such Motorola software. No other use, including without limitation disassembly of such Motorola software or exercise of the exclusive rights reserved for Motorola, is permitted.

Export Law Assurances

This product is controlled under the export regulations of the United States of America and Canada. The Governments of the United States of America and Canada may restrict the exportation or re-exportation of this product to certain destinations. For further information contact the U.S. Department of Commerce or the Canadian Department of Foreign Affairs and International Trade.

Wireless Phone Safety Tips

Drive Safe, Call Smart SM

Check the laws and regulations on the use of wireless phones and their accessories in the areas where you drive. Always obey them. The use of these devices may be prohibited or restricted in certain areas. Contact www.motorola.com/callsmart for more information.

Your wireless phone lets you communicate by voice and data—almost anywhere, anytime, wherever wireless service is available and safe conditions allow. When driving a car, driving is your first responsibility. If you choose to use your wireless phone while driving, remember the following tips:

- **Get to know your Motorola wireless phone and its features such as speed dial and redial.** If available, these features help you to place your call without taking your attention off the road.
- **When available, use a handsfree device.** If possible, add an additional layer of convenience to your wireless phone with one of the many Motorola Original™ handsfree accessories available today.
- **Position your wireless phone within easy reach.** Be able to access your wireless phone without removing your eyes from the road. If you receive an incoming call at an inconvenient time, if possible, let your voice mail answer it for you.

- **Let the person you are speaking with know you are driving; if necessary, suspend the call in heavy traffic or hazardous weather conditions.** Rain, sleet, snow, ice, and even heavy traffic can be hazardous.
- **Do not take notes or look up phone numbers while driving.** Jotting down a “to do” list or going through your address book takes attention away from your primary responsibility—driving safely.
- **Dial sensibly and assess the traffic; if possible, place calls when your car is not moving or before pulling into traffic.** If you must make a call while moving, dial only a few numbers, check the road and your mirrors, then continue.

- **Do not engage in stressful or emotional conversations that may be distracting.** Make people you are talking with aware you are driving and suspend conversations that can divert your attention away from the road.
- **Use your wireless phone to call for help.** Dial 9-1-1 or other local emergency number in the case of fire, traffic accident, or medical emergencies.¹
- **Use your wireless phone to help others in emergencies.** If you see an auto accident, crime in progress, or other serious emergency where lives are in danger, call 9-1-1 or other local emergency number, as you would want others to do for you.¹

- **Call roadside assistance or a special non-emergency wireless assistance number when necessary.** If you see a broken-down vehicle posing no serious hazard, a broken traffic signal, a minor traffic accident where no one appears injured, or a vehicle you know to be stolen, call roadside assistance or other special non-emergency wireless number.¹

1. Wherever wireless phone service is available.

DRAFT

motorola.com