


Wireless

Entertainment Input Device



FEDERAL COMMUNICATIONS

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions : (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.



This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection. This equipment generates uses and can radiated radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in particular installation if this equipment dose cause harmful interference to radio or television, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures :

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician of help.

Shielded interface cables must be used in order to comply with emission limits. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate equipment.

IMPORTANT NOTE: To comply with the FCC RF exposure compliance requirements, no change to the antenna or the device is permitted. Any change to the antenna or the device could result in the device exceeding the RF exposure requirements and void user's authority to operate the device.


System Requirement

1. IBM-Compatible PC
2. Microsoft Windows ME/2000/XP
3. Available USB port

Install


1 Connect the receiver to your computer

- Please plug the USB Mini Receiver into a rectangular USB port on your computer.



2 Insert the batteries


- Insert two AA batteries into the back of the keyboard. Please note the correct direction of the batteries.



3 Connection keyboard



- Please press the connect button on the Mini Receiver. The LED on the receiver will begin flashing.

Connect Button





- Then gently press the connect button on the keyboard. The LED on the receiver will stop flashing immediately after the button has been pressed.

Connect Button




- Finally, gently press the "O. SENSOR" button to start the Optical Trackball. The device is now installed and ready to be used.

O. SENSOR button



4 Charge keyboard

- Prior to the first time usage, please fully charge the device. Use the Charge cable, and connect the device to the computer to charge the batteries inside the device (Please see Page-6 on Charge Keyboard). When the Charge LED is turned off, which means the charging process is finished, the charge cable may be unplugged, and the device is ready to be used.



Mouse Key And Optical Trackball

- Mouse keys are located on the upper left of the device with same functionalities as regular mouse keys. Optical Trackball is located on the upper right of the device. User can control the pointer's motion by rolling the optical trackball. Combining the mouse keys and the scroll wheel, it is just as convenient as using an actual mouse.

