

## **MOTION SENSOR Model PS-MT FCC ID: KUTPS10X**

### **1. INTRODUCTION**

The motion sensor model PS-MT is designed to monitor movement around your house. Once motion is detected, the receiver will beep and flash.

In this package, you should find a motion sensor and mounting accessories.

Please follow the instructions below to setup the motion sensor.

### **2. INSTALLATION**

- i) Remove the back cover on the motion sensor and insert one AA battery (not included) to the sensor as shown in the diagram.
- ii) After inserting the battery to the motion sensor and its LED will be on for 2 seconds. The motion sensor requires a warm up time of approx. 30 seconds before it can function properly. After powering up the motion sensor, face it to the wall where no motion will be detected.
- iii) After 30 seconds, the motion sensor is ready. Press and hold the learn button in the receiver unit, release the button when the receiver emits a beep. Select the zone location in the receiver, press the zone button [1 or 2 or 3 or 4] once on the receiver unit. The corresponding zone red LED on the receiver will flash.
- iv) Wave your hand or walk in front of the motion sensor, the receiver will emit a beep and the corresponding red LED on the receiver will stop flashing indicating it has learned the code from the sensor.

### **MOUNTING LOCATION**

Mount the motion sensor on the wall or ceiling with screws or double sided tape provided.

### **WALK TEST**

After mounting the sensor at the desired location, it is important to perform a walk test in order to determine if the sensor is detecting the things you want to detect.

You should walk in the area that you would like the sensor to monitor. The receiver will beep if the sensor detects your movement. If the receiver does not respond, adjust the mounting accordingly. Perform the walk test again after 20 seconds. Repeat this procedure until your motion is detected. There should be no movement in the detected area during the 20 seconds.

Perform walk test in the undesired area to ensure movement cannot be detected.

*Tips: The sensor should not face towards direct sunlight, placing near heat or clod producing devices (i.e. A/C or furnace vents, fans, ovens, heaters etc) that may cause false triggers.*

### **OPERATION**

When motion is detected in the monitored area, the motion sensor will send a signal to the receiver. It will beep and the corresponding zone red LED light will flash.

### **FCC**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

## **WARRANTY**

If, within one year from date of purchase, this product should become defective (except battery), due to faulty workmanship or materials, it will be repaired or replaced, without charge. Proof of purchase and a Return Authorization are required.

## **CUSTOMER SERVICE**

If you would like to order Skylink's products or have difficulty getting them to work or download information and user manual, please:

1. visit our FAQ section at [www.skylinkhome.com](http://www.skylinkhome.com), or
2. email us at [support@skylinkhome.com](mailto:support@skylinkhome.com), or
3. call our toll free at 1-800-304-1187 from Monday to Friday, 9 am to 5 pm EST.

17 Sheard Avenue, Brampton, Ontario, Canada L6Y 1J3  
©2014 SKYLINK GROUP



This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.