

***EXHIBIT C***

***User Manual***

# USB Mouse Manual

1. After plugging USB mouse in USB Root Hub(or Hub) when Windows 98 is active. Windows 98 found the USB mouse automatically then show “**Add New Hardware Wizard**” dialog, just click “**Next**” to continue.
2. The next dialog ask you do a choice select “**Search for the best driver for you device (Recommended)**” and click “**Next**”.
3. Windows 98 popup new dialog to ask you the selected locations to search for new drivers in its driver database . Please select “**CD\_ROM driver**” option, then click “**Next**” icon.
4. Click “**Next**” icon in next popup-dialog.
5. Wait for Windows 98 installing USB mouse driver.
6. Click “**Finish**” icon in last dialog, then Windows 98 will active USB mouse.

## User's Manual

Copyright All Rights Reserved  
Statement on CLASS B

Note: This equipment has been tested and found to comply with the limits for CLASS B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and if not installed and used in accordance with the instruction manual may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- \* Reorient or relocate the receiving antenna.
- \* Increase the separation between the equipment and receiver.
- \* Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- \* Consult the dealer or an experienced radio TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference.
- (2) this device must accept any interference received, including interference that may cause undesired operation.