



# Media Wireless Presenter

**User's Quick Guide**

© 2005 All Rights Reserved. The copyright is the property of its respective owners.

Class 2 Laser Product

#### **Federal Communications Commission (FCC) requirements, Part 15**

This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**CAUTION:** Any changes of modifications not expressly approved by the grantee of this device could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This product complies with 21 CFR, Chapter 1, Subchapter J at the date of manufactured. This Class B digital apparatus meets all requirements of the Canadian interference-causing equipment regulations.

**NOTE: THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THIS EQUIPMENT. SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.**

#### **CE Declaration Of Conformity**

Hereby, the manufacturer, declares that this Media Wireless Presenter is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

Essential requirements - Article 3

Protection requirements for health and safety - Article 3.1a

--Testing for electric safety according to EN 60950 has been conducted. These are considered relevant and sufficient.

Protection requirements for electromagnetic compatibility -Article 3.1b

--Testing for electromagnetic compatibility according to EN 301 489-1 and EN 301 489-3 has been conducted. These are considered relevant and sufficient.

Effective use of the radio spectrum -Article 3.2

--Testing for radio test suites according to EN 300 440-2 has been conducted. These are considered relevant and sufficient.

**CAUTION:** The batteries may explode or leak if they are improperly recharged, inserted, disposed in fire or mixed with used or different battery types.

**Congratulations on your purchase of the 2.4GHz Wireless Media Presenter featured with the unique Smart Link function. Please carefully read the User's Quick Guide to learn about the installation and the powerful functions of your new Wireless Media Presenter.**

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

## Contents of Package

- ✓ Wireless Media Presenter
- ✓ 2.4GHz Dongle
- ✓ Battery: AAA \* 1
- ✓ User's Quick Guide

## Install Hardware

- Install the Dongle
  - 1) Turn on the computer.
  - 2) Connect the USB dongle to the computer.
- Link the Presenter with the Dongle

### Note:


- **The max. operation distance is 6~8 meters. Please link the devices within the effective distance.**
- **The linkage period is 15 seconds. Once press the dongle's Link Button, please complete the presenter linkage process within the linkage period.**
  - 1) Place the batteries into the device.
  - 2) Press the ID Link Button on the dongle and the LED indicator will blink. There are 15 seconds for the presenter linkage.
  - 3) Press the ID Link Button of the presenter.
  - 4) The presenter is linked with the dongle and the dongle's LED indicator is off.
  - 5) The product designs with the unique Smart Link function. Once the linkage process is complete, you don't have to re-link the mouse even if you change batteries or restart the computer.
  - 6) If the presenter does not link with the receiver, please repeat Step 2~3.
  - 7) The 2.4GHz product features with 4 channels and there are 256 changeable IDs for each channel. If the selected channel or ID is interfered by other wireless-device users nearby, please change the Link ID by re-linkage the device immediately. The channel and the ID will automatically change.

- Presenter Control Mode  
Mode/ Button Definition:

- 1 — Start
- 2 — Previous Page
- 3 — Next Page
- 4 — Screen Dark / Light
- 5 — Scroll Page Up / Scroll Page Down
- 6 — N/A
- 7 — Presenter Mode: Red
- 8 — Link Button
- 9 — Power Switch
- 10 — Pointer Button

- Advanced Media Mode

You can play the presenter for controlling more media functions through the control switch. The control panel is described as below.



Mode / Button Definition:

- 1 — Play / Pause / Stop
- 2 — Previous Track
- 3 — Next Track
- 4 — N/A
- 5 — Scroll Volume Up / Scroll Volume Down
- 6 — Mute
- 7 — CD Mode: Green

## Notification

This equipment is intended for use in the following countries.

18 European Countries:

Austria, Belgium, Denmark, Finland, France, Germany, Greece, Iceland, Ireland, Italy, Luxembourg, Netherlands, Norway, Portugal, Spain, Sweden, Switzerland and United Kingdom.

## Caution!

Avoid direct or indirect (such as reflection) eye exposure to laser light!  
Keep out of the reach of children!

PMU-Z0400001 / MADE IN CHINA