### TROUBLESHOOTING

/		
	No power	Recharge your headphones using the included Micro USB charging cable.
	Music is not playing over Bluetooth®	Make sure your Bluetooth® device has A2DP profile. Check if both devices are paired and connected over Bluetooth®. Restart the headphones to reconnect your Bluetooth® device.
	Bluetooth <sup>®</sup> device will not reconnect with the earbuds	Navigate to your Bluetooth <sup>®</sup> settings menu on your Bluetooth <sup>®</sup> device, tap " ***** ," and select "Forget." Now follow the steps to pair your device again.

Battery Playback: Approx. 5 hrs\*

Charging Time: Approx. 2-3 hrs

\*Depends on individual use.

### Specifications:

Bluetooth® Version: 3.0 Wireless Range: Up to 30ft Battery Capacity: 300 mAh Driver Size: 40mm

## FCC Notice:

This device complies with Part 15 of the FCC Rules. Operation is subject to the two following conditions:

1. This device may not cause harmful interference.

2. This device must accept any interference received, including interference that may cause undesired operation.


#### Technical Support:

Please do not attempt to fix the product by yourself. If you are experiencing any problems with the product, please do not return it to the store you bought if from. You can contact our technical support representatives and they will assist you with any questions you might have. For assistance operating your product, please consult the User's Manual first, then feel free to contact. contact



OUTSIDE

## WIRELESS **BLUETOOTH®** HEADPHONES





password to connect to the earbuds,

. enter "0000"

# CHARGE IT:

• Plug the micro USB cable into the micro USB port on the bottom of the headphone, and connect the other end of the cable to either a computer USB port of to a USB-compatible car or wall charger. • A solid red LED light will appear when the headphones are charging, even while headphones are turned off. • When charging is complete, the LED indicator will turn off. · Charging time is approximately 2-3 hours\*.

## PAIR & CONNECT WITH A NEW DEVICE:


- With your headphones powered OFF, press & hold the "ひ▶II" button for 3-4 seconds until the LED light
- turns on The LED light will start to flash blue & red. Your headphones are ready to be paired.
- The LED light will start to flash blue & red. Your headphones are ready to be paired.
   On your Bluetooth®-enabled device, navigate to the Bluetooth® settings menu, turn on the Bluetooth® feature, and search for new devices.
   After a few seconds you will see "MERKURY-BTH92" listed.
   Tap this model to select it. The LED will begin to slowly blink blue, and the headphones will emit a tone to indicate that it has been successfully paired with your device.
   AUX-IN: The headphones will automatically switch to wired mode once you plug a 3.5mm cable into the autor into the advice.
- the aux jack on the headphone
- NOTE: You only need to pair your Bluetooth® device with the headphones once. NOTE: If your device asks for a password to connect to the headphones, enter "0000."

### PAUSE / PLAY MUSIC:

<ul> <li>Connect your device to the SYMPH'Z headphones via Bluetooth<sup>®</sup> (see "Pair &amp; Connect with a New Device")</li> <li>Open your favorite music app and press play.</li> </ul>	•
• Control the track & volume from your device, or using the in-line controls on the headphones • Press the " <b>()</b> ▶II " button once to play/pause music.	•
<ul> <li>Press the "+" or "-" button once to raise/lower the volume on the headphones. Press and hold to skip to the next/previous track.</li> </ul>	
<ul> <li>All audio, including music, games, videos, and notifications will be routed through the SYMPH'Z headphones.</li> </ul>	
NOTE: Volume on your device and on the headphones are controlled separately. NOTE: On-board controls will not work in wired mode.	
RECONNECT WITH YOUR DEVICE:	_
	Control the track & volume from your device, or using the in-line controls on the headphones Press the " Ů >II " button once to play/pause music. Press the " Ů >II " or " ⊥ Utton once to raise/lower the volume on the headphones. Press and hold to skip to the next/previous track. All audio, including music, games, videos, and notifications will be routed through the SYMPH'Z headphones. NOTE: Volume on your device and on the headphones are controlled separately. NOTE: On-board controls will not work in wired mode.

• Press & hold the "U►II" button on the SYMPH'Z headphones for 3-4 seconds. The headphones will automatically reconnect to the last Bluetooth<sup>®</sup> device they were connected If you have a previously paired device that does not auto-reconnect, navigate to the Bluetooth settings menu on your device, turn on the Bluetooth® feature, and select " " fr

your list of paired Bluetooth® devices. Press " 
" button to answer/end calls.



# FCC STATEMENT :

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) This device must accept any interference received, including interference that may cause undesired operation.

**Warning:** Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

# **RF** warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.