DO NOT USE LOW RESOLUTION PDF FILE FOR PRINTING. ONLY USE THE HIGH RESOLUTION AI FILE

这是一个低分辨率的PDF文件,绝对不能用来做印刷,只能用高分辨率的AI

MERKURY

MERKURY INNOVATIONS CONFIDENTIAL

FILE INFORMATION

DATE: 07/19/21

FACTORY: China Etech Groups Ltd.

MODEL NUMBER:

MI-S074B-250 (MANUAL)

PRINTER SPECIFICATIONS

FILE NAME: MI-S074B-250_Manual_071921_0L.ai

SCALE: 100%

SIZE: Trim: W 221mm x H 151mm PAPER STOCK: 80g Art Paper FINISH: Matt Lamination

INKS: 1/1 Grayscale

PRESS WORK / NOTES: Trim to size, score, fold,

& glue in specified areas. Trim

Score

DO NOT print Comments or Dielines.

Physical sample according to specs must be approved by MERKURY before proceeding to production.

CONTACT

MERKURY CHINA: Perry perry@merkuryinnovations.com.cn

COMMENTS (Internal reference only)

File created by Eileen

- Please include this manual in all packaging for MI-S074B-250
- Grayscale
- Double sided printing

 $\textbf{WARNING:} \ \textbf{Drilling, sawing, sanding or machining wood products can expose you to wood dust, a}$ substance known to the State of California to cause cancer. Avoid inhaling wood dust or use a dust mask or other safeguards for personal protection. For more information go to www.P65Warnings.ca.gov/wood.

This device complies with Part 15 of the FCC Rules. Operation is subject

- to the two following conditions:

 1. This device may not cause harmful interference. that may cause undesired operation.
- 2. This device must accept any interference received, including interference

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules, These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed. and used in accordance with the instructions, may cause harmful interference to radio communications. However there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
 Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.
FCC RF exposure statement:

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with inimum distance between 20cm the radiator your body.

Please do not attempt to fix the product by yourself. If you are experiencing any problems with the product, please do not return it to the store you bought it from. You can contact our technical support representatives and they will assist you with any questions you might have.

For assistance operating your product, please consult the User Manual first, then feel free to contact Merkury Innovations technical support

Merkury Innovations

45 Broadway, 3rd Floor

New York, New York 10006 www.merkurvinnovations.com

E-mail: support@merkuryinnovations.com

© 2021 Merkury Innovations, LLC. • 45 Broadway 3rd FL. New York, NY 10006 To explore our full selection of products, visit us at: www.merkuryinnovations.com
The Bluetooth word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The illustrated product and specifications may differ slightly from those supplied. All other trademarks and

trade names are those of their respective owners. Made in China

MERKURY



CHELSEA

WIRELESS SOUNDBAR & SPEAKER

User Manual for MI-S074R

IN THE BOX: Wireless Soundbar & Speaker Micro USB Cable, User Manual



IMPORTANT: PLEASE READ BEFORE USING THIS PRODUCT

Connecting to the Soundbar

USB & SD Card The Chelsea soundbar will automatically switch to this mode when a USB drive or SD card is detected. The Chelsea Soundbar recognizes and plays MP3 audio files automatically. Play, pause, skip, and repeat tracks with the on-board controls.

Aux Input

Simply connect a device to the soundbar via the aux input and play your music instantly, adjusting the volume on both the device and the speake

With the soundbar Bluetooth mode, go to your device's Bluetooth settings and search for new devices. In a moment, "Merkury S074B" should appear. Tap it and a sound should emit from the soundbar to indicate the device is connecte

NOTE: Soundbar will always auto-pair with your device as long as it is in range and your device's ooth is enabled

FM Mode

Always press and hold the scan button when using the radio for the first time. This will scan for nearby stations

Output Power: Dual 3W Frequency Response: 20Hz to 20KHz Dimensions (WxHxD) 420mm x 84mm x 67mm

Additional Connection Sources:

Power Information: Input: DC 5V

Battery Capacity: 1200mAH Music playing time: Up to 7 Hours* Charging time: 3-4 Hours* Talk Time: Up to 5 Hours'

Audio: 3.5mm AUX cable Power Source: Built-in rechargeable battery or via USB cable

Bluetooth® Information: Bluetooth® Specification: V5.0

Operating Distance: Up to 10m

*Depends on individual use and may be slightly more or less than the time specified.

Troubleshooting

Music is not playing

Recharge the soundbar using the included micro USB cable. Try using a different cable.

Bluetooth device will

Make sure your Bluetooth $^{\tiny{\scriptsize{\$}}}$ device has A2DP profile. Check if both devices are paired and connected over Bluetooth®. Restart the speaker

the speaker

to reconnect your Bluetooth® device. Navigate to your Bluetooth® settings menu on your Bluetooth® device, tap "Merkury S074B" and select "Forget." Now follow the steps to pair your device again.

Powering The Soundbar

- . Be sure the soundbar is fully charged using the included charging cable. The indicator light will glow red when charging and will turn off when charging is complete
- · The power switch is located on the back of the soundbar
- The speaker will emit a low chime when the battery is running low

Control



