

User Manual

H.264 4X CPU Cortex-A7
1080P Encoder 4X GPU Mali-400

H.265
1080P Encoder

SiME Smart Q TV BOX



SiME

Preface

Thanks very much for choosing our TV Box. In order to make it more convenient for you to use proficiently, we provide you with a user manual. Please read it carefully before using and properly keep it for reference.

Statements

We have made every effort to provide the most current information about the product.

We do not grant any guarantees as to the contents of the present instruction manual and disclaim any implied guarantees concerning market value or suitability for specific purposes.

The information contained here is an instruction intended to enable the correct usage and maintenance of the receiver.

We reserve the right to introduce amendments, changes or translations of the user manual without prior notification thereof. For this reason, we recommend you regularly visit our website in order to obtain the latest information.

FCC Notice

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help.
-
- Any changes or modifications not expressly approved by the party responsible for compliance could void the authority to operate equipment.
 - This device and its antenna must not be co-located or operating in conjunction with any other antenna or transmitter.
 - End-users and installers must be provided with antenna installation instructions and transmitter operating conditions for satisfying RF exposure compliance.
 - For product available in the USA/Canada market, only channel 1~11 can be operated. Selection of other channels is not possible

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.



Contents

Chapter 1 System Introduction	2
1.1 Key Features	2
1.2 Environment for System	2
1.3 Package Contents	2
Chapter 2 Remote Controller	3
2.1 Introduction of Remote	3
Chapter 3 System Connection	4
3.1 AV Connection.....	4
3.2 HDMI Connection	4
3.3 Startup	5
Chapter 4 Home	5
Chapter 5 My Apps	6
5.1 Browser	6
5.2 eHome Media Center	7
5.3 File Explorer	7
5.4 Download.....	8
5.5 Apk Installer.....	8
Chapter 6 Settings	9
6.1 Network	9
6.2 Display.....	10
6.3 OTA update Optional.....	11
6.4 Other.....	11
Chapter 7 Upgrade Steps	12
Chapter 8 Trouble Shooting	14
Chapter 9 Specification	15



Chapter 1 System Introduction

1.1 Key Features

- Support many kinds of IPTV and OTT TV programmes.
- Support FHD H.265, VC-1, H.264, MPEG-2 and many other formats such as MPEG-1, MPEG-2, MPEG-4, DIVX, REALMEDIA, VP9, VP8, MVC and so on.
- Video formats include hevc, avi, mpg, vob, rmvb, mkv, m2ts, ts and so on.
- Photo formats include JPEG, BMP and PNG up to 80M pixels.
- Audio formats include MP3, WMA, WAV, AC3, AAC and so on.
- Support SD/SDHC/MMC cards.
- Support four USB 2.0 host connectors with maximum output current of 1.5A/5V.
- Support standard RJ45 cable network connection and wireless network connection.
- Support infrared remote controller operation.

1.2 Environment for System

- Operation : Temperature limitation: 0--40°C; Humidity limitation: 20--80%.
- Storage: Temperature limitation: -20--50°C; Humidity limitation: 10--90%.


1.3 Package Contents













Accessories	Quantity
Power adaptor	1
Remote control	1
HDMI cable	1
User manual	1




Chapter 2 Remote Controller

2.1 Introduction of Remote





-  POWER: Press to standby.
-  MUTE: Press to turn down the volume.
-  MEDIA: Fast key to go to my recommend.
-  TV: Fast key to go to online video.
-  WEB: Press to enter the browser home page.
-  APP: Fast key to go to android application.
-  VOL+/-: Press to increase/decrease the volume.
-  Go to previous page or next page.
-  HOME: Fast key to go to back to main menu.
-  RETURN: Press to return back to previous menu.
-  MOUSE: Press to switch mouse mode or remote mode.
-  MENU: Press to choose function menu of corresponding application in video, music, photo and website.

-  Navigation: Press to navigate left/right/up/down. Press OK to confirm your choice.



Number keypad 0-9: Press to input Arabic number.


-  Backspace: Press to backspace the input.
-  Point keypad: Press to input point.



Chapter 3 System Connection

3.1 AV Connection

3.2 HDMI Connection





3.3 Startup

Turn on the TV box while indicator light is blue. Enter into main menu at about 30 seconds.



Chapter 4 Home

There are apps which you usually use.

You can add the apps according to your own preference.

Please tick the apps you need. Tick it again when you don't need it.






Chapter 5 My Apps

Move to “My Apps”, Press OK to enter in.

You can see icons referring to different function on the picture.



5.1 Browser

Move to “Browser”. Press OK to enter in.

It is a convenient way for you to go to your desired website.

Notice: Please go to the system setting to set the internet connection before entering into the website.





5.2 eHome Media Center

Move to “eHome Media Center ” icon, You can play all your prefer media here.




5.3 File Explorer

Move to “File Explorer”. Press OK to enter into the device list.

When inserting with USB device or SD/ SDHC/ MMC cards, the sign “Device is mounting” will be shown on the screen.


Here you can cut, copy, paste and move the files and folder between the local disk and external storage card.





5.4 Download

Move to “Downloads”. Press OK to enter in. You can check the status here when downloading APKs from the internet.




5.5 APK Installer

Move to “APK Installer”. Press OK to enter in.

You can install software by this app installer function. Please first download your desired software by APK formats from the computer to the USB. You will choose your desired device in order to scan the APKs.

Press OK to install your desired software.

After the installation finished, the software icon will be shown on the applications menu.






Chapter 6 Settings

6.1 Network

Wi-Fi


Select “Wi-Fi”, System will start scanning available Wi-Fi networks around you automatically.



Press OK to choose your Wi-Fi network and enter your password.

After authenticating IP address, when “connected” is shown, Wi-Fi is available now.

Notice: If Wi-Fi connection failed, please try again.





Ethernet:

Select "Ethernet" System will start scanning Ethernet automatically.

When the IP address appears, the Ethernet connected.



6.2 Display

Move to "Display".


Here you can set HDMI video output mode, turn on/off hide status bar, display position, choose the time of start screen saver.





6.3 OTA update Optional


If there is an update in server, you can choose to download it.
After upgrade is finished, system will restart automatically.



6.4 Other

See more TV Box information.

You can do system update and adjust more settings here.






Chapter 7 Upgrade Steps

7.1 Please unzip the upgrade package to the SD card .There will be three files in the root of the SD card as follow,

factory_update_param.aml (Some upgrade packages don't have this file)
xxx.zip (the upgrade package zip file)
recovery

7.2 Insert HDMI cable and SD card with the box.

(connect the other side of the HDMI cable to the TV HDMI port.)







7.3 Insert a stick into AV port.

There is a reset button inside AV port.
And keep pressing the button.

7.4 Insert power adaptor.

(still pressing the button)



7.5 You can stop pressing the reset button until you see the android robot. And use the remote to choose " apply update from EXT" → choose " Update from SD card" → Choose "xxx.zip (the upgrade package file)" and press OK.

7.6 You will see "--Install / SD card..." It means the box is updating.
After upgrade, you can see "Install from SD card complete "at the bottom.

7.7 Use remote to choose "reboot system now" and press OK
or plug the power adaptor again to reboot the box.

7.8 Finished upgrade. You can see the "Welcome" interface.

Tips:

You can check the build number in setting to confirm
You have updated the box successfully.



Chapter 8 Trouble Shooting

Under no circumstances should you try to repair the TV Box by yourself, as this will invalidate the warranty. Do not open the TV Box as there is a risk of electric shock. If a fault occurs, first check with points listed below before taking the TV Box for repair. If you are unable to remedy a problem by following hints, consult your dealer for help.

Problem	Solution
No power	<ul style="list-style-type: none"> -Check if the power adaptor is properly connected to the power and the TV Box. -Press the power on the remote controller to turn on the power.
No picture	<ul style="list-style-type: none"> -Reconnect with HDMI cable or AV cable. -Check if the TV is switched on.
No sound or distorted sound	<ul style="list-style-type: none"> -Adjust the volume. -Check that the speakers are connected correctly.
No audio or digital output	<ul style="list-style-type: none"> -Check the digital connections. -Check if your amplifier is set correctly.
The box does not respond to the Remote Control	<ul style="list-style-type: none"> -Aim the remote control directly at the sensor on the front of the TV Box. -Reduce the distance to the TV Box. -Replace the batteries in the remote control.
Player does not respond to some operating commands during playback	<ul style="list-style-type: none"> -Operations may not be permitted. Refer to the user manual. -Possibility of system halted, re-insert with power adaptor to restart.
No sound during movies playback	<ul style="list-style-type: none"> -The audio codec may not be supported by the TV Box. You can change to the supported audio on playing menu. -Check the volume.
The contents of the USB flash drive cannot be read	<ul style="list-style-type: none"> -The USB flash drive format is not compatible with the Box. -If one of the USB can not be read, please turn off the TV Box for 30seconds and restart the TV Box.
Slow operation of the USB flash drive	<ul style="list-style-type: none"> -Big file size or high resolution USB flash drive takes longer time to read and display on the TV screen.
No sound with HDMI connection	<ul style="list-style-type: none"> -Check the connection between the TV and the HDMI jack of box. -Check your TV system setup. -Check the volume.
The TV screen is blank and the player LED is blinking	<ul style="list-style-type: none"> -Turn off your TV Box, wait 30 seconds, turn it on again. -If under HDMI status, check if HDMI connection is correct or change another HDMI cable set the output resolution of this TV Box into 720p.



Chapter 9 Specification

Parameters Item	Android TV Box	
Main function	On-line video (IPTV and OTT TV programs)	Many IPTV programmes, all standard IPTV softwares and popular on-line video websites based on android system. (such as Youtube, Netflix, local satellite TVs, sports,finance,etc) It can also connect to your designated websites.
	Android applications	Support many applications from google play including web browser, google map,2D/3D games, P2P download, online video chat email and so on. Support mouse and keyboard ;Support FAT16, FAT32, NTFS file system.
	Full HD definition All formats	H.264/H.265 high definition decoding, support all formats
Video format	1080p/720p/480p multi-format decoding	MPEG1/MPEG2/MPEG4/VC-1/H. 264//H. 265 Real Video formats including avi, mpeg, vob, mkv, ts, m2ts, wmv, rm, rmvb suffixes and so on.
Photo format	Up to 80M pixels	JPG,BMG,PNG
Audio format	multi-audio format	MP3, WMA, WAV, MIDI, OGG, AC3, DTS(some formats need the support of the third party player software.)
Hardware configuration	Main chipset	Quad core Cortex A7
	GPU	Quad-core Mali-400
	Memory	Memory: 1GB-DDR3 8GB-FLASH (other capacity available.)
Input interface	Storage cards	SD/SDHC/MMC card; Voltage: 2.7- 3.3V
	USB interface	For way high speed USB 2.0 high speed, output current up to 1.5A/5V, connect with different kinds of mobile devices directly without additional power, Supports hot-plugging
	Internet interface	Standard RJ45 Internet interface. Support internal wireless Wi-Fi(some other models require additional adaptor)
Output interface	Audio	Coaxial digital audio output . L/R stereo output: standard 3.5mm earphone socket.
	Video	CVBS output (AV output),Standard 3.5mm earphone socket. HDMI interface: HDMI 1.4 standard interface.
Others	Remote distance	Effective distance is more than 6 meters.
	Dimension	118x118x27(mm)
	Weight	256g
Electric parameters	Video	Range: 1.0V+/-0.1V(75Ω overload); S/N 55dB
	Audio	Range: 2.0V+/-0.2V(10kΩ overload); S/N 85dB
	Electric power	Power supply: 5V DC; Current: 3A.

This specification will be modified if necessary without notice.



ANDROID

Product Name : SiME Smart Q

Model : SiME Q1