

# TYPO MIGHTY SPEAKER

Folded Booklet  
Each page is 70mm x 70mm

## FRONT

<p><b>Instructions of use</b></p> <p>Slide the Off/On switch on the speaker to the ON position. Press and hold the Bluetooth pairing button for 2 seconds. Tones will sound and the light will flash blue to indicate pairing attempt.</p> <p>Place your audio device in Bluetooth mode (look in the device's settings menu) and make it discoverable. 'Typo Mighty Speaker' should appear on your device. If 'Not Connected', 'Not Paired' or similar message appears, select 'Typo Mighty Speaker' to connect. If prompted for a password, enter '1234' on your device's keypad. Once paired, the light will glow solid blue and a confirmation beep will sound and you can then stream audio. If pairing is not successful, turn the power off on the speaker and repeat the pairing procedure.</p> <p>To listen to Bluetooth audio in the future, slide the Off/On switch on the speaker to the ON position. The light will flash blue slowly as the speaker attempts to auto-link with the last previously linked unit in range (30 feet). Control Bluetooth audio from your device.</p>	<p>Remember to turn off the speaker and your device after listening.</p> <p>NOTE: When unit is charging, the blue light will appear solid red.</p> <p><b>Maintenance</b></p> <p>Place the unit on a level surface away from sources of direct sunlight or excessive heat.</p> <p>Protect your furniture when placing your unit on a natural wood and lacquered finish. A cloth or other protective material should be placed between it and the furniture.</p> <p>Clean your unit with a soft cloth moistened only with mild soap and water</p> <p>Do not use strong cleaning agents such as thinner or similar materials as they can damage the surface of the unit.</p> <p>NOTE:</p> <p>When not in use, turn speaker OFF to save battery power. Unit will automatically power down after 5 minutes if no audio or bluetooth stream is detected (you will then need to slide the power switch to OFF position.</p>	<p><b>WARNING</b></p> <p>Lithium batteries can explode or cause burns if disassembled, shorted, recharged, exposed to water, fire, or high temperature &amp; not handled appropriately</p> <p>Do not place loose batteries in a pocket, purse, or other container containing metal objects, do not mix with used or other battery types, or store with hazardous or combustible materials.</p> <p>Store in a cool, dry, ventilated area.</p> <p>Follow applicable laws and regulations for transport and disposal.</p> <p>When used in the directed manner, this unit has been designed and manufactured to ensure your personal safety. However, improper use can result in potential electrical shock or fire hazards. Please read all safety and operating instructions carefully before installation and use, and keep these instructions handy for future reference.</p>
---	--	---

70mm

210mm

## BACK

<p>Take note of following warnings;</p> <p>Charge before use – must be fully charged.</p> <p>Keep away from water, all liquids, moisture and heat.</p> <p>This product must be well ventilated at all times.</p> <p>This product should only be connected to a power supply as described in instructions.</p> <p>This product should only be cleaned as recommended.</p> <p>Keep unplugged from power source if not being used for a period of time.</p> <p>If damaged this can only be repaired by a professional technician.</p> <p>The speaker is powered by a rechargeable battery in the speaker. Make sure to charge the speaker before using.</p> <p>Connect the micro-USB plug to the USB Charging jack on the speaker.</p> <p>Connect the larger USB plug to USB AX adaptor or to a powered USB port, such as that on a computer. The light on the speaker will turn to solid red while charging and turn off when fully charged. When the red light flashes or if you start to notice sound distortion at higher volumes, it's time to recharge the battery.</p>	<p><b>FCC Information</b></p> <p>FCC Radiation Exposure Statement</p> <p>This equipment complies with the FCC RF radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.</p> <p>This device complies with Part 15 of the FCC Rules, operation is subject to the following two conditions:</p> <p>(1) This device may not cause harmful interference, and</p> <p>(2) this device must accept any interference received, including interference that may cause undesired operation.</p> <p>Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.</p> <p>NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of FCC Rules.</p>	<p>These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.</p> <p>However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures;</p> <p>Reorient or relocate the receiving antenna.</p> <p>Increase the separation between the equipment and receiver.</p> <p>Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.</p> <p>Consult the dealer or an experienced radio/TV technician for help.</p>
--	--	---