
Bluetooth Dongle User's Manual BTD-1000



The unit is a wireless comfort Bluetooth USB dongle for PC and some USB host feature supporting phones. When the Bluetooth is commonly using for wireless connection, people prefer to use Bluetooth headsets with mobile phones and PC. Nowadays, most of desktop PC and laptop computers have built-in Bluetooth and different types of Bluetooth products can be paired. With internal Bluetooth, most of audio streaming can be delivered via A2DP profile. By this reason, lots of softphone users have some difficulty to use Bluetooth headsets. To overcome this difficulties and limitation, customized Bluetooth dongle is developed.

Features

- Bluetooth Version 4.2, with improved data transfer, security and connectivity.
- Pairing Button
- LED status indication
- USB Type A Interface
- Frequency: 2402 ~ 2480MHz
- RF Power: 8.52dBm/Max
- Operating Temperature :40



| 번호 | 명칭 | | | |
|----|--|--|--|--|
| 1 | USB TYPE-A CONNECTOR | | | |
| 2 | TACT SWITCH (REGISTRATION) | | | |
| 3 | TOP CASE (SILK PRINTING, LED LIGHTING 표시됨) | | | |
| 4 | BOTTOM CASE | | | |

The BTD-1000 dongle is Bluetooth host device. So, Bluetooth headset can be paired with it. To make pairing, press the pairing button for a while. When it is on pairing mode, pupple LED is blinking. If pairing is success, the blue LED stops blinking and turns on.

| STATUS | LED COLOR AND ACTION | | | |
|----------------------|------------------------------------|--|--|--|
| POWER ON | RED LED ON | | | |
| REGISTRATION MODE | RED & BLUE TOGGLE -> 1MIN TIME OUT | | | |
| HEADSET REGISTRATION | BLUE LED ON | | | |
| A2DP MODE | PUPPLE LED ON&OFF | | | |
| A2DP PLAY | PUPPLE LED ON&OFF | | | |
| HFP MODE | BLUE LED ON&OFF (FAST) | | | |
| NOT USED MODE | - | | | |

HFP

A2DP

AVCRP

 $\bullet \quad \mbox{ Dial the number on the mobile phone and press the answer button briefly.}$

Model Name: BTD-1000

Manufacturer: DASAN ELECTRON CO., LTD

Address: #307, Plant 1 Dong, Kyunggitechno Park 705, Haean-ro, Sangnok-gu,

Ansan-si, Gyeonggi-do Ansan-si South Korea

Contact: andychoi@headsetkorea.com



| 1 | Αľ | BE | BG | HR | CY | CZ | DK | IS |
|---|----|----|----|----|----|----|----|----|
| | EE | FI | FR | DE | EL | HU | IE | LI |
| | IT | LV | LT | LU | MT | NL | PL | NO |
| | PT | RO | SK | SI | ES | SE | UK | CH |

WARRANTY CARD

| Mr./Mrs./Miss/Co. |
|-------------------|
| Telephone No. |
| Address |
| |
| Model No. |
| Brand |
| Serial No. |
| Invoice No. |
| Dealer |
| Date of Purchase |

Note: THIS WARRANTY CARD WILL BE VOID IF IT IS NOT MAILED BACK TO OUR COMPANY WITHIN 10 DAYS FROM DATE OF PURCHASE, WARRANTY CONDITIONS (PLEASE SEE OVERLEAF) This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- —Increase the separation between the equipment and receiver.
- —Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- —Consult the dealer or an experienced radio/TV technician for help.

RF Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.