

SOUND CYLINDER - MANUAL ARTWORK BCPA\_ART\_0600 SCALE 1:1



PANTONE PROCESS BLACK C

PRINT 2 SIDES






print front

Tablet **Bluetooth** Speaker Haut-parleur 🐉 Bluetooth

# WHAT'S IN THE BOX

Sound Cylinder™ Sound Cylinder™



3.5mm stereo cable câble audio stéréo de 3,5 mm

**CONTENU DE L'EMBALLAGE** 



USB to micro-USB cable câble USB vers micro-USB




user guide guide d'utilisation

#### **GETTING STARTED** PREMIERS PAS









#### POSITION YOUR SOUND CYLINDER™ POSITIONNEZ VOTRE SOUND CYLINDER™

horizontal/vertical i à l'horizontale/à la verticale





kickstand béquille

portable



standalone par lui-même






#### **CHARGING** CHARGER

plug micro-USB connector into Sound Cylinder™





I plug USB connector into power adapter or USB input

I branchez l'autre extrémité du câble USB à l'adaptateur d'alimentation ou à un port USB

### CONNECT CONNECTER




allumez le haut-parleur



search for Bluetooth® devices on your tablet and select "Defintive Cyl."

recherchez les appareils *Bluetooth®* à proximité sur votre tablette et sélectionnez "Definitive Cyl."



print back

#### **CONTROLS** COMMANDES


power on/off (hold for 1 second) allumer ou éteindre (maintenez le bouton enfoncé pendant 1 seconde)



increase volume augmenter le volume

decrease volume

diminuer le volume



## **LED STATUS** DÉL D'ÉTAT

₿ blue - on l bleue - allumé



red flashing - low battery

I rouge clignotant - pile faible



rouge - recharge en cours



three flashes - maximum volume trois flashs - volume maximum



#### **SPECIFICATIONS SPÉCIFICATIONS**

| battery life: 10 hours autonomie: 10 heures



drivers: two 25mm drivers, one 43mm bass driver I haut-parleurs: deux unités de 25 mm, un haut-parleur de basse de 43 mm



output: 85dBA @ 1m sortie: 85 dBA @ 1 m

power: 2W x 2, 4W x 1 alimentation: 2 W x 2, 4 W x 1

Bluetooth® range: 10m (33') portée Bluetooth®: 10 m (33 pi)

weight: 320g 1 poids: 320 g

ac adapter: 5VDC @1A adaptateur d'alimentation: 5 V c.c. @ 1 A

#### FOR MORE INFORMATION **POUR PLUS DE RENSEIGNEMENTS**







Definitive Technology 11433 Cronridge Dr. Owings Mills, MD 21117

CANADA-INDUSTRY CANADA (IC): Operation is subject to the following two conditions: 1) This device may not cause interference and 2) This device must accept any interference, including interference that may cause undesired operation of the device. This device complies with RSS-210 of the Industry Canada Rules. Operation is subject to the following two conditions: (1) This device ma not cause harmful interference, and (2) this device must accept any interference received including interference that may cause undesired operation. Radiation Exposure Statement: This equipment complies with IC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

FEDERAL COMMUNICATION COMMISSION INTERFERENCE STATEMENT: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipmen generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. I this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures: Reorient or relocate the receiving antenna. - Increase the separation between the equipment and receiver. - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. onsult the dealer or an experienced radio/TV technician for help. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device mus received, including interference that may cause undesired operation. FCC CAUTION: Any changes or modifications not expressly approved by the p void the user's authority to operate this equipment. FCC RADIATION EXPOSURE

**STATEMENT:** This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in IMPORTANT SAFETY INSTRUCTIONS: 1. Read these Instructions, 2. Keep these Instructions, 3. Heed all Warnings, 4, Follow all instructions, 5. Do not use this apparatus near water, 6. Clean only with a dry cloth, 7. Do not block any of the ventilation openings sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat. 9. Do not defeat the safety purpose of the polarized or grounding — type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. When the provided plug does not fit into your outlet, consult an electrician for electrician for replacement of the obsolete outlet. 10. Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus. 11. Only use attachments / accessories specified by the manufacturer. 12. Use only with a cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart / apparatus combination to avoid injury from tip-over. 13. Unplug this apparatus during lightning storms or when unused for long periods of time. 14. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been

damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rai poisture, does not operate normally, or has been dropped. **DÉCLARATION DE** Canada applicable aux appareils radio exempts de licence. Son fonctionnement est sujet aux deux conditions suivantes: [1] le dispositif ne doit pas produire de brouillage préjudiciable, et (2) ce dispositif doit accepter tout brouillage reçu, y compris un brouillage voquer un fonctionnement indésirable. Déclaration d'exposition aux radiations: Cet équipement est conforme aux limites d'exposition aux

ement non contrôlé. Cet équipement doit être installé et utilisé RENSEIGNEMENTS IMPORTANTS CONCERNANT LA SÉCURITÉ: 1. lisez ntivement ces instructions. 2. Gardez ces instructions à proximité. 3. Portez attention tous les avertissements, 4, Suivez attentivement toutes les instructions, 5, N'utilisez pas cet bloquez pas les orifices de ventilation. Installez l'appareil selon les instructions du fabricant bouches de chaleur, les cuisinières ou autres appareils (y compris les amplificateurs) dégageant de la chaleur. 9. Nemodifiez pas le connecteur polarisé ou la mise à la terre. Un connecteur polarisé est doté de deux lames, dont une plus large que l'autre. Un connecteur avecmise à la terre est doté de deux broches semblables et d'une troisième différente. Cette lame large, ou troisième broche, est conçue pour assurer votre sécurité. Si la fiche ne rentre pas dans votre prise de courant, consultez un électricien afin de faire remplacer la prise désuète. 10. Protégez le cordon d'alimentation pour éviter de marcher dessus ou de le pincer, particulièrement aux points des fiches, des prises et de sortie de l'appareil. 11. Utilisez uniquement des accessoires ou options recommandés par le fabricant. 12. Utilise uniquement un meuble sur roulettes, un support, un trépied, une étagère ou une table d'un singues de la commandé par le fabricant ou vendu[e] avec l'appareil. Si vous utilisez un meuble sur roulettes, veillez à le déplacer avec précaution afin d'éviter tout accident corporel si l'équipement se renversait. 13. Débranchez l'appareil pendant les orages ou s'il doit rester inutilisé pendant une période prolongée. 14. Pour toute réparation, faites appel à un quelconque manière; par exemple si le cordon d'alimentation est endommagé, si des liquides ou des objets sont tombés dans l'appareil, si l'appareil a été exposé à la pluie ou à l'humidité, si l'appareil ne fonctionne pas correctement ou s'il a été échappé sur le sol.













©2012 Definitive Technology