


## INSTALLATION

1. Connect 1st String Light set to be controlled by dimmer to End Plug (A)
2. Connect additional string lights to 1st string light.
3. Plug in Prong Plug - C to power outlet.
4. Turn on or Dim Lights accordingly.



- A- End Plug Connector
- B- Adapter
- C- Prong Plug

# Honeywell

## EN LED String Light Dimming Kit with Remote Control

### Use and Care Guide

Read and Save this Instructions Before Use


Model: ST-ILDIM-1

### International Development Company

899 Henrietta Creek Rd.  
Roanoke, TX 76262 USA  
Toll-free: 1-877-723-0723

Made in China  
© 2019 IDC, all rights reserved.  
The Honeywell Trademark is used under license  
from Honeywell International Inc.  
Honeywell International Inc. makes no  
representations or warranties with respect  
to this product. This product is manufactured for  
International Development Company.

# Honeywell



## SAFETY INFORMATION

**WARNING:** These products may represent a possible shock or fire hazard if improperly installed or attached in any way.

Products should be installed in accordance with these instructions, current electrical codes, and/or the current National Electric Code (NEC). Use this product only with its attached plug-in power cord. Any other power cord or feed may damage the fixture.

**WARNINGS: READ ALL INSTRUCTIONS BEFORE YOU START:**

**CAUTION-**To reduce risk of fire, electric shock, or injury to persons, pay close attention to this manual and stay within its guidelines when using this product.

**WARNING-RISK OF ELECTRIC SHOCK!** Disconnect power at source prior to connecting cord set, lamping (installing light bulbs into sockets), re-lamping or servicing in any way.

**WARNING-RISK OF ELECTRIC SHOCK!!** Do not operate light string with any open sockets. Make sure each socket has a bulb securely fastened before connecting to a power source.

**WARNING-RISK OF FIRE!! DO NOT OVERLOAD SOCKETS OR LIGHT STRING!!** DO NOT exceed the maximum number of connected strings or total feet (and sockets) listed in the table below.

**WARNING-RISK OF ELECTRIC SHOCK!!** For outdoor string lights, do NOT connect cord set to light strings during rain or other inclement weather conditions. Connect Dimming Kit to string lights only during dry and calm weather conditions.


## PARTS AND SPECIFICATIONS



AA: Screw (2)



BB: Wall Anchors (2)




CC: Bracket (1)



DD: Remote Control (1)



FF: A23 Battery (1)




EE: Dimmer Kit (1)

## REMOTE CONTROL OPERATING

### USING THE REMOTE CONTROL:

The radio frequency handheld remote is battery operated (one A23 battery, included). This remote operates within 88.5ft (27m) of the dimming kit. Do not install dimming kit with string light more than 88.5ft (27m) away from the intended location of remote control use.

**Note:** The working temperature for the remote control is -20 °C -40 °C (-4F-104F).



Power On/Power Off

Increase Brightness

Decrease Brightness

Candle Scene

**FCC:** This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

\*\*\*\*\*

**NOTES:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

## INSTALL BATTERY



- Remove the battery cover.
- Place a A23 battery into the battery compartment aligning polarity (+)(-) as indicated
- Return battery cover.

**Note:** When using the remote control for the first time, check that the battery is in place.



Battery Cover

**⚠ WARNING:** Do not dispose batteries in municipal waste stream or by fire as batteries may explode. Do not open, short circuit, or mutilate batteries. Dispose of batteries in accordance with Local, State, and Federal regulations. Do not mix old and new batteries. Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel cadmium or nickel hydride) batteries with lithium batteries.