



HOME AUTOMATION HUB

Box Contents:

- 1—Home Automation Hub
- 1—Power Supply
- 1—Remote Control with 2 AA Batteries
- 1—HDMI Cable

SAGEbyHughes.com

SAGE
by HUGHES
SECURITY & HOME AUTOMATION

HOME AUTOMATION HUB

Integrate with a variety of Sage-approved devices, including door and window sensors, cameras, thermostats, motion sensors, wall switches, lights, locks, and more.

SAGE Approved

SAGE makes security and home automation simple, conveniently putting control of your home on your TV and mobile devices!

Getting Started

- 1 Disconnect your existing AV source (e.g., satellite, cable) from the TV, and connect it to the HDMI In port on the SAGE Hub's back panel.
- 2 Using the included HDMI cable, connect the HDMI cable from the HDMI Out port on the SAGE Hub's back panel to your TV.
- 3 Plug the power adapter into a wall outlet not controlled by a wall switch. SAGE Hub powers on.

4 Insert the batteries into the SAGE remote, using the diagram inside the case to ensure the batteries are positioned correctly.

5 Follow the on-screen instructions to pair the remote, complete set-up, and install the devices included in your kit.

For additional information go to SAGEbyHughes.com

SAGE
by HUGHES
SECURITY & HOME AUTOMATION

Works with most tablets and mobile devices and is available on:

Download on the **App Store** or **GET IT ON Google play**

Visit SAGEbyHughes.com for updated browser support, hardware, operating system and network bandwidth requirements.

Video quality is dependent on network devices and conditions.

SAGE and Hughes are trademarks of EchoStar Technologies L.L.C. or its affiliates.

SAGE
by HUGHES
SECURITY & HOME AUTOMATION

Works with most tablets and mobile devices and is available on:

Download on the **App Store** or **GET IT ON Google play**

Visit SAGEbyHughes.com for updated browser support, hardware, operating system and network bandwidth requirements.

Video quality is dependent on network devices and conditions.

SAGE and Hughes are trademarks of EchoStar Technologies L.L.C. or its affiliates.

Getting Started

- 1 Read these instructions.
- 2 Keep these instructions.
- 3 Do not use this product near water or where spilled liquids are likely.
- 4 Clean only with a dry cloth.
- 5 Do not block any ventilation openings.
- 6 The power supply must be readily accessible so that the product can be easily disconnected from the AC power.
- 7 Do not place any objects on top of the product.
- 8 The product contains a compartment for rechargeable batteries. Before inserting or replacing batteries unplug the product from the power supply.
- 9 Use only AA NiMH type rechargeable batteries in this product.
- 10 Never insert AA alkaline or lithium batteries into the product.
- 11 Do not expose batteries to excessive heat or fire.
- 12 Dispose of used batteries at a retail recycling drop off in accordance with local codes.
- 13 Use only the provided power supply with this product. Unplug the power supply by gripping the case not the cord.
- 14 Do not place the product inside an enclosure without proper ventilation.
- 15 Do not exceed a maximum ambient operating temperature of 113°F.

CAUTION: Risk of explosion if battery is replaced by an incorrect type. Dispose of used batteries according to the instructions.

Consignes de Sécurité importantes

1. Lisez ces consignes.
2. Conservez ces consignes.
3. Ne laissez pas l'appareil à proximité d'eau ou dans des endroits où le déversement de liquides est fréquent.
4. Nettoyez l'appareil avec un chiffon sec uniquement.
5. Ne bloquez pas les orifices d'aération.
6. La prise électrique doit être facilement accessible afin que le produit puisse être aisément débranché de l'alimentation secteur.
7. Ne placez pas d'objets sur le produit.
8. Ce produit possède un emplacement pour batteries rechargeables. Avant d'insérer ou de remplacer les batteries, débranchez le produit de la prise électrique.
9. Pour ce produit, utilisez uniquement des batteries rechargeables de type AA NiMH.
10. N'exposez jamais les batteries à une chaleur excessive ou au feu.
11. N'insérez jamais les batteries alcalines ou lithium dans ce produit.
12. Recyclez les batteries usagées au point de recyclage agréé, conformément aux normes locales.
13. Utilisez uniquement la prise électrique fournie avec le produit. Débranchez la prise électrique en saisissant par le fil et non pas le câble.
14. Ne placez pas le produit dans un endroit clos sans une ventilation adéquate.
15. Ne dépassez pas la température ambiante maximale de fonctionnement de 45°C.

ATTENTION: Il y a danger d'explosion si l'on remplace incorrectement la batterie. Mettre au rebut les batteries usagées conformément aux instructions du fabricant.

Federal Communications Commission and IC Notices

This Class B digital apparatus complies with Canadian ICES-003. Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

This device complies with Part 15 of the FCC Rules and with Industry Canada license-exempt RSS standards. Operation is subject to the following two conditions:

1. this device may not cause harmful interference, and
2. this device must accept any interference received, including interference that may cause undesired operation.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

1. l'appareil ne doit pas produire de brouillage,
- et
2. l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by following one or more of the following measures:

1. Reorient or relocate the receiving antenna.
2. Increase the separation between the equipment and receiver.
3. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
4. Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications to this device may void your authority to operate this equipment. Device must be installed at least 20cm (8 inches) from typical person locations per FCC RF Exposure guidelines.

Operation in the band 5150-5250 MHz is only for indoor use to reduce the potential for harmful interference to co-channel mobile satellite systems. Les dispositifs fonctionnant dans la bande 5150-5250 MHz sont réservés uniquement pour une utilisation à l'intérieur afin de réduire les risques de brouillage interférentiel aux systèmes de satellites mobiles utilisant les mêmes canaux.

IC Antenna Notice

Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum gain approved for this transmitter by Industry Canada. To reduce potential interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication.

Avis d'Industrie Canada sur les antennes

Conformément à la réglementation d'Industrie Canada, le présent émetteur radio peut fonctionner avec une antenne d'un type et d'un gain maximal (ou inférieur) approuvés pour l'émetteur par Industrie Canada. Dans le but de réduire les risques de brouillage interférentiel à l'endroit des utilisateurs, il faut choisir le type d'antenne et son gain de sorte que la puissance isotrope rayonnée équivalente (p.i.r.e.) ne dépasse pas l'intensité nécessaire à l'établissement d'une communication satisfaisante.

Limited Warranty

A 12-month Limited Warranty covers this SAGE kit. Limited Warranty details are available at: SAGEbyHughes.com/warranty

To view customer agreement, go to SAGEbyHughes.com/customer-agreement

Security Alerts and Alerts from your SAGE Home Automation system

Security Alerts and Alerts from your SAGE Home Automation system

Consignes de sécurité et alertes de votre système d'automatisation à domicile SAGE

Security Alerts and Alerts from your SAGE Home Automation system

Consignes de sécurité et alertes de votre système d'automatisation à domicile SAGE

Security Alerts and Alerts from your SAGE Home Automation system

Consignes de sécurité et alertes de votre système d'automatisation à domicile SAGE

Security Alerts and Alerts from your SAGE Home Automation system

Security Alerts and Alerts from your SAGE Home Automation system

Consignes de sécurité et alertes de votre système d'automatisation à domicile SAGE

Security Alerts and Alerts from your SAGE Home Automation system

Consignes de sécurité et alertes de votre système d'automatisation à domicile SAGE

TITLE
ART, BOX, STANDALONE SAGE HUB (US)

DWG. NO **207137** REV **01**

DRAWN **Jason Walker** DATE **02/19/15**

SCALE: 1:1 SHEET 1 of 1

NOTES
SEE PRINT SPEC FOR ADDITIONAL PRINTING REQUIREMENTS.