#### **1** Confirmation of the use of the environment

1) Home security cameras use the environment to have a wireless router, and can access the Internet in real time

2) Support IE browser, Safiri browser, Chrome browser, Firefox browser, Opera browser, etc.;

3) Support for mobile phones: Android (Android4.0 or more, CPU frequency 1GHz above),

IOS (5 or more)

#### 2, Installation and configuration

Step 1: connect the device to the power supply

Step 2: Download and install hand monitoring software

1) .In the Android (Android Market) or apple (APPStore) search for HomeC to download;

2) .Mobile phone monitoring software to get the mobile phone monitoring software to download.







3. After installation, pls connect your mobile with Wifi and run the software, then register an account by click "Regrister" button.

hom	<u>e</u> c
R 13316870488	
Password	
Register	Retrieve
Login	Ē
Visitor Log	gin



You may register by using your mobile or email, the following is taking mobile register for example:



Input mobile No., then click" verification code", then you will get the code, then click " Next".

4. After finishing reinstate, pls login by using the account we reinstated, shown as follows:



#### 5. After login, pls add the camera



A. : Click "+" as below

B.: Select "SMART ADD"

C: Type your wifi password



D: It will search your cameras automatically, pls wait for 100% processing. Then click the searched camera to finish adding camera operation.





Buttons in the GUI function instruction:

Rotate your mobile, it will shift to full screen:





## Motion detection alarm setting:



$\langle\!$	Device Manage		
<b>P</b>	System Management	>	
E	Alarm Settings	>	
	Time Zone	>	
6	Net Settings	>	
<b>::</b>	Link Settings	>	
ä	Storage Management	>	
C	Version	>	
			Click "Alarm settings"
China China	Telecom  図   参 璽 <i>求 奈 灣</i> Alarm Settings	::: 🖬 💶 16:29	
	Alert	Ø	
Enabl video	e this function, your phone can re picture or message.	ceive the alert	
-st	Motion Detection	ø	
nabl bjec	e this function, the equipment suc t is detected, will be prompted to a	h as moving alarm.	
Ť	Safeguard time scale	All Day >	
/ou c	an choose a suitable time scale to	receive alert.	
-	Motion Detection Sensitivity	>	
Motic	n detection sensitivity adjustable.		
40	Startup the alarm sound		
lf alar when	m sound is turned off, the device alarming.	will not sound	
(ه)	Wireless alarm device		
Can q	uickly set up wireless devices		

If you need other functions, you may select accordingly.

Mobile alarming receiver setting:

China Te	elecom 🖻 🛛 🛛 🕸 🗷 🕫 🕵 🕌 16	5:20
	More	
	13316870488	
<b>;;;</b> ]	System Information	>
	Function Setting	
i	About Software	>
	Quit	
8		
My Dev	nce message media More	Click "MORE", Select "Function Setting"
China To	elecom 🗟 🗹 🛛 🛛 🕸 🗷 🎜 💭 16	5:20
$(\leftarrow)$	Function Setting	
ľ	Alarming Configuration	>
oQ)	Viewing Mode(Single Device)	
Î	Scene Graph	
mtu	MTU Setting	>
8	Auto Login	
		Select "Alarming Configuration"



Select and initiate the need function, "Alarm

Information Delivery" must be selected, or cannot get the alarming by mobile(Pls keep your mobile network in good condition

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.

-Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.

RF exposure statement

the min. operating distance between users and device is 20cm.