

FCC INFORMATION:
 This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.


FCC WARNING:
 This equipment may generate or use radio frequency energy. Changes or modifications to this equipment may cause harmful interference unless the modifications are expressly approved in the instruction manual. Modifications not authorized by the manufacturer may void user's authority to operate this device.
 This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

POWER SOURCE

Recharging the battery
 The unit has a built-in DC 3.7V, Li-polymer rechargeable battery, recharge as follows:
 1. Connect the speaker to a computer or any USB charger using the supplied connection cable.
 -Connect the Micro USB plug from the supplied connection cable to the Micro USB port on the speaker.
 -Connect the full size USB plug to the USB port on a computer or any USB charger with DC 5V, 300mA (or more than 300mA) output.
 2. While charging, the Charging Indicator light on the bottom of the speaker will illuminate. When charging is complete, the light will turn off.

Notes:
 Your battery will last longer if you follow these simple guidelines for charging and storing.
 A. For charging the first time, charge it at least 10 hours.
 B. Recharge and store the unit within the temperature range of 5°C-35°C (40°F-95°F)
 C. Do not over charge (longer than 24 hours). Excessive charging may shorten the battery life.
 D. Battery life naturally shortens slowly over time.
 E. The rechargeable battery incorporated in this product is not user replaceable.

OPERATION



- Location of Controls:**
- 1 — : Skip Backward/Volume Down Button
 - 2 ► : Play/Pause Button
 - 3 + : Skip Forward/Volume Up Button
 - 4 ↓ : Built-in Microphone
 - 5 : Micro USB Port (For charge and AUX in only)
 - 6 : Power ON/OFF Switch
 - 7 : Indications (Bottom of unit)
 - 8 : Cover: Please be sure to open the cover before powering the unit ON/OFF or before making connections.

OPERATION

BT (Bluetooth) mode
 The first time you use the speaker or pair it to a new Bluetooth device, please follow these instructions:
 1. Slide the Power ON/OFF switch to the ON position. The indicator on the bottom of the speaker will light up and blink.
 2. Power on the external Bluetooth Device and enter searching mode. Begin pairing by following the on-screen instructions from the external Bluetooth device. After pairing, the indicator on the bottom of the speaker will stop blinking.

Notes:
 -When pairing this speaker to your Bluetooth Device, you will need to select BT pairing name "STICKY DUDE"
 -You may also need to enter the pairing code "0000"

Normal Operation After Pairing:
 1. Turn on the Bluetooth function of the external Bluetooth device.
 2. Slide the Power ON/OFF switch to the ON position. The indicator on the bottom of the speaker will light up and blink. Wait until the unit is paired with the external Bluetooth Device (this will take a few seconds and you will know it's complete when the indicator light stops blinking).

3. Now you're ready to play your music!

OPERATION

4. During Playback:
 ● Press and hold the "-" or "+" Buttons to adjust volume level.
 ● Press the "►" button to pause; press again to resume normal playback.
 ● Press and release the "-" or "+" Button repeatedly to skip tracks.
 5. If the unit is paired to Cell Phone:
 When you receive an incoming call while listening to music, press the ► button to pause the music and answer the call. When your call is complete, press the ► button to end the call and resume the music.
 6. When finished listening, slide the Power ON/OFF Switch to OFF position to shut off the unit.

AUX Mode
 1. Connect the 3.5mm stereo jack from the included connection cable to the AUX out/Line Out/Phone jack on the external audio player. Connect the Micro USB plug from the included connection cable to the Micro USB port on the speaker.
 2. Slide the Power ON/OFF switch to the ON position. The indicator on the bottom of the speaker will light up. Now your music will play.
 3. To adjust the volume, use the volume controls on the connected external audio player. The volume +/- buttons on the speaker will not work when you're in AUX Mode.

SPECIFICATION

4. When finished listening, slide the Power ON/OFF Switch to OFF position.
IMPORTANT:
 If the Micro USB plug from the included connection cable was inserted into the Micro USB port on the speaker, the Bluetooth function will cut off automatically. Unplug this cable before using the Bluetooth function.

Specification:
 Power source: --- Built-in DC 3.7V, Li-polymer rechargeable battery. Recharge by DC 5V, 300mA from Computer or USB charger through Micro USB port (Computer and USB Charger not included).
 Audio Power: ----- 1.75W (RMS)
 Speaker Impedance: ----- 4Ω, 3W

Note: The specifications are subject to change without notice.

Accessories:
 1x User's Manual
 1x Charging and Audio Connections Cable