


# HF-391 Instruction manual

## Introduction:

Please read below before your using.



- ① LINE IN    ② CHARGE    ③ Warning LED    ④ Power ON/OFF  
⑤ Headset OUT    ⑥ “-” quickly press : volumce decrease/long press :last song    ⑦ “+” quickly press : play、 stop、 answer calls、 hang up/long press : start to pair agian    ⑧ quickly press: volumce increase/long press : next song    ⑨ MIC

## Operation:

- 1.switch the “Power on/off”button on, you can hear the warning sounds “hello” which means in pairing mode.
2. 1.Active your pnone's Bluetoon function and the enter Bluetooth device's searching mode, find out “Quadpod” device and start pairing.
- 3.successfully connected., you can hear the warning sounds “Your d evice is connected”, and now you can play music/talk on phone/teleconference.
- 4.when the power of battery is less than 10%, you will hear another sounds “Battery low” , and please charge it in time.
5. switch off the “Power on/ off” button, you will find the device is turned off and said “Goodbye” .

## LINE In manual:

- 1.switch the “power on /off ”, connect the 3.5mm line-in cable to your audio source and the other port to the speaker “IN”.
- 2.start playing music. ()

## charging :


to charge , connect the USB cable directly to a laptop or mains USB to your speaker , the Micro USB connected into the “CHARGE” hole. The LED will turn red whilst charging

## Headphone connected

it is able to connect with the headphone too when connect the 3.5 line-in cable to your headphone and the other port into the “OUT” hole

## See from Blow drawing

charging/LINE IN / LINE OUT



Technical details:

- Power supplier:DC5V---1A
- Output power:10W(1khz,THD3%)
- Frequency: 120HZ---15000HZ
- Speaker:OD40mm (4 OHM 3W\*2)+OD32mm(4OHM3W\*2)
- effective distance: ≤10m
- Li-ion:3.7V 40 mm X 30 mm X 16mm (1000mA)
- full charing: 3 hours

- Playing : 50% volumce ≥6 hours
- S/N: ≥65dB
- Bluetooth version : Bluetooth 4.0
- APT X audio processing

**FCC NOTE :**

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. □ □

THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV  
INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS OR CHANGE  
TO THIS EQUIPMENT. SUCH MODIFICATIONS OR CHANGE COULD VOID AND  
CHANGE ANTENNA WHICH THE MANUFACTURER PROVIDES.  
IT IS THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF exposure guidelines, this equipment should be installed and operated with a minimum distance of 20cm between the radiator and your body.