USER MANUAL

1 Main Parameters

Product Name: R/C Construction Trucks

Item No.: E519-003

Material: plastic and electronic components

Batteries: Car battery: 1pc of 4. 8V AA rechargeable battery

Remote controller battery: 2pcs of 1. 5V AA batteries



- 1.Open the battery cover of remote controller as the Fig 2A showed, inserts 2pcs of 1.5V AA batteries and then screws the cover.
- Open the cover under the truck by screwdriver, inserts 1pc of 4.8V AA rechargeable battery as the correct polarity, and then screw the cover. (Fig 2B)


4.8V

battery pack

4 to 5 hours.

Forward





3 Basic Operation and Functions

Please confirm the batteries of remote controller and car have been installed as the correct polarity, and then turn the switch to ON. Be make sure the truck and the remote controller are the same channel. (Fig 3A)

1.Turn ON/OFF

 Press the ON/OFF key, there will be a start-up sound. To press the key again after starting, the truck would be turned off with a sound of DI. (Fig 3B)

2.Horn Key

- Press the Horn Key after starting the truck, the truck would emit a simulated sound.
 3.Forward/backward
- To push the Left Trigger ahead/back, the truck would go forward/backward; when forward, the lights on front and back would be lighted on; backward, the lights would be flashed (turn off when in a mute station) (Fig 3C)


4. Turn Left/Right

 To push the Left Trigger forward/backward, and Right Trigger turns left/right, the truck would turn left/right

The lights on left would be flashed when turn left the same of right lights when turn right. (Fig 3D)

5.Loading & Unloading

 After starting, press the Up (Down) key, the bucket would be rise (falled) slowly; at the same time, the front and back lights would be lighted on with the mechanical sound. There would be the TATA sound at the zenith or nadir for clutch protection. (Fig 3E)



Double E

battery

ndicator

Notice: first charging requires

8 hours, future charging requires

Fig 2C

4 Advanced Function

1.Mute Switch

 After starting the truck, to press the Horn Key for a long time, the truck would turn in a mute condition.
To press the Horn Key again, it could be turned in to the sound station.

2.DEMO Function

 To press the DEMO key, the truck could operate a series of the functions automatically; to exit the functions through pressing any keys.

3. Programme Function

 To press the Programme Key after starting until the indicator turning to red, there would be the state of Program.

Fig 3E

4. Auto OFF


- Without receiving any remote controlled signals after starting, the truck would auto off in 50 seconds. When turn off, the truck would with a sound of DI and at a standby stations
 5.Athletics Function
- There are A/B/C three channels on the remote controller and truck, so more than two players could play together through choosing different channel.

5 Recharging

Notice: please push the power switch to OFF if not be used for a long time. Please take out of the batteries from the remote controller and truck for storing to avoid weeping.

6 Notice

- 1.Don't play the toy on the road, select a safe place for operation to avoid dangerous.
- 2.Play the toy in water may cause short circuit damage. Please use the dry cloth to clean the car.
- 3.If abnormal speed or reaction, it maybe because of insufficient battery power, please recharge the battery.
- 4. The batteries should be charged under adult supervision. Please use the batteries recommended.
- 5. Please install the battery in a correct polarity.
- 6.Do not mix new and old batteries together, short-circuited.
- 7.Please charge the battery before initial use.
- 8.Don't break the antenna to prevent injury.
- 9.Please check the plug case and other units of charge regularly to make sure that it is not broken. Don't use again if you find abnormality of the charger.
- 10.Please do not connect the product to different performance power.



This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help.

Frequency bands: 2402MHz to 2480MHz

Maximum output power: 2DBm

Manufacturer: Doubleeagle Industry (China) Limited.

Address: Xingda Industrial Park, Chenghai

District, Shantou City, Guangdong Province, China.

Importer: JAMARA e.K.

Address: Inh. Manuel Natterer

Am Lauerb ü hl 5 - DE-88317 Aichstetten

CHOKING HAZARD-small parts, not for children under 3 years. Specifications colors and contents may vary from illustrations.



