

# Quick User Guide

## Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

## CAUTION STATEMENT

### FCC Radiation Exposure Statement:

To assure continued compliance, (example - use only shielded interface cables when connecting to computer or peripheral devices). Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

## INSTALLATION PROCEDURES

### Installing the Driver Under Windows 98

1. Plug the Wireless USB Adapter into the USB port of a notebook or desktop PC.
2. The Add New Hardware Wizard indicates that Windows have recognized a new hardware device.
3. Instruct the Wizard to search for the best driver for your device.
4. Insert the Driver CD into your CD-ROM drive.
5. Specify the location of the drivers.
6. Click the Next button when Windows is ready to install the driver.
7. A dialog will inform you that the installation is complete.

### Installing the Driver Under Windows 2000

1. Plug the Wireless USB Adapter into the USB port of a notebook or desktop PC.
2. The Found New Hardware Wizard indicates that Windows have recognized a new hardware device.
3. Instruct the Wizard to search for a suitable driver for your device.
4. Insert the Driver CD into your CD-ROM drive.
5. Specify the location of the drivers.
6. Click the Next button when Windows have located the driver.
7. Windows may display the message "Digital Signature Not Found". Ignore it by clicking "Yes".
8. A dialog will inform you that the installation is complete.

### Installing the Driver Under Windows ME

1. Plug the Wireless USB Adapter into the USB port of a notebook or desktop PC.
2. The Add New Hardware Wizard indicates that Windows have recognized a new hardware device.
3. Instruct the Wizard to search for the location of the driver for your device.
4. Insert the Driver CD into your CD-ROM drive.
5. Specify the location of the drivers.
6. Click the Next button when Windows is ready to install the driver.
7. A dialog will inform you that the installation is complete.

# CONFIGURATION AND MONITOR



## How to Install the Configuration and Monitor Utility

1. Find the setup.exe program in the "Config\_Utility" folder on the installation CD.
2. Execute the program setup.exe to do the installation.
3. Run the Configuration and Monitor Utility under **Start -> Program -> Wireless 802.11 USB Utility -> Configuration & Monitor Utility.**


## Using the Configuration and Monitor Utility

The configuration and monitor utility appears as an icon on the system tray of Windows every time the Wireless USB Adapter is running.


1. Double-click the icon on the system tray of Windows.
2. The Configuration and Monitor screen is shown below.
3. The Statistics screen is shown below.




4. The Site Survey screen is shown below.




5. The Encryption screen is shown below.



6. The Advanced screen is shown below.



7. The Version screen is shown below.




## How to Uninstall the Configuration and Monitor Application

Go to **Start -> Programs -> Wireless 802.11 USB -> Uninstall.**

# FIRMWARE UPGRADE UTILITY

How to do firmware upgrade

1. Go to **Start -> Programs -> Wireless 802.11 USB -> Firmware Upgrade Utility**
2. The Window of Firmware Upgrade Utility will appear.



3. Click the Upgrade button. An open file dialog appears. Open the \*.rom file which contains the new firmware.
4. Once the upgrade procedure has been completed successfully, the device will be working with the new firmware.