 A Phoenix Mecano Company	Issue Department: Bedding Division	Date:	2025-2-10
	System Instruction	Author:	Alexandria
Instruction of RF7220		Edition:	1.1
		Page 1 of 5	

Instruction of RF7220




Figure 1 button of remote Item

1.1 M1 button 1


Press the M1 button, and the bed will move to the M1 position. Hold the M1 button for 5 seconds until the backlight blinks, and the control box will set the current position as the M1 position.

1.2 M2 button 2

Press the M2 button, and the bed will move to the M2 position. Hold the M2 button for 5 seconds until the backlight blinks, and the control box will set the current position as the M2 position.

1.3 AntiSnore button 3

Press the ANTI SNORE button, and the bed will move to the ANTI SNORE position.

 <small>A Phoenix Mecano Company</small>	Issue Department: Bedding Division	Date:	2025-2-10
	System Instruction	Author:	Alexandria
Instruction of RF7220		Edition:	1.1
		Page 2 of 5	

1.4 zeroG button 4

Press the zeroG button, and the bed will move to the zeroG position. Hold the zeroG button for 5 seconds until the backlight blinks, and the control box will set the current position as the zeroG position.

1.5 HEAD UP button 5

Hold the button to extend the head actuator. Release the button to stop the actuator.

1.6 FOOT UP button 6

Hold the button to extend the foot actuator. Release the button to stop the actuator.

1.7 M3 OUT button 7

Hold the button to extend the lumbar actuator. Release the button to stop the actuator.

1.8 HEAD+FOOT UP button 8

Hold the button to extend both the head and foot actuators simultaneously. Release the button to stop the actuators.

1.9 HEAD DOWN button 9

Hold the button to retract the head actuator. Release the button to stop the actuator.

1.10 FOOT DOWN button 10

Hold the button to retract the foot actuator. Release the button to stop the actuator.

1.11 M3 IN button 11


Hold the button to retract the lumbar actuator. Release the button to stop the actuator.

1.12 HEAD+FOOT DOWN button 12

Hold the button to retract both the head and foot actuators simultaneously. Release the button to stop the actuators.

1.13 MASSAGE WAVE button 13

When the massage function is activated, press the button to cycle through the massage modes.

 A Phoenix Mecano Company	Issue Department: Bedding Division	Date:	2025-2-10
	System Instruction	Author:	Alexandria
Instruction of RF7220		Edition:	1.1
		Page 3 of 5	

1.14 MASSAGE TIMER button 14

When the massage function is activated, press the button to switch the massage duration (10-20-30min-Off).

1.15 MASSAGE INTENSITY button 15

Press the button to cycle through the massage intensity levels.

1.16 MASSAGE STOP ALL button 16

Press this button to turn off the massage function.

1.17 FLAT button 17

Press this button to recline the bed to a flat position.

1.18 UBB button 18

Press this button to turn the RGB light strip on or off.

1.19 M4 OUT button 19

Press and hold this button to extend the tilt actuator; release the button to stop the actuator.

1.20 M4 IN button 20

Press and hold this button to retract the tilt actuator; release the button to stop the actuator.

1.21 UBB COLOR button 21

When the light strip is on, press this button to cycle through the colors of the light strip.


1.22 UBB BRIGHTNESS button 22

When the light strip is on, press this button to cycle through the brightness levels of the light strip.

Other functions.


zero G+flat

Press and hold the zeroG+flat buttons for 5 seconds until the backlight flashes, and the control box will restore the memory positions to the factory settings.

	Issue Department: Bedding Division	Date:	2025-2-10
	System Instruction	Author:	Alexandria
Instruction of RF7220		Edition:	1.1
		Page 4 of 5	

UBB BRIGHTNESS + UBB COLOR

Press and hold this combination of buttons, and the backlight will flash indicating that the remote control has entered the pairing mode. When the backlight remains steadily lit, it signifies a successful pairing. If the backlight turns off, it indicates that the pairing has failed.

 A Phoenix Mecano Company	Issue Department: Bedding Division	Date:	2025-2-10
	System Instruction	Author:	Alexandria
Instruction of RF7220		Edition:	1.1
		Page 5 of 5	

FCC:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This

Equipment generates,uses and can radiate radio frequency energy and,if not installed and used in accordance with the instructions,may cause harmful interference to radio communications.However,there is no guarantee that interference will not occur in a Particular installation.If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

ISED RSS Warning:

This device complies with Innovation,Science and Economic Development Canada licenceexempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'ISED applicables aux appareils radioexempts de licence.

L'exploitation est autorisée aux deux conditions suivantes:

- (1) l'appareil ne doit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.