


he power bank capacity 4400MAH, mutti function Bluetooth speaker power ban elf timer function can be achieved self timer at any time, with back light source an be customized LOGO, with over charge protection, over discharge protection hort circuit protection, to ensure the user's safety

Accessories included

2: Instructions



Accessory Name

A speaker mesh B LED LOGO C discharge port D sucker

1:when power unful,green lamp flashing when full discharge,green lamp off 2:Led will be flashing during discharging and will when totally discharging

Charge for portable device

Step 2:Connect connecter to the output (A)



Charge for charger

Step 1: Connect the Micro cable to the recharge port(B) Step 2 : Connect the other end of the micro cable to USB port



Power bank function

- 2. search bluetooth named "BTPB001" after boot
- 3, after searched , press match , when success , it could play musi-



Note: connected to Android, as with selfie function phone input cannot be used if you want to input method

Power cannot insolate, not in wet place, not charge by high voltage not falling


Quick start guide portable charger



be power bank capacity 4400MAH, multi-function Bluetooth speaker power ban of timer function can be achieved self timer at any time, with back light source n be customized LOGO, with over charge protection, over discharge print circuit protection, to ensure the user's safety

Accessories included

- 2: Instructions



Accessory Name

A speaker mesh B LED LOGO C discharge port D sucker E. Bluetooth buttory'self time button . F charging port . G speaker

1:when power unful,green lamp flashing when full discharge,green lamp off 2:Led will be flashing during discharging and will when totally discharging

Charge for portable device



Charge for charger

Step 1: Connect the Micro cable to the recharge port(B)



Power bank function

- 3. after searched press match, when success, it could play music

- 4. Selfie-timer



Note: connected to Android, as with selfle function, phone input cannot be used if you want to use a phone input method, step. Settings. > bluetooth> shut the input, then you can use the input method

Power cannot insolate, not in wet place, not charge by high voltage not falling

Quick start guide portable charger




escription is power bank capacity 4400MAH, multi function Blueboth speaker power bank to power bank capacity 4400MAH, multi function Blueboth speaker power bank the function can be achieved self timer at any time, with back light source in be customized LOGO, with over charge protection, over discharge protection cort circuit protection, to emsure the user's safety

Accessories included

2: Instructions


Learn more about our charger



Accessory Name

A speaker mesh B LED LOGO C discharge port D sucker E. Bluetooth button/self time button. F charging port. G:speake

1:when power unful,green lamp flashing when full discharge,green lamp off 2:Led will be flashing during discharging and will when totally discharging 3:LED on/off in turn ench 10 mins



Step 1: Connect the Micro cable to the recharge port(B)



Power bank function

- 3, after searched , press match , when success , it could play music



Note: connected to Android, as with selfie function, phone input cannot be input method

Power cannot insolate, not in wet place, not charge by high voltage not falling

Quick start guide portable charger






he power bank capacity 4400MAH, multi function Bluebodh speaker power ban left timer function can be achieved self timer at any time, with back light source an be customized LOGO, with over charge protection, over discharge protection hort circuit protection, to ensure the user's safety

Accessories included

2: Instructions

Learn more about our charger



Accessory Name

mesh B LED LOGO C discharge p

when power unful, green lamp flashing when full discharge, green lamp off 2:Led will be flashing during discharging and will when totally discharging

Charge for portable device



Charge for charger

Sten 1: Connect the Micro cable to the recharge port(R) Step 2 : Connect the other end of the micro-cable to USB port



Power bank function

- 3. after searched, press match, when success, it could play music

- 4. Selfie-timer

Power bank specification

Capacity: 4400mAh Input:5V/1000mA Output:5V/1000mA Phone audio
Connected to phone audio Media audio
Connected to media a Input device

Note: connected to Android, as with selfie function, phone input cannot be input method

Power cannot insolate, not in wet place, not charge by high voltage not falling

FCC STATEMENT:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.