

SE-0205 TOOL BOX ALARM

-Remote Activated Alarm

PACKAGE INCLUDES:

- Tool Box Alarm Main Unit with two magnetic detectors...1PC
- Remote with ARM/DISARM buttons...1PC
- 12V 23A Alkaline battery (for Remote)...1 PC
- Warning Sticker... 1 PC

BATTERY INSTALLATION:

Main Alarm Unit:

- Remove the front battery cover by sliding it downwards
- Unscrew the water resistant cover
- Follow the polarity instructions and insert the three AAA Alkaline batteries (not included)
- Screw on the water resistant cover
- After the batteries are installed, the red LED will flash. The Main Alarm unit is now prepared for the Remote Unit to learn the mutual control code
- Press either the ARM or DISARM button on the Remote unit. Three short beeps will sound and the red LED will flash to indicate that the Main Alarm unit has successfully learning the code

Remote Unit:

- Unscrew the back cover to insert or replace 1pc fresh DC12V battery (included) into the battery compartment
- The red LED will turn on to indicate that the battery has been installed successfully
- Press either of the two buttons on the Remote Unit to turn OFF the red LED

OPERATION:

- Attach the alarm to the inside of your tool box using the included adhesive
- When setting up the Tool Box Alarm for the first time, place the magnetic sensors inside your truck tool box adjacent to each other. Make sure that the two sensors are not separated by more than 1 CM when the lid is closed.
- After closing the lid, press the remote and wait for the confirming beep: If one beep is heard, then Tool Box Alarm is armed. If instead four beeps sound, then the magnetic sensors are too far apart under the lid and need to be placed closer together. Open the lid, re-adjust, and try again until a "bi" sound is heard. Now the Tool Box Alarm is ready to protect your valuables.
- Use the remote to arm and disarm the Tool Box Alarm. These actions are confirmed by an audible beep and LED flash.
- The alarm will enter into arm status 5 seconds after the ARM button is pressed
- In the event of a Tool Box break-in, the armed alarm and the LED will go off continuously for one minute and then automatically reset to armed status.
- Turn OFF the alarm by pressing DISARM. Two short beeps will then sound accompanied by an LED flash.

LOW BATTERY INDICATION:

Main Alarm Unit: When the battery power becomes low, the red LED will flash at 20 second intervals to remind the user that the batteries will need to be replaced soon.

Remote Unit: If the remote distance becomes obviously shorter than average, then may indicate that the Remote unit's battery is low and needs to be replaced.

NOTES:

- Each time new batteries are placed in the Main Unit or the Remote, the alarm needs to re-learn the code by repeating the above steps.
- When the Tool Box Alarm is not in use, please remove the batteries to conserve power.
- For better performance, alkaline batteries are recommended.

DISCLAIMER:

All Doberman Security items are strenuously tested by our experienced R&D teams. Doberman, however, does not guarantee that this item will prevent all theft and/or attacks from occurring. This item is only meant to act as an alarm and alert the user of an unauthorized entry.

LIMITED WARRANTY COVERAGE:

If your product does not work properly because of a defect in materials or workmanship, Doberman will, for the length of the period as follows, which starts with the date of original purchase ("warranty period"), replace it with a new or a refurbished product.

Product	Parts	Services
All Doberman Brand Products	Ninety (90) Days	Mail-in

During the parts warranty period, there will be no charge for Parts. You must first email acquiring a RMA number, and then mail-in your product during the warranty period. This warranty only applies to products purchased and serviced in U.S.A./CANADA

The warranty is extended only to the original purchaser of a new product, which was not sold "as is". A purchase receipt or other proof of the original purchase is required for warranty service.

For assistance in U.S.A./CANADA, please visit our Website at: <http://www.dobermanproducts.com> or, send your request by E-Mail to: sales@dobermanproducts.com

LIMITED WARRANTY LIMITS AND EXCLUSIONS:

The Warranty ONLY COVERS failures due to defects in materials or workmanship, and DOES NOT COVER normal wear and tear or cosmetic damage. The warranty ALSO DOES NOT COVER damages which occurred in shipment, or failures which are caused by products not supplied By Doberman, or failures which result from accidents, misuse, abuse, neglect, mishandling, misapplication, alteration, faulty installation, set-up adjustments, miss-adjustment of consumer controls, improper maintenance, power line surge, lighting damage, modification, rental use of the product, serviced by anyone other than a factory service center or other unauthorized service, or damage that is attributable to acts of God.

THERE ARE NO EXPRESS WARRANTIES EXCEPT AS LISTED UNDER "LIMITED WARRANTY COVERAGE". DOBERMAN IS NOT LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OF THIS PRODUCT, OR ARISING OUT OF ANY BREACH OF THIS WARRANTY, INCLUDING WITHOUT LIMITATION, LOSS OF GOODWILL, PROFITS OR REVENUE, LOSS OF USE OF THIS PRODUCT OR ANY ASSOCIATED EQUIPMENT, COST OF SUBSTITUTE EQUIPMENT, DOWNTIME COSTS, OR CLAIMS OF ANY PARTY DEALING WITH BUYER FOR SUCH DAMAGES.

(As examples, this excludes damages for lost time, cost of having someone remove or re-install an installed unit if applicable, travel to and from the servicer. The items listed are not exclusive, but are for illustration only.)

ALL EXPRESS AND IMPLIED WARRANTIES, INCLUDING THE WARRANTIES OF MERCHANTABILITY, ARE LIMITED TO THE PERIOD OF THE LIMITED WARRANTY.

Some states and/or provinces do not allow the exclusions or limitations of incidental or consequential damages, or limitations on how long an implied warranty lasts, so the exclusions may not apply to you.

This warranty gives you specific legal rights and you may also have others rights which vary from state to state and from province to province. If a problem with this product develops during or after the warranty period, you may contact your dealer or service center. If the problem is not handled to your satisfaction, then write to Doberman's Customer Services Department

PARTS AND SERVICE, WHICH ARE NOT COVERED BY THIS LIMITED WARRANTY, ARE YOUR RESPONSIBILITY.

©2006, Doberman Security Products, Inc.

Tustin, CA 92780 USA

E-mail: customerservice@dobermanproducts.com

Internet: www.dobermanproducts.com

FCC LABEL COMPLIANCE STATEMENT:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

IMPORTANT NOTE:**FCC RADIATION EXPOSURE STATEMENT:**

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. To maintain compliance with FCC RF exposure compliance requirements, please follow operation instruction as documented in this manual.