



www.classicexhibits.com




www.classicexhibits.com

NOTE: When assembling horizontals they should be placed approximately one inch from TOP and BOTTOM.





Assure that a good connection is made and tighten to secure.




Step stool may be required for assembly.



© 2014

Page 1 of 5



www.classicexhibits.com







© 2014

patent D599,121

### Page 2 of 5

#### **Order #XXXXX - P10 - Fleur - Backwall Attachments**






WHEN DISASSEMBLING TIGHTEN ALL KNOBS TO PREVENT LOSS DURING SHIPPING

www.classicexhibits.com

### Step 3

#### 866.652.2100



© 2014

### patent D599,121


### Page 3 of 5

Part Number	Description
А	Left Leg Assembly
В	Right Leg Assembly
С	Horizontal Extrusion
D	Horiontal Extrusion w/ Door Stopper

Steps:

- 1) Connect lower horizontal extrusion [C] between bottom of leg assemblies [A and B] as shown.
- 2) Insert Laminated infill into grooves of leg assemblies [A and B].
- 3) Attach extrusion door between leg assemblies [A and B] and on top of laminated infill.
- 4) Attach upper horizontal extrusion w/ door stopper [D] between leg assemblies [A and B],
- and set flush with top of legs [A and B].

NOTE: Make sure the lock is flush with extrusion before tightening. If lock will not fully engage, gently rock lock and extrusion back and forth while turning knob until lock fully opens.




Align with bottom of leg assemblies [A and B].

# WHEN DISASSEMBLING TIGHTEN ALL KNOBS TO PREVENT LOSS DURING SHIPPING

www.classicexhibits.com

### Step 4

#### 866.652.2100



Page 4 of 5

Part Number	Description
-------------	-------------

Е Horizontal Extrusion

Horizontal Extrusion

Steps:

F


1) Attach horizontal extrusion [E] between vertical leg assemblies [A and B] as shown below.

2) Insert Laminated infill into grooves of vertical leg assemblies [A and B].

3) Attach upper horizontal extrusion [F] between vertical leg assemblies [A and B] atop infill.

4) Place internal shelf into assembled pedestal atop pins...

5) Set Counter atop assembled pedestal and secure with Velcro straps attached to underside of top.




Place internal shelf into workstation then place counter atop assembled workstation.

WHEN DISASSEMBLING TIGHTEN ALL KNOBS TO PREVENT LOSS DURING SHIPPING

www.classicexhibits.com

### Step 5


#### 866.652.2100



patent D599,121

© 2014

#### Page 5 of 5




Vertical Connection Bar

www.classicexhibits.com

866.652.2100

### Additional Items:

- Setup Hardware
- Graphic
- (3) Lights



# Top View




WHEN DISASSEMBLING TIGHTEN ALL KNOBS TO PREVENT LOSS DURING SHIPPING

www.classicexhibits.com

#### 866.652.2100

© 2014



# Top View of Each Level

WHEN DISASSEMBLING TIGHTEN ALL KNOBS TO PREVENT LOSS DURING SHIPPING

www.classicexhibits.com

866.652.2100

