

Manual


Rolls Royce Model Car

Instructions and Components




Checking package content

- Rolls Royce model Car
- Remote control (M6005)



Remote control details

- See below the controller buttons assignment:



Needed before start

- Wall socket for USB 100-240V~50-60HZ 0.15A

Prepare for use

- Connect the wall socket to a standard housing electric plug
- Connect USB cable from the Rolls Royce model Car to the wall socket
- Take the controller and turn it ON

Turn ON/OFF the model Car

- Press button 1 one time, you just opened the model Car
- Press button 1 a second time, you activated all functions and can now switch all the lights
- Press button 1 a third time and then the electronic functions will all change to OFF

Light functions

- Press button 2 one time will activate the low beam lights
- Press button 2 a second time will turn on the High beam lights
- Press button 2 a third time will back to the low beam lights
- Press button 2 a fourth time will turn off the driving lights

- Press button 3 one time will turn on the flashers
- Press button 3 a second time will turn off the flashers

- Press button 4 one time will turn on the brake lights
- Press button 4 a second time will turn off the brake lights and turn on the reversing gear lights
- Press button 4 a third time will turn off brake and reversing lights

- Press button 5 one time will turn on the interior lights at the front of the model car
- Press button 5 a second time will turn off the interior lights at the front of the model car

- Press button 6 one time will turn on the interior lights at the rear of the model car
- Press button 6 a second time will turn off the interior lights at the rear of the model car

Motorized door functions

- Press button 7 one time will open the Front Left door
- Press button 7 a second time will close the Front Left door

- Press button 8 one time will open the Front Right door
- Press button 8 a second time will close the Front Right door

- Press button 9 one time will open the Rear Left door
- Press button 9 a second time will close the Rear Left door

- Press button 10 one time will open the Rear Right door
- Press button 10 a second time will close the Rear Right door

- Press button 11 one time will open the Bonnet
- Press button 11 a second time will close the Bonnet

- Press button 12 one time will open the Boot
- Press button 12 a second time will close the Boot

FCC ID: 2AQYS-M6005

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter