


## USE AND CARE GUIDE

### BLUETOOTH SPEAKER



**THANK YOU**

We appreciate the trust and confidence you have placed in CE Tech through the purchase of this bluetooth speaker. We strive to continually create quality products designed to enhance your home. Visit us online to see our full line of products available for your home improvement needs. Thank you for choosing CE Tech!

## Operation



### 1 Turning on the speaker

- Place the on/off switch (A) to the ON position to turn on the speaker. The blue indicator light (B) will flash and attempts to detect Bluetooth-enabled devices near you.

The blue indicator light (B) will stop flashing if no Bluetooth device is detected within 5 minutes.

- Either pair the speaker with the desired Bluetooth device or connect the speaker to your music player using the AUX cable (D). Plug the mini-USB end of the AUX cable (D) into the mini-USB port on (C) on the speaker and the other end of the AUX cable (D) into your music device.

**NOTE:** If you need to pair the speaker with another Bluetooth device, disconnect the speaker from the Bluetooth device already in use first.



## Safety Information

Please read and understand the instructions in this manual before using this product. Save this manual for future reference.

### FCC STATEMENT

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

- WARNING:** This appliance is intended for domestic household use only and should not be used for any other purpose or in any other application, such as for non domestic use or in a commercial environment.
- WARNING:** The ventilation should not be impeded by covering the ventilation openings with items such as newspapers, table cloths, and curtains. Allow at least a 10 cm gap all around the product.
- WARNING:** No naked flame sources, such as lighted candles, should be placed on the speaker.

## Safety Information (continued)

- WARNING:** Do not expose the speaker dripping or splashing. Do not place objects filled with liquids, such as vases, on the speaker.
- WARNING:** This speaker is not suitable for use in a tropical climate.
- WARNING:** Do not expose this speaker to excessive heat such as sunshine, fire or the like.

### BATTERY HANDLING AND USAGE

The product is supplied with one rechargeable Lithium 3.7V 300 mA battery incorporated in the product which is not accessible and cannot be replaced. Therefore when the product reaches the end of its useful life it must be disposed of at a recycling center. You must follow laws and regulations about disposal. Waste electrical products and batteries must be disposed of separately from household waste when the product reaches the end of its life. The batteries must be disposed of at your local recycling facility.

## Warranty

The manufacturer warrants to the original purchaser or user for a period of one year from the date of the original retail sales invoice that the accompanying product will be free from defects in materials and workmanship if properly assembled, installed, and operated. In no case will the manufacturer be liable for the incidental or consequential damages, whether such damages are claimed on account of the breach of warranty, breach of contract, negligence, or strict/product liability, including without limitation damage to property other than the product or economic losses.

Contact the Customer Service Team at 1-800-394-7519 or visit [www.HomeDepot.com/CETech](http://www.HomeDepot.com/CETech).


## Pre-Operation

### SPECIFICATIONS

- 5V, 500 mA
- Transmission Distance:** ≤ 10 m – Varies when the environmental factors and the connected Bluetooth devices are different.
- Power:** Built-in Lithium battery

### PRODUCT DESCRIPTION

The product also includes one rechargeable Lithium 3.7V 300 mA battery.



Part	Description
A	On/Off switch
B	Blue/Red indicator light
C	Mini USB and Auth port
D	AUX cable
E	USB cable

### 2 Charging the speaker

The speaker has a built-in Lithium battery. The battery is rechargeable and provides approximately 2-hours of continuous operation when fully charged.

- Plug the mini-USB connector end of the USB cable (E) into the mini USB port (C) on the speaker.
- Plug the USB end of the USB cable (E) into any device that can charge the speaker such as a PC or use a USB plug.
- The red indicator light (B) will illuminate.
- The red indicator light (B) will go out when the speaker is fully charged.

