


Wireless Slim Speaker

Model #: BT8500BLK



User Manual

All trademarks are trademarks or registered trademarks of their respective companies. The Bluetooth word mark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by Gear Head is under license. Other trademarks and trade names are those of their respective owners.

ı	н	C		D	, C	F	$\boldsymbol{\cap}$	\frown	D		١.
L	J٠	J	ᆮ	П	•) r	u	v	П	ப	١.

To provide quality customer service and technical support, it is suggested that you keep the following information as well as your store receipt and this user manual.					
·					
Date of Purchase:					
Model Number:					
Product Rev Number (located below the UPC on the package):					

PACKAGE CONTENTS:

Your new speaker will ship with the following items:

Wireless Slim Speaker

USB to Micro USB Charging Cable

User Manual and Warranty Information


SYSTEM REQUIREMENTS:

Works with:

Bluetooth wireless technology enabled devices.

INDICATION:

NOTE: The pictures shown in this User Manual are for demonstration purposes only. Your speaker may look slightly different.



1. Power-on state:

Switch on the speaker. The speaker will give out a warning tone and the Bluetooth indicator light flashes Blue.

2. Bluetooth connection:

- 1. Please turn your device and speaker on, then search the pairing model number "GH_BT8500" and pair it manually.
- 2.At first, the speaker will give out a warning tone, Bluetooth indicator light flashes Red and Blue alternately during pairing, it will flash Blue slowly after successful connection and also you will hear a warning tone .If Bluetooth speaker fails to detect any equipments, about 10 minutes, the speaker will shut itself down automatically.
- 3. To make another connection, it is necessary to switch on. The Bluetooth device once connected successfully ,which means the Bluetooth is activated ,and it will be connected automatically next time.
- **3. Smart automatic quick charge:** Charging the speaker, one side, insert an available USB power cable into the Micro USB charge port of the speaker ,another side, connect with computer USB port or an USB charger. At the beginning, the charging indicator light flashes Red and Blue alternately at standby state or flashes Red at switch-off state, while it will finally change to Blue light after full charging.

CONSIDERATE HINTS:

- 1) If connection fails, please switch off the device to restart. It may be low power with battery. Please charge it.
- 2) Pairing should be in the valid distance or it may fail to work.
- 3) Do not turn up the volume to a fair high level constantly as this could shorten the service life of this product or impair your hearing.
- 4) The Bluetooth transmission range or connectivity could be affected by low battery power. In that case, please recharge immediately.
- 5) When encountering any faults during operation, please cut off the power supply and disconnect the USB cable to prevent further damage to the speaker or other components.

TROUBLESHOOTING

Problems	Solutions
	Check whether the speaker is still in the process of searching or switch it off and then turn it on.
Unable to pair with other devices	2. Check whether the speaker is in the valid range of pairing.
	3. There are too many Bluetooth devices in the proximity that may cause difficulties in connection. Please turn them off.
The sound is rather low or distorted	Check the Bluetooth device's volume and then adjust it to a proper level on your mobile devices or your computer.
	2. Recharge the speaker if necessary.
The music stops from time to	Check whether the speaker is in the effective transmission range.
time	2. There is an obstacle standing between the speaker and Bluetooth devices.
The Bluetooth indicator remains off	It suggests the battery power drops quite low and retry once being recharged.
	2. Turn it on again.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- —Increase the separation between the equipment and receiver.
- —Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- —Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.