

**SPECIFICATION**

Model: Electra Bluetooth® Headphones  
 Bluetooth Specifications: Bluetooth® V4.2  
 Transmission distance: up to 10 m (This may vary based on environmental factors or the type of Bluetooth® device being used)  
 Built-in battery: 300 mAh Lithium battery  
 USB Recharge voltage: DC 5V/500mAh  
 Output power: 30mW  
 Frequency Response: 20Hz-20KHz  
 Sensitivity: 105db (AT 1KHZ+3db)  
 Product dimensions: 6" x 7" x 2"

**PACKING**

- Bluetooth® Headphones
- Micro USB Charging Cable
- User Manual


**Electra Bluetooth® Headphones**

Instruction Manual

Back Cover

Front Cover

**OVERVIEW**



page 02

**BLUETOOTH OPERATION**

1. Please ensure that the Bluetooth function has been turned on in the settings of your Bluetooth enabled device.
2. Turn the headphones on by pressing the power button for 3 seconds. The indicator light will flash to detect Bluetooth enabled devices near you and will enter pairing mode. The indicator light will go off if no Bluetooth devices are detected within 5 minutes.
3. "GEMLINE HP" will appear on the Bluetooth device list, select "GEMLINE HP" to establish pairing. If instructed to enter a PIN code, please enter '0000'.
4. When you want to play audio from another Bluetooth device, disconnect the headphones from the original device and follow steps 1-3 to re-pair the headphones with a new Bluetooth enabled device.
5. Press the multi-function button to play/pause audio. Press the - button once for last track, press and hold the - button for volume down. Press the + once for next track, press and hold the + button for volume up.

page 03

**SPEAKERPHONE OPERATION**

1. If you receive a call during Bluetooth mode, press the multi-function button to answer the call. Press the button again to end the call.
2. To dial the last phone number dialed, double click the multi-function button.

**AUX PLAYBACK OPERATION**

1. Turn on the headphones.
2. Connect the headphones to a smartphone, audio device, or laptop with the 3.5mm AUX cable (not included).
3. Play/Pause as desired by pressing the multi-function button.
4. The volume and next/previous song button can only be adjusted on the device that is connected through the 3.5mm AUX cable.

**CHARGING THE HEADPHONES**

1. When the battery is low, please charge via the included Micro USB cable. The charging time is approximately 1.5 hours and provides up to 4 hours of continuous operation.
2. The LED indicator light will be red during charging and will turn off once it is fully charged.

page 04

**WARNING**

1. Do not disassemble, repair, or modify the headphones.
2. Do not place product in or near fire to avoid danger, as it uses a lithium battery.
3. Avoid storage at extreme temperatures, this can shorten the battery life and may affect the headphones.
4. Keep the headphones dry and do not store the headphones in damp areas to avoid damage to the headphones.
5. Avoid dropping the headphones as it may damage the product.

**KIND REMINDER**

1. To prolong the headphones life span and to avoid hearing damage, please do not listen to music under high volume for long periods of time.
2. When an error occurs with the headphones, please turn off the headphones and restart it to troubleshoot.
3. When the headphones power is low, the Bluetooth range may be affected. Please charge the headphones to avoid disruptions during use.

page 05

PROBLEM	TROUBLESHOOTING METHOD
Unable to pair the headphones with a mobile device	1. Inspect whether the headphones are searching for a Bluetooth enabled device to connect to. If not, restart the headphones. 2. Difficulty in searching and connecting to a desired device can be affected if multiple devices are equipped, turned on, and in range for Bluetooth connectivity. Please turn off or disable the Bluetooth function on the other devices. 3. The power of the battery is insufficient, please recharge the headphones.
The music stops from time to time	1. Inspect the distance between the headphones and the Bluetooth enabled device, it may exceed the Bluetooth transmission range. 2. Inspect if there is an obstacle between the headphones and the Bluetooth enabled device. 3. The power of the battery is insufficient, please recharge the headphones.

page 06

PROBLEM	TROUBLESHOOTING METHOD
The sound is low or distorted	1. Inspect the volume of the connected headphones or Bluetooth enabled device and adjust the volume as needed. 2. The power of the battery is insufficient, please recharge the headphones.
The Bluetooth indicator light remains OFF	1. The power of the battery is insufficient, please recharge the headphones. 2. Restart the headphones.

page 07

**#3976\_Electra Bluetooth® Headphones Instruction Manual**

Please read the following clearly before you do the printing of all kind of our instruction sheets.

- 1) The folded size should be 3"W x 3"H.
- 2) Please exactly follow all the trim marks and fold marks.
- 3) Please exactly follow the page in proper order.(The page numbers do not need to print.)
- 4) The color of this kind instruction is : 1C(Black)
- 5) Use 90gsm gloss art paper for bulk production.
- 6) 8PP Book Binding with saddle stitching.

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.